












<div><div>FIO MOTUS</div><div></div><div><div>FIO MOTUS FM20</div><div>Quick Start Guide</div></div></div>	<div><div>FIRST TIME SETUP: BLUETOOTH PAIRING</div><div><div><div>1 Turn on the Bluetooth in your device settings.</div><div></div></div><div><div>2 Press and hold button for 5 seconds. Release. Lights will flash blue/red.</div><div></div></div><div><div>3 Select“ FIO MOTUS FM20” in your device Setting to connect.</div><div></div><div>Power on 3S, Pairing 5S.</div></div><div>Once successfully connected, the headphone will memorize your device and automatically pair when turned on in the future.</div></div></div>	<div><div>BUTTON FUNCTIONS</div><div></div><div><div>Connected To Bluetooth: Cycle Be Ambient Sound / ANC On / ANC Off. Press Once</div><div>Power On / Off: Press & Hold 3+ Seconds</div><div>Play / Pause / Answer / Hang Up Calls: Press Once</div><div>Reject Incoming Call: Press & Hold 1 Second</div><div>Activate Siri (Ios) Or “Ok Google” (Android): Press Twice</div><div>Bluetooth Pairing: See First Time Setup</div><div>Volume Down: Press Once</div><div>Track Backward: Press & Hold 1+ Seconds</div><div>Volume Up: Press Once</div><div>Track Forward: Press & Hold 1+ Seconds</div></div></div>	<div><div>CHARGING</div><div></div><div>Connect to computer or USB 5V 1A (or less) output device.</div></div>	<div><div>AUX INPUT</div><div></div><div><div>NOTE :</div><div><div>The AUX INPUT will override your Bluetooth device connection. Unplug and press power button 3 + seconds to revert back to Bluetooth.</div><div>The button functions for your Bluetooth device will not work when AUX INPUT is connected.</div><div>The volume will be dependent on your AUX device settings, Adjust accordingly.</div></div></div></div>
<div><div>Troubleshooting</div><div><div>If the headphones are not working correctly, turn them on/off to reset</div><div>If the headphones won't turn on, recharge the battery and try again</div><div>If the headphones won't charge, make sure the power supply works, is 5V 1A, and not damaged</div><div>If the headphones make no sound or do not show as an available device, make sure they are not paired to a different device already</div><div>To re-enter pairing mode hold the power button for 5 seconds when headphones are off</div></div><div><div>need some help?</div><div>Can't get it to pair? Have a question or comment?</div><div><div>✉</div><div>service@fiomotus.com</div></div></div><div><div>Important Safety Information</div><div><div>Avoid dropping.</div><div>Do not disassemble.</div><div>Do not submerge in water.</div><div>The product should not be exposed to dripping or splashing.</div><div>Avoid extreme temperatures.</div><div>The product should not be exposed to excessive heat such as sunshine, fire or the like.</div><div>Use original or certified cables.</div><div>Clean with a dry, soft lint-free cloth. Do not use any corrosive cleaner or oil.</div><div>Do not use the product outdoors during thunderstorms.</div></div></div></div>	<div><div>Hearing Safety</div><div><div>To avoid hearing damage , do not listen for extended periods at high volume.</div><div>Do not turn the volume so high that you're unable to hear your surroundings.</div><div>Do not use earphones while driving.</div><div>You should use caution or temporarily discontinue use in potentially hazardous situations.</div></div><div><div>Notice</div><div><div>CE</div><div>This product complies with the radio interference requirements of the European Community.</div></div></div><div><div>CAUTION</div><div><div>Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery , that can result in an explosion; Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;</div><div>A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.</div></div><div><div>This symbol means the product must not be discarded as household waste,and should be delivered to an appropriate collection facility for recycling.Follow local rules and never dispose of the product and rechargeable batteries with normal household waste. Correct disposal of old products and rechargeable batteries helps prevent negative consequences for the environment and human health.</div></div></div></div>	<div><div>Warning</div><div><div>FCC ID:2BCN9-FM20 Model:FM20 Input: DC5V1A Made in China. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</div><div>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</div><div>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.</div><div>If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</div><div>--Reorient or relocate the receiving antenna.</div><div>--Increase the separation between the equipment and receiver</div><div>--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</div><div>--Consult the dealer or an experienced radio/TV technician for help</div><div>NOTE:This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter</div><div>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</div></div></div>	<div><div><div>FIO MOTUS</div><div></div></div><div><div><div>GET IT ON</div><div>Google Play</div></div><div>Google Play and the Google Play logo are trademarks of Google Inc</div></div><div><div><div>Download on the</div><div>App Store</div></div><div>Apple and the Apple logo are trademarks of Apple Inc</div></div><div></div><div>Download the FIO MOTUS app for EQ setting and firmware update.</div></div>	<div><div>FIO MOTUS</div></div>