

User Manual

Manufacturer:	Shenzhen Jiemeisen Technology Co., Ltd
Address of manufacturer:	Huafeng Xin'an Youth Incubation Base 3A46, District 41, Bao'an District, Shenzhen
Product Name:	Bluetooth Speaker
Model No.:	CM-002
FCC ID:	2BCQ5-CM-002

1. product introduction

Thank you for choosing our Bluetooth speaker! This product uses advanced Bluetooth technology, supports wireless connection, and is compatible with a variety of Bluetooth devices to provide you with high-quality music experience. Please read this manual carefully to ensure proper use and full performance of the product.

2. Product specifications

Model: CM-002

Bluetooth version: 5.3

Wireless range: 10M

Battery capacity: 3600mAh

Playback time: 10H

Charging time: 3H-4H

Input interface: TYPE-C

Size: 87mm × 86mm × 246mm

Weight: 550g

3. product components

Bluetooth audio host

TYPE-C charging cable

Instructions

4. Instructions for use

1. Turn on/off Power on:

Press and hold the power button for 3 seconds, the indicator lights up and emits a prompt tone, indicating that the power is on. Power off: Hold down the power button for 3 seconds. When the indicator is off and a prompt tone is played, it indicates that the power is off.

2. Bluetooth pairing

- ①.Turn on the audio power and enter the Bluetooth pairing mode (the indicator flashes).
- ②.Turn on the Bluetooth function of your mobile phone or other Bluetooth device to search for available devices.
- ③. Select "Bullet" from the device list to connect.
- ④. After the connection is successful, the indicator is steady on and a prompt tone is played.

3. Play music

- ① After the connection is successful, you can play music through the Bluetooth device, and the stereo will automatically play simultaneously.
- ② Use the volume key of the Bluetooth device or the volume key of the stereo to adjust the volume.

4. Charge

- ① Use the included TYPE-C charging cable to connect the audio and power adapter or computer USB port.
- ② When charging, the indicator light is steady red; When full, the indicator turns green.
- ③ After charging, please unplug the charging cable.

5 Reset

If you encounter connection problems, you can reset the stereo: ①. In the off state, press and hold the power button and volume down button for 5 seconds at the same time. If the indicator blinks rapidly, the reset is successful.

5. Precautions

- (1) Do not expose the speaker to high temperature, humidity or strong magnetic field.
- (2) Do not disassemble or modify the stereo to avoid damage or safety risks.
- (3) When not in use for a long time, please turn off the power and charge regularly to keep the battery active.
- (4) Please use the original charging cable or charging equipment that meets the specifications, and avoid using inferior chargers.
- (5) If you find abnormal sound (such as fever, odor, etc.), please stop using immediately and contact after-sales service.

6. common problems

- (1) The Bluetooth device cannot be connected
 - Make sure the speaker is in pairing mode (indicator flashing).
 - Make sure the Bluetooth device is enabled and searchable.
 - Ensure that the distance between the speaker and the Bluetooth device is within 10 meters.
 - Try resetting the stereo and repairing.
- (2) The sound is not clear or intermittent
 - Check whether there is an obstacle between the speaker and the Bluetooth device.
 - Ensure that the distance between Bluetooth device and speaker is within effective range.
 - Check whether the Bluetooth device volume is low.

(3) Short battery life

- Make sure the speaker is fully charged.
- Reduce volume or turn off unnecessary features to extend battery life.
- If the battery is old, contact after-sales service to replace the battery.

7. After-sales service

- This product enjoys one year limited warranty service.
- The warranty covers hardware failure that is not caused by human damage.

8. Waring

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

9. Environmental tips

Do not discard this product at will, and dispose of it in accordance with local e-waste recycling regulations to protect the environment.

Thank you for your support and trust! Wish you a happy use!