

102*70mm
70g 双胶纸

408 mm


280 mm

OPENFREE

User Manual


Pairing

1. Open the charging case for the first time and remove the earbuds to automatically enter pairing mode.
2. Turn on the Bluetooth on the device you want to pair with, and search for the earbuds named [ROSE OpenFree] to connect.




Resetting

1. Place the earbuds in the charging case with the case lid open. Press and hold the reset button on the charging case for 5 seconds until the indicator light on the case pulses white three times, indicating a successful reset.
2. After the reset, close and reopen the charging case to automatically enter pairing mode.



Charging

1. Place the earbuds in the charging case and close the lid to charge.
2. Use a USB-C cable to charge the charging case.



* Battery status: 0 White light >70%; ● Green light 30% - 70%; ● Orange light <30%; ● Orange light pulsing <10%.
* Charging: White light pulsing; Charging completed: White light off.

Touch Control (Customizable in the app)

● Single Tap ● Press / N/A

Action	Left Earbud (L)	Right Earbud (R)
Previous Track	***	/
Next Track	/	***
Play / Pause	**	**
Answer Call	*	*
End Call	*	*
Reject Call	**	**
Volume Down	*	/
Volume Up	/	*
Voice Assistant	==	==
Game Mode	*****	*****

Safety Precautions

1. Follow Regulations: Turn off the device in areas where wireless devices are prohibited.
2. Maintain Distance: Keep at least 15cm away from implanted medical devices (e.g., pacemakers).
3. Volume Control: Set an appropriate volume to avoid hearing damage.
4. Temperature Range: Use the device and accessories between 5°C and 35°C. Extreme temperatures may cause malfunction.
5. Storage: Store in a well-ventilated, cool place away from direct sunlight (e.g., not on car dashboards or windowills).
6. Keep Away from Children: This device is not a toy. Use under adult supervision and store out of children's reach to avoid damage or choking hazards.
7. Avoid Distractions: Do not use while driving, operating machinery, or performing tasks requiring full attention.
8. Avoid Thunderstorms: Do not use during thunderstorms to prevent malfunction or electric shock risks.
9. Avoid Heat and Impact: Keep away from heat sources or open flames; avoid strong impacts or vibrations.
10. Cleaning: Use a dry, soft cloth for cleaning. Do not use harsh chemicals or heating tools (e.g., hair dryers, microwaves).
11. No Unauthorized Repairs: Do not disassemble or modify the device.
12. Use Approved Chargers: Only use approved or compatible chargers to prevent faults, fire, or explosion risks.

Warranty (In case of discrepancies, national laws and regulations take precedence)

1. We offer a 1-year (i.e. 365 days) warranty coverage for our products (excluding carry cases, ear tips and other accessories). Warranty period starts from the date of purchase.
 2. Our Warranty covers any factory defects that might affect the proper functionality. It does not cover any man-made damage due to human error, negligence and etcetera.
 3. Once we have confirmed that your item is defective due to manufacturing issues, we will arrange for a replacement, partial refund or a full refund upon return (if applicable).
 4. Before proceeding in our warranty policy, please provide the order number and state the issue clearly.
- * The warranty does not cover the following situations:
1. Expired Warranty: The warranty period has ended or the product's validity cannot be verified.
 2. No Proof of Purchase: Absence of a valid purchase receipt (order screenshot or invoice).
 3. Improper Use: Damage caused by not following the user manual's instructions for use, maintenance, or care.
 4. Accidental Damage: Damage due to product drops or water immersion.
 5. Unauthorized Repairs: Damage resulting from unauthorized disassembly or modifications.
 6. External Factors: Damage caused by unavoidable events (e.g., fire, earthquake, lightning).
 7. Normal Wear and Tear: Scratches and other damage due to natural wear.

* FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction


Statement

We provide customer service only for products purchased directly from Rose Technics or Rose Technics authorized distributors. If you have purchased from a different seller, please contact them for any exchange or refund request.

Thank you for purchasing authentic Rose Technics products. For any assistance, please contact us freely.


Bluetooth ペアリング

1. 充電ケースを初めて開け、イヤホンを取り出すと自動的にペアリングモードに入ります。
2. イヤホンとペアリングするデバイスの Bluetooth スイッチをオンにし、[ROSE OpenFree] というイヤホン名を検索してペアリング接続してください。



工場出荷時設定に戻す

1. イヤホンを充電ケースに入れ、充電ケースの蓋を開いた状態で、充電ケースのリセットボタンを5秒押し続けます。充電ケースのインジケータライトが3回点滅すると、工場出荷時の設定に戻りました。
2. 工場出荷時設定に戻した後、充電ケースの蓋を閉じ、再度開けると自動的にペアリングモードに入ります。



充電

1. イヤホンを充電ケースに入れ、充電ケー
2. USB-C充電ケーブルを使用して



* 0 白色の点灯 > 70%; ● 緑色の点灯 30% - 70%; ● オレンジ色の点灯 < 30%; ● オレンジ色の点滅 < 10%.
* 充電中は白色の点滅。充電完了後は白色の点灯が点滅します。

タッチ機能 (カスタムタッチはアプリで設定可能)

● タップ ● 長押し / 未操作

-	左イヤホン (L)	右イヤホン (R)
機能	左イヤホン (L)	右イヤホン (R)
前の曲	***	/
次の曲	/	***
再生/一時停止	**	**
通話を受ける	*	*
通話を終了する	*	*
拒否	**	**
音量を下げる	*	/
音量を上げる	/	*
音声アシスタント	==	==
ゲームモード	*****	*****

安全情報

1. 禁止されている場所でのワイヤレス機器の使用は、規定に従いデバイスを閉じてください。
2. このデバイスを使用する際は、植え込み型医療機器（ペースメーカーなど）とは少なくとも15センチの距離を保ってください。
3. 適切な音量を設定し、聴力を損傷しないようにしてください。
4. デバイスおよびアクセサリは5℃から35℃の範囲内で使用してください。過度に高いまたは低い温度環境はデバイスの故障を引き起こす可能性があります。
5. デバイスおよびアクセサリは通気性が良く、涼しい場所に保管し、直射日光を避けてください。車のダッシュボードの上や窓辺など。
6. このデバイスはおもちゃではありません。子供は大人の監督のもとで使用する必要があります。デバイスおよびアクセサリは子供の手の届かない場所に保管し、意図しない損傷や事故による窒息などの危険を回避してください。
7. 車の運転、機械操作、または注意を集中する必要がある他の作業中にデバイスをしないでください。
8. 雷のある天候下でのデバイスの使用は避け、デバイスの故障や感電の危険を回避してください。

安全情報

9. デバイスを熱源や露出した火元に近づけないでください。強い衝撃や振動を避けてください。
10. 強力な化学製品や洗剤を使用してデバイスを清掃しないでください。乾いた柔らかい布で拭くだけで大丈夫です。デバイスを乾燥させるためにヘアドライヤーや電子レンジなどの加熱ツールを使用しないでください。
11. デバイスを勝手に分解したり改造したりしないでください。
12. 製造されていないまたは互換性のない充電アダプターを使用すると、故障、発火、爆発などの危険があります。

アフターサービス

以下、国家の法律に違反する場合、国家の法律を優先します。

1. 当社の製品には、購入日から1年（すなわち365日）の保証期間が適用されます（ケース、イヤークリップ、その他のアクセサリは除く）。保証期間は購入日から開始します。
2. 当社の保証は、適切な機能に影響を及ぼす可能性がある工場の欠陥をカバーします。人為的なミスや過失などによる人為的な損傷はカバーされません。
3. 製造上の問題による不良を確認した場合、交換、一部返金、または全額返金の手配をいたします（該当する場合）。

* 以下のいずれかに該当する場合、保証の対象外となります

1. 保証期間を超過した場合、または製品が保証期間内であることを証明できない場合。
2. 有効な購入証明書（注文のスクリーンショットまたは請求書）がない場合。
3. 説明書の指示に従って使用、保守、お手入れをしていない場合による損傷。
4. 製品の落下や水没による損傷。
5. 自己解体や改造など的人為的原因による損傷。
6. 火災、地震、雷撃などの不可抗力による損傷。
7. 自然摩耗による傷などによる損傷。



DOWNLOAD ROSELINK




OPENFREE

使用说明书


蓝牙配对

1. 首次打开充电盒，取出耳机，自动进入配对状态。
2. 耳机恢复出厂设置后，首次开机耳机将进入配对状态。
3. 打开与耳机配对设备的蓝牙开关，搜索耳机名称选择配对连接。



恢复出厂设置

1. 耳机放入充电盒中，保持充电盒开盖状态，长按充电盒复位键5s，充电盒白光交替闪烁3次，即恢复耳机出厂设置。
2. 恢复出厂设置完成后，关闭充电盒盖，重新打开进入配对模式。



充电

1. 将耳机放入充电盒后，合上充电盒盖进行充电。
2. 使用USB-C充电线为充电盒充电。



*电量指示：0 白灯亮70%以上；● 绿灯亮30%-70%；● 红灯亮30%以下；● 红灯闪烁3次（1s为周期）10%以下。
*充电中灯光明度闪烁。充电完成时白灯常亮。

功能使用

1. 您可以使用手机下载“ROSELINK”APP，自定义耳机的操作功能；
2. 在应用商店搜索“ROSELINK”APP或者扫描左图二维码下载安装。

ROSELINK

产品中有害物质的名称及含量

部件名称	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)
金属零件	X	O	O	O	O	O
电池	X	O	O	O	O	O
塑料部件	O	O	O	O	O	O
线缆	X	O	O	O	O	O
电源适配器	X	O	O	O	O	O

本产品符合RoHS/REACH法规要求。有害物质含量符合GB/T 26572规定的限量要求。且目前业界没有成熟的替代方案。符合欧盟RoHS指令环保豁免条款。

10 本产品的“电子电气产品有害物质限制使用标志”为10年，其标识如左图所示。本产品及其组件上的使用期限限制可能有所不同，组件上的使用期限标识优先于产品上任何与之相冲突的不同的环保使用期限标识。

触控功能

● 单击 ● 长按 / 无操作

-	左耳机 (L)	右耳机 (R)
功能	左耳机 (L)	右耳机 (R)
上一曲	***	/
下一曲	/	***
播放/暂停	**	**
接听	*	*
挂断	*	*
拒接	**	**
音量减	*	/
音量加	/	*
语音助手	==	==
游戏模式	*****	*****

安全信息

在使用和操作设备前，请阅读并遵守下面的注意事项，避免出现危险或非法的情况。

提示

1. 在禁止使用无线设备的场所，请遵守该场所的规定，并关闭设备。
2. 在使用本设备时，请与植入式医疗设备（如起搏器等）保持至少15厘米的距离。
3. 当您使用设备收听音乐或通话时，建议使用音乐或通话所需的最小音量，以免损伤听力；长时间接触高音量可能会分散注意力，从而导致事故。
4. 请在温度5℃~35℃范围内使用及存放设备及配件，当环境温度过高或过低时，可能会引起设备故障。
5. 请将设备及配件放置在通风、阴凉、无阳光直射的地方。
6. 请将设备及配件放置在儿童接触不到的地方，儿童可能在无意中损坏本设备及其配件，或吞下小零件导致窒息或其他危险。
7. 本设备并非玩具，儿童应在成人监护下使用设备。

售后服务说明

以下若有与国家政策不符或遗漏之处，以国家政策为准。


1. 自购买之日起的7日内，因产品质量问题可退货；30日之内，因质量问题可换货；12个月内，因产品质量问题造成性能故障，消费者可享受保修服务。
2. 在三包有效期内，用户必须凭其购买发票和有效三包凭证才能享受三包、包换、保修的权利。
3. 本公司对产品的其他配置（如包装盒等）不承担三包责任。
4. 所有在保修期后被维修或更换下来的零件、部件和附件等归本公司所有。

在用户使用过程中，符合下列情况之一者不在保修范围内：

1. 超过三包有效期。
2. 无三包凭证及购机发票，且无法证明该产品在三包有效期内。
3. 未按产品说明书要求使用、维护、保养而造成损坏。
4. 在使用过程中因产品跌落或水浸而造成损坏。
5. 由于擅自拆卸、改装、人为原因造成的故障。
6. 由于不可抗力因素（如火灾、地震、雷击等）而造成故障或损坏。
7. 未按说明书或操作手册中的要求使用而造成损坏。
8. 产品自然磨损（如外壳）。


蓝牙配对

1. 首次打開充電盒，取出耳機可自動進入配對狀態。
2. 打開與耳機配對設備的藍牙開關，搜索耳機名稱[ROSE OpenFree]進行配對連接。




恢復出廠設置

1. 將耳機放入充電盒中，保持充電盒開蓋狀態，長按充電盒復位鍵5s，見充電盒指示燈白光閃爍3次，即成功恢復出廠設置。
2. 恢復出廠設置後，關閉充電盒蓋並重新打開，自動進入配對模式。



充電

1. 將耳機放入充電盒後，合上充電盒蓋給耳機進行充電。
2. 使用USB-C充電線為充電盒充電。



*电量指示：0 白灯亮 > 70%; ● 绿灯亮 30% - 70%; ● 红灯亮 < 30%; ● 红灯快速闪烁 < 10%.
* 充电中 白灯呼吸；充电完成 白灯常亮。

触控功能

(自定义触控可在APP中设置) ● 单击 ● 长按 / 无操作

-	左耳机 (L)	右耳机 (R)
功能	左耳机 (L)	右耳机 (R)
上一曲	***	/
下一曲	/	***
播放/暂停	**	**
接听	*	*
挂断	*	*
拒接	**	**
音量减	*	/
音量加	/	*
语音助手	==	==
游戏模式	*****	*****

安全信息

1. 在禁止使用無線設備的場所，請遵守規定關閉設備。
2. 在使用本設備時，請與植入式醫療設備（如起搏器等）保持至少15厘米的距離。
3. 請設置合適的音量大小，避免損傷聽力。
4. 請在5℃~35℃範圍內使用該設備及配件。過高或過低的環境溫度可能引起設備故障。
5. 將設備及配件保存在乾燥、陰涼的地方，避免陽光直射，如汽車儀表盤上方、窗臺等。
6. 本設備並非玩具，兒童或在成人監督下使用；將設備及配件保存在兒童接觸不到的地方，避免意外損壞、或誤吞導致窒息等危險。
7. 請勿在駕車、操作機器或從事其他需要集中注意力的工作時使用。
8. 請勿在雷雨天氣下使用該設備，避免設備故障或電擊危險。
9. 勿將設備靠近熱源或強電源的火源，避免設備受到強烈的衝擊或震動。
10. 勿使用刺激性化學品或強洗滌劑清潔設備，使用乾乾淨的軟布擦拭即可；勿使用加熱工具對設備進行乾燥處理，如電吹風、微波爐等。
11. 勿擅自拆卸或改裝設備。
12. 使用未經認可或不兼容的充電設備，可能導致故障、起火、爆炸等危險。

售後服務

以下若有與國家法律法規不符之處，以國家法律法規為準。

1. 我們為我們的產品提供為期1年（即365天）的保修服務（不包括攜帶盒、耳塞和其他配件）。保修期從購買日期開始計算。
2. 我們的保修範圍包括可能影響正常功能的任何工廠缺陷，不包括任何由於人為錯誤、疏忽或造成的人為損壞。
3. 一旦我們確認您的產品因製造問題而有缺陷，我們將在退回物品後安排更換、部分退款或全額退款（如果適用）。

*符合下列情況之一者不在保修範圍內：

1. 超過warranty policy有效期間，或無法證明產品在有效期間內。
2. 無有效的購買憑證（訂單截圖或發票）。
3. 未按說明書的要求使用、維護、保養而造成損壞。
4. 在使用過程中因產品跌落或水浸而造成損壞。
5. 因擅自拆卸、改裝等人為原因而造成損壞。
6. 由於不可抗力因素（火災、地震、雷擊等）而造成損壞。
7. 產品自然磨損造成的損壞等。



下載 ROSELINK

