

Instruction Manual

Car player

说明书

车载播放器

1. HOME

In the task bar click  to enter the main menu interface.



- ① Click here to enter radio player interface.
- ② Click here to enter the music player interface.
- ③ Click here to enter the video player interface.
- ④ Click here to go to photo browsing interface.



- ⑤ Click to go to AV IN interface.
- ⑥ Click to go to aux input interface.
- ⑦ Click here to go to the Bluetooth player interface.
- ⑧ Click to go to GPS interface.
- ⑨ Click to go to the prev/next page.
- ⑩ Click here to adjust the screen brightness and off screen.
- ⑪ Click to go to System Settings interface.

1

2. MUSIC

In the main menu interface, touch MUSIC icon to enter the music state.

2.1 Features taskbar icon



- ① Click here to enter the menu setting.
- ② The volume regulation, padding can adjust the volume.
- ③ Return
- ④ Enter the main menu



- ⑤ Click here to play the prev/next song.
- ⑥ Click here to play / pause.
- ⑦ Click here to Shuffle.
- ⑧ Click here loop.
- ⑨ Playback progress display.

3. PHOTO

In the main menu interface, touch PHOTO icon to enter the photo state.

- ① Click here to play the prev/next picture.
- ② Click here to play / pause.
- ③ Click here zoom in.
- ④ Click here zoom out.
- ⑤ Click here to rotate image.

2

1. HOME

在任务栏点击  进入主菜单界面



- ① 点击radio进入收音机播放界面.
- ② 点击music进入音乐播放界面.
- ③ 点击movie进入视频播放界面.
- ④ 点击photo进入图片播放界面.



- ⑤ 点击进入AV IN界面
- ⑥ 点击进入AUX IN外接音频输入界面.
- ⑦ 点击BT进入蓝牙控制界面.
- ⑧ 点击进入GPS导航界面.
- ⑨ 点击进入上一页和下一页.
- ⑩ 点击进入屏幕亮度调节和息屏.
- ⑪ 点击进入系统设置界面.

1

2. MUSIC

在主页面点击MUSIC进入音乐播放界面。

2.1 任务栏图标的功能



- ① 点击进入菜单设置
- ② 音量调节, 划动可以调节音量
- ③ 返回到上一级
- ④ 进入主菜单




- ⑤ 点击选择上一曲和下一曲
- ⑥ 点击播放或暂停
- ⑦ 点击进入随机播放
- ⑧ 点击进入循环播放
- ⑨ 播放进度条显示

3. PHOTO

在主页面点击PHOTO进入图片播放界面。


- ① 点击播放上一张和下一张照片
- ② 点击播放和暂停
- ③ 点击放大照片
- ④ 点击缩小照片
- ⑤ 点击旋转照片

2




4. VIDEO

In the main menu interface, touch VIDEO icon to enter the video state.




- ① Click here to play the prev/next video.
- ② Click here to play / pause.
- ③ Click here loop.
- ④ Click here to Shuffle.
- ⑤ Playback progress display. Touch paddling can fast forward and rewind.
- ⑥ Next page

3



4. VIDEO

In the main menu interface, click VIDEO to enter the video playback interface.



- ① Click to play the previous/next video.
- ② Click to play/pause.
- ③ Click to enter loop playback.
- ④ Click to enter random playback.
- ⑤ Playback progress bar display, touch and drag to fast forward or fast backward.
- ⑥ Next page

3

5. RADIO

In the main menu interface, touch RADIO icon to enter the radio state.



- ① Click here to manually scan radio.
- ② In radio state, each band has six frequency points, press any frequency, you can store your favorite radio stations.
- ③ LOC/DX Switch
- ④ Stereo
- ⑤ Press to automatically search for radio stations and store the FM1- FM2- FM3 18 radio stations, short press to navigate through the radio.
- ⑥ Band Switch

6. BT

In the main menu interface, touch BT icon to enter the bluetooth state.



4

5. RADIO

In the main menu interface, click RADIO to enter the radio interface.



- ① Click to manually search for stations.
- ② In radio mode, each band has 6 frequency points. Press any frequency to store your favorite stations.
- ③ Select remote/long range.
- ④ Stereo sound switch.
- ⑤ In radio mode, click to manually search for stations and store them in FM1, FM2, FM3, etc. 18 stations. Short press to switch between stations.
- ⑥ Band selection for FM1, FM2, FM3.

6. BT

In the main menu interface, click BT to enter the Bluetooth control interface.



4

6.1 Click into the dial-up interface.

- ① Bluetooth dial number keys can be used to enter a phone number to dial.
- ② Backspace
- ③ Bluetooth is available under the call state will host the button to switch the sound to the phone.
- ④ hang up the phone.
- ⑤ Dial / answer a call.

6.2 Click to go to the call log interface



① Missed record, received record dial record list.

② Received record

③ Dial record


④ Missed record

6.3 Click into the contact interface



5

6.4 Click to go to the Bluetooth music interface.



① Prev / Next , play / pause function.

7. SETUP

In the main menu interface, touch SETUP icon to enter the setup state.



① Click to sound settings.

② Click on the language Set up.

③ Other settings.

④ Click to go to the radio region selection.

⑤ Click on the steering wheel control settings.

⑥ Click to set the time.

6

6.1 Click into the dial-up interface.

- ① Bluetooth dial number keys can be used to enter a phone number to dial.
- ② Backspace
- ③ Bluetooth is available under the call state will host the button to switch the sound to the phone.
- ④挂电话
- ⑤拨打/接听电话

6.2 Click into the call log interface



①未接电话、已接电话、拨号记录列表。

②已接电话

③拨号记录


④未接电话

6.3 Click into the contact interface



5

6.1 Click into the Bluetooth music interface.



①上一曲/下一曲，播放/暂停功能。

7. SETUP

In the main page click SETUP enter the system setup page.



①点击设置声音

②点击设置语言

③其他设置

④点击选择收音区域

⑤点击设置方向盘控制

⑥点击设置时间

6

7.1 Touch Radio Area ,select the radio region.



7.2 Touch TIME, into the time setting.



① Touch to set the time and date

② 12/24 standard switch

7

7.3 Touch Wheel Control , Steering wheel control interface.



Enter the learning state:

- ① long press button on the steering wheel use left hand, then touch screen corresponding function use right hand, make it highlight, mean learn OK;
- ② When the learning was completed, click Confirm.
- ③ When learning has failed, it should be not respond in the steering wheel.
- ④ If operating mistake in the learning process, click Reset to re-learning.

7.4 Other settings interface.



① Softenware Update

② Factory Data Reset

③ Calibration

④ Background Set

8

7.1点击RADIO AREA, 选择收音区域。



7.2点击TIME, 进入时间设置。



①触摸设置时间和日期

②12/24时制选择

7

7.3 点击 WHEEL CONTROL , 进入方向盘设置界面



进入续写界面:

- ① 左手按住方向盘上的按键不放, 然后用右手选择屏幕上对应的功能钮, 使其高亮, 意思就是已经学习成功;
- ② 当学习完成后, 点击Confirm确认;
- ③ 当学习失败时, 点击方向盘按键是无响应的;
- ④ 如果学习时发生失误, 可以点击Reset键重新学习。

7.4 其他设置界面



①软件更新

②恢复出厂设置

③屏幕校对

④背景图设置

8

7.5 Touch Language, select the national language.




8. GPS NAVIGATION (Optional)

In the main menu interface, touch GPS icon to enter the Navigation.



9

7.5 点击LANGUAGE进入语言设置



8. GPS NAVIGATION (Optional)


在主页面点击GPS进入导航界面。 (可选功能)



9

9. AUX IN


In the main menu interface, touch aux in icon to enter the aux in state.



Front panel 3.5mm audio input.

10. AV IN

In the main menu interface, touch av in icon to enter the av in state.




RCA audio/video input.

10

9. AUX IN


在主页面点击AUX进入外接视频输入界面。



前面板3.5mm外接音频输入接口

10. AV IN

在主页面点击AV IN进入外接音视频输入界面。



后面板RCA莲花插外接音视频输入接口

10

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.