

Size: 90× 90mm

90mm

90mm

90mm

90mm

90mm

90mm

90mm

90mm

90mm

90mm

90mm

90mm

90mm

90mm



Camping light Wireless Speaker instructions



Audio = 1



Instruction manual



Type-C charging cable X1

Product Specifications

Bluetooth version : V5.0
Communication distance : 10M
Music time : 12H(50% volume)
Speaker : 52mm 4010W*2
Charging time : 5.9H
Battery capacity : 3000mAh/3.7V
Charging voltage : DCA-71-5.0V
Rated power : 20W

① Illuminated light button

Short press: open
Short press to switch between three modes/levels
Short press the fourth time to turn off
Long press for 8 seconds to reset and shut down

② Color light button

Short press: turn on the breathing light
Long press: close the breathing light
In any state, short press to open the cycle of color light breathing light, in short press to change to monochrome breathing light mode, continue to short press to restore the cycle mode, long press to close the breathing light

③ Volume button +

Long press the volume key +: turn up the volume
Short press the volume key -: switch the next song

Product diagram

Function Keys



Audio LED indicator status

Charging	Red light flashing
Bluetooth connection / TF card / AUX input	Blue light is always on
Volume plus / previous song	
Power on / mode / light button	White light long light 15 seconds off
Volume down / next song	
Fully charged	Charging full charge red light is always on
Start up	Blue light blinking
Shutdown	Blue light off
Matching search status	Blue light blinking

Voice Prompt

Incoming call	Follow the phone
Connection with cell phone	Connected
Low battery (less than 10% battery)	Warning sound
Answering	No beep
Maximum volume	Beep
Turn on the phone	Power on

Voice Prompt

Pairing	Ding Ding
End the call	No beep
Turn off the phone	Power off
Volume up / down	No beep
AUX / TF / Bluetooth mode	Lineinmusic@Bluetooth mode

Tips

- Do not attempt to disassemble or replace any parts inside the product except for the operation method specifically indicated in the manual.
- Do not put the product into water or any other liquid, this product is not designed to be waterproof.
- If any liquid accidentally enters the product, please immediately disconnect and remove the product.
- To avoid electric shock, please make sure there is no water on your hands when installing or uninstalling the product.
- Do not place the product near a heat source or expose it directly to a fire source.
- Do not place this product in an environment where there is a strong electromagnetic force, as this may cause the product to malfunction.
- It is recommended not to operate the device while it is charging.

FCC warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates noise and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.