

Technical parameters

Specification

Measurements (L x W x H): 151mm x 59mm x 12.5mm
Weight (grams): 100g / 0.22 pound
Operational Range: up to 10 meters/ 30 feet
Transmit power: +4db Max
Operation voltage: 3.3V
Operation current: < 80mA
Charging current: < 300mA
Sleep current: < 1mA

Computer system requirements

Windows 2000
Windows XP
Windows Vista, Windows CE, Windows 7
Linux (Debian-3.1, Redhat-9.0 Ubuntu-8.10 Fedora-7.0 tested)

Troubleshooting

Below are some basic troubleshooting scenarios for the device. Please contact support from the place of purchase if you are unable to resolve any issues with the device

Problem	Possible issue	Solution
Unit does not respond	1. Low battery power. 2. Unit is not turned on.	1. Charge the device for at least 15 minutes. 2. Check if the switch selected to the "ON" position
Keyboard cannot establish a connection to the receiver.	1. The receiver may not be inserted correctly. 2. Possible wireless interference with another device	1. Disconnect and reconnect the receiver to the USB port. 2. Change the channel of the device by pressing and holding the Fn + F1 key for 10 seconds and let the unit reconnect.
The mouse pointer moves erratically and/or unresponsive	1. Device may not be within optimal range of the receiver 2. Dust or oil on the touchpad	1. Bring the unit closer to the receiver. 2. Clean the touchpad with a damp cloth
Unit does not charge	1. Defective battery. 2. Check connections	1. Contact your local dealer for replacements. 2. Verify if the device is securely connected to the charger.


MANUAL DE USUARIO

MANDO-SMARTTV2

Este producto es una fabulosa combinación de mini teclado Qwerty 2.4GHz (teclado más habitual), con panel táctil y receptor de USB

Este producto no es solo un teclado inalámbrico normal, también tiene teclas para control multimedia y teclas para juegos. Tiene incorporado un panel táctil que puede ser utilizado en sentido horizontal o en vertical. Tiene indicador de encendido, indicador de señal RF, indicador de mayúsculas, indicador de batería baja y retroiluminación en el teclado para facilitar su uso en ambientes con poca luz. Además tiene también un puntero incorporado

Producto



Conexión del receptor

Saque el receptor USB del lateral del teclado, e insértelo en el interfaz USB del dispositivo a controlar. Una vez conectado, ponga en la posición "ON" el interruptor que se encuentra en la parte izquierda del teclado

Función auto-apagado y auto-encendido

El teclado también dispone de las funciones de apagado y encendido automáticos. Si hay un periodo de inactividad el teclado pasara al modo apagado automáticamente. Durante esta función, el usuario puede activar el teclado presionando cualquier tecla. El receptor de 2.4 GHz y el indicador de RF del teclado continuará parpadeando y no se apagará

Desactivar el teclado después de su uso

Después de utilizar el teclado, ponga el interruptor en la posición de apagado (OFF), esto desactiva la alimentación del teclado. El receptor USB debe desconectarse del aparato donde se conectó y colocarlo en el alojamiento del teclado para guardarlo de forma segura

Carga de la batería

El teclado incorpora una batería de ión-litio, por favor, utilice sólo cargadores homologados o cárguelo utilizando una conexión desde el conector mini USB a un puerto USB

Nota: Cargue completamente la batería antes de utilizarla por primera vez. El dispositivo se puede utilizar mientras está cargando pero el tiempo de carga será más largo. Cuando la batería está baja, la luz de carga baja parpadea para avisar al usuario. La unidad se apagará automáticamente si la batería se ha agotado

Parámetros técnicos

Especificación

Medidas (L x Anch. xAlt.): 151mm x 59mm x 12.5mm
Peso: 100 gr.
Rango de funcionamiento: hasta 10 metros
Potencia de transmisión: +4 db Max
Voltaje: 3.3V
Intensidad: <80mA
Intensidad de carga: <300mA
Intensidad en reposo: <1mA

Requisitos del sistema informático

Windows 2000
Windows XP
Windows Vista, Windows CE, Windows 7
Linux (Debian-3.1, Redhat-9.0 Ubuntu-8.10 Fedora-7.0 tested)

Solución de problemas

A continuación presentamos algunas soluciones a los problemas más comunes en el dispositivo. Por favor, póngase en contacto con el establecimiento de compra si usted no puede resolver cualquier problema con el dispositivo

Problema	Posible problema	Solución
La unidad no responde	1. Batería con carga baja 2. La unidad no está encendida	1. Cargue el dispositivo durante al menos 15 minutos 2. Compruebe que el interruptor está en la posición "ON"
El teclado no establece conexión con el receptor	1. El receptor USB no está insertado correctamente 2. Interferencias inalámbricas con otro dispositivo	1. Desconectar y volver a conectar el receptor USB al puerto USB 2. Cambie el canal del dispositivo manteniendo pulsadas las teclas Fn + F1 durante 10 segundos y dejar que la unidad se vuelva a conectar.
El puntero del ratón se mueve erróneamente y / o no responde	1. El dispositivo puede estar fuera del alcance óptimo del receptor 2. Hay polvo o aceite en el panel táctil.	1. Aproxime la unidad al receptor. 2. Limpie el panel táctil con paño húmedo
La unidad no carga	1. Batería defectuosa 2. Compruebe las conexiones	1. Contacte con el punto de venta 2. Compruebe que la unidad está bien conectada al cargador.


USER'S MANUAL

MANDO-SMARTTV2

This is a wonderful combo, 2.4GHz Wireless mini QWERTY keyboard, Touch Pad and presenter combo, with USB interface receiver.

This product consists not only of normal wireless keyboard keys, but also of multimedia control keys and PC gaming control keys. It has built-in programmable smart touch pad-the world's first Touchpad which can be used in horizontal and vertical directions. It has power indicator, RF signal indicator, CAPSLOCK light, low-voltage indicator and keypad backlight to facilitate the use in dark environments. In addition, it also has a built-in pointer.

Product overview



Connecting the receiver

Slide the receiver out from the side of keyboard, and insert to the devices with a standard USB interface. Once connected, slide the power switch to the "ON" position located on the left side of the unit to establish the connection

Auto sleep and wake feature

The keyboard also features an auto sleep and auto wake mode. If there is a long period of inactivity, the keyboard will automatically go into a sleep mode. During the sleep mode, the user can wake the unit up by pressing any key. The 2.4 GHz receiver and keyboard's RF indicator will continue to flash and will not power down

Switching off the keyboard after use

After finishing using the keyboard, push the switch to the off position. This turns off the power of the keyboard. The USB receiver should be plugged out from the PC and then inserted back in the keyboard so it is being kept safely.

Charging the battery

The device with built-in lithium-ion battery, please use only approved data lines and chargers

Note: Fully charge the unit before operating for the first time. This device can be used when charging, but will extend the charging time. When the battery is low, the low-voltage light will flash to warn the user. The unit will automatically turn off if the battery has been depleted.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could

void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.