


阿蒙
毛绒音响

AMON
SOUND

产品使用
说明书

INSTRUCTIONS
FOR USE



Frifizz®
星期五罐头

Packing List


Packing List			
1	AMON SOUND X1	2	USB charging cableX1
3	Instruction for use (Including Warranty Card)X1	4	AUX connection cableX1

Specification Parameters


Product Name:	AMON SOUND
Product Model:	M-Y-AMON1
Product Dimensions:	180x180x258mm
Net Weight of the Product:	1200g
Rated Output:	10W
Maximum Power:	15W
Battery Capacity:	4000mAh
Bluetooth Version:	V5.3
Power Input:	DC 5v 1A
Frequency Response:	100Hz—18KHz
Maximum Sound Pressure Level:	87dB
Speaker Unit:	67MM 15W 4Ω

Product Introduction

Please read this instruction manual carefully before using the product and keep it properly.



Operation Instructions



Power on and off

- Power on: Long press for 2 seconds to power on/off
- Force restart: Long press the button on the top of the head for 10 seconds to force a shutdown and restart.

Pause/Resume

- Press the button once to pause the music or resume playing.

Light Control

- Double-click the button on the top of the head to turn the light on or off.

Operation Instructions

Bluetooth Connection

- Pairing Name: Frifizz-AMON
- Pairing Status: After turning on the device, it will directly enter the Bluetooth pairing mode.
- Reconnection after Out of Range:
 1. Within 30 minutes of disconnection: The original device will automatically reconnect when it returns to the Bluetooth connectable area. (The device can also be searched and connected by other devices during the period of Bluetooth disconnection.)
 2. The device will automatically turn off 30 minutes after disconnection.
- Re-pairing of Bluetooth: Tap the top of the device four times in succession to force a disconnection of the Bluetooth. After the Bluetooth is disconnected, search for and pair it again.

TWS Connection
(The effective distance is within 15 meters)

- Connection and Pairing:

[Only one of the two devices is connected to Bluetooth] Triple-tap the "top" of the connected device. If you hear a prompt tone within 10 seconds, the connection is successful (the host/left channel is the device that has been connected to Bluetooth).

[Neither of the two devices is connected to Bluetooth] Triple-tap the "top" of either device. If you hear a prompt tone within 10 seconds, the connection is successful (the host/left channel is the device on which the triple-tap operation is performed).

Note: If there is no connection within 15 seconds, the pairing state will be exited.
- Disconnecting the Pairing: When the two devices are in the connected state, triple-tap either device to exit the pairing state; when in the pairing state, triple-tap the device in the connected state to exit the pairing state.

AUX Mode

- AUX Connection: When the AUX cable is inserted into the bottom interface, the device will enter the AUX connection mode, and AUX takes precedence.
- Interrupting the AUX Connection: Disconnect the AUX cable to break the connection, and the device will enter the Bluetooth connection mode.

深圳市星期五罐头生活科技有限公司
Shenzhen FriFizz Life Technology Co., LTD



WeChat Official Account




Rednote

Contact Address:
No.19, Xinghua First Road(Extension Section), Haiwang Community,
Xin'an Street, Bao'an District, Shenzhen.

Service Telephone:
0755-23148478

FC CE RoHS

Lighting Instructions



Lighting Instructions

- Power On/Off:** Turn on/turn off the light.
- Bluetooth Matching:** The light breathes.
- Bluetooth Matching Successful:** The light changes from the breathing mode to a constant-on state.
- Bluetooth Disconnected:** The light turns back to the breathing mode.
- Music Playing:** The light breathes (the brightness of the light is proportional to the volume level).
- Music Paused:** The light stays constantly on.
- TWS Matching:** The light switches to the effect of flashing alternately between the left and right sides.
- TWS Matching Successful:** When in the playing state, the light changes from flashing to the breathing mode; when in the paused state, the light changes to a constant-on state.
- AUX Connection Successful:** The light flashes quickly twice and then changes to the breathing mode.
- Volume Adjustment:** The brightness of the light is proportional to the volume.
- Charging Status:** The indicator light at the bottom stays constantly red.
- Fully Charged Status:** The indicator light at the bottom stays constantly green.
- Sound Instructions**
- Bluetooth/TWS Connection Successful:**DENG DENG~ (Refer to the sound effect.)
- Bluetooth/TWS Connection Interrupted:** DU (Refer to the sound effect.)
- Low Battery Alert:** DENG DENG DENG~ (Refer to the sound effect.)
- Power Off:** The sound of opening a soda can (Refer to the sound effect.)

Operation Instructions and Precautions

- Do not severely impact the main unit.
- Do not come into contact with chemical substances such as benzene and diluents. Do not use the device near strong magnetic or electric fields.
- Avoid direct sunlight or heating appliances.
- Do not disassemble, repair, or modify the device by yourself.
- Do not listen at a high volume for an extended period to avoid causing adverse effects on your hearing. Do not clean this device with clean water. Instead, simply clean the surface of this device with a slightly damp cloth. When using it at a low voltage, it may cause sound distortion, so please charge it in a timely manner. If you do not use it for a long time, please disconnect the power supply.
- The Bluetooth function is compatible with common smartphones, tablets, etc. However, depending on the device or application you are using, some functions may not be supported.
- Insufficient voltage due to low battery level may cause abnormal device functions. Please charge the device in a timely manner.

Environmental Protection Instructions

Environmental Protection Reminder: This product is equipped with a rechargeable lithium battery. When this product or any of its components are to be discarded, please do not dispose of them together with household waste. Instead, they can be taken to waste battery recycling bins, waste disposal stations or recycling centers for safe and effective disposal, so as to prevent environmental pollution.

Names and Contents of Hazardous Substances in the Product

Hazardous Substances						
Component Names	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
Plastic	○	○	○	○	○	○
Silicone	○	○	○	○	○	○
Hardware	○	○	○	○	○	○
Circuit Board	○	○	○	○	○	○

Polybrominated Diphenyl Ethers (PBDE)

O: It indicates that the content of this hazardous substance in all homogeneous materials of this component is below the limit requirements specified in GB/T 26572-2011.

X: It indicates that the content of this hazardous substance in at least one homogeneous material of this component exceeds the limit requirements specified in GB/T 26572-2011.



Warranty Instructions

The after-sales service of the AMON SOUND strictly implements the "Three Guarantees" after-sales service in accordance with the "Law of the People's Republic of China on the Protection of Consumers' Rights and Interests" and the "Law of the People's Republic of China on Product Quality". For details, please consult the purchasing merchant or the official of FrFiFizz.

Non-warranty Instructions

- Unauthorized repair, misuse, collision, negligence, abuse, liquid ingress, accidents, modifications, or the incorrect use of accessories not intended for this product.
- Acts such as tearing or altering labels, anti-counterfeiting marks, etc.
- The product has exceeded the validity period of the "Three Guarantees" service
- Damage caused by force majeure.
- Performance failures of this product and its accessories caused by human factors.

Certificate of Conformity

Production Date

Inspector



Product Warranty Card

Thank you very much for purchasing the products of FrFiFizz!

We will provide limited warranty service in accordance with the relevant terms on your warranty card after confirming your purchase certificate. Please keep this warranty card properly and present it when the product needs to be repaired.

If you need repair service, please contact our service team from 9:00 to 18:00 on weekdays (excluding legal holidays)!

After-sales Service Hotline:0755-23148478

Correspondence Address:2006(Qianhai HOP International),No.19, Xinghua First Road(Extension Section),Haiwang Community, Xin'an Street,Bao'an District,Shenzhen

Important Notice: The warranty period shall be calculated from the date of the initial purchase, and the warranty duration is 1 year.

Product Information		User Name	
Product Model		User Address	
Purchase Date		Contact Number	
Purchase Channel		Maintenance Personnel	
Fault Description			
Signature (Seal)			


阿蒙
毛绒音响

AMON
SOUND


产品使用
说明书

INSTRUCTIONS
FOR USE


Frifizz®
星期五罐头



操作说明



头顶为按钮



开关机

- 开机：长按 2 秒，即可开机 / 关机
- 强制重启：长按头顶 10s，即可强制关机重启

暂停 / 继续

- 单按一次，即可暂停音乐 / 继续播放

灯光控制

- 双击头顶按钮，即可打开 / 关闭灯光

包装清单

包装清单			
1	AMON阿蒙毛绒音响×1	2	USB充电线×1
3	产品说明书(含保修卡)×1	4	AUX连接线×1

规格参数

产品名称：	AMON 阿蒙毛绒音响	电池容量：	4000mAh
产品型号：	M-Y-AMON1	蓝牙版本：	V5.3
产品尺寸：	180x180x258mm	电源输入：	DC 5v 1A
产品净重：	1200g	频率响应：	100Hz—18KHz
额定输出：	10W	最大声压级：	87dB
最大功率：	15W	扬声器单元：	67MM 15W 4Ω

操作说明

蓝牙连接

- 配对名：Frifizz—AMON
- 待配对：开机后，直接进入蓝牙配对模式
- 超距回连：
 1. 断开连接 30 分钟以内：原设备回到蓝牙可连接区域自动连接（蓝牙断开期间也可被其它设备搜索连接）
 2. 断开 30 分钟后自动关机
- 蓝牙重新配对：对头顶四连击强制断开蓝牙，蓝牙断开连接并重新搜索配对

TWS 连接(有效距离为：15 米以内)

- 连接组队：

【两台设备仅一台连接蓝牙】对已连接设备“头顶”进行三连击，10 秒内听到提示音即连接成功(主机 / 左声道为已连接蓝牙的设备)；

【两台设备均未连接蓝牙】对任意一台“头顶”进行三连击，10 秒内听到提示音即连接成功(主机 / 左声道为进行三连击操作的设备)；

备注：15 秒内若无连接即退出组队状态
- 断开组队：两台设备在已连接状态下，三连击任意一台设备即可退出组队状态；组队中状态下，三连击连接状态中的设备即可退出组队状态


AUX 模式

- AUX 连接：在 AUX 线插入底端接口处时，进入 AUX 连接模式，且以 AUX 优先
- 中断 AUX 连接：拔掉 AUX 线则断开连接，进入蓝牙连接模式

产品介绍

使用产品前请仔细阅读本说明书，并妥善保管。

蓝牙键 / 电源开关 / 音量调节键 / 灯光开关键 / TWS 连接键



深圳市星期五罐头生活科技有限公司

Shenzhen Frifizz Life Technology Co., LTD

微信公众号



小红书



联系地址：


深圳市宝安区新安街道海旺社区兴华一路（延伸段）19 号（前海 HOP 国际）2006
2006(Qianhai HOP International), No. 19, Xinghua First Road (Extension
Section), Haiwang Community, Xin'an Street, Bao'an District, Shenzhen

服务电话：

0755-23148478

FC CE RoHS

灯光说明



灯光说明

开/关机：打开/熄灭

蓝牙匹配中：呼吸灯

蓝牙匹配成功：灯光由呼吸灯转为常亮

蓝牙断开连接：转为呼吸灯

播放音乐：呼吸灯（灯光亮度与音量大小成正比）

暂停播放：常亮

TWS匹配中： 转为左右互闪效果

TWS匹配成功：播放状态下灯光由闪烁转为呼吸灯，暂停状态下转为常亮

AUX连接成功：快闪两下后转为呼吸灯

声音调整：灯光与音量成正比

充电状态：底部指示灯红色常亮

充满状态：底部指示灯绿色常亮

声音说明

蓝牙/TWS连接成功: DENG DENG~ (见音效)

蓝牙/TWS中断连接：DU（见音效）

低电量提示: DENG DENG DENG~ (见音效)

关机：汽水开罐声（见音效）

产品中有害物质的名称及含量

有害物质						
部件名称	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
塑胶	○	○	○	○	○	○
硅胶	○	○	○	○	○	○
五金	○	○	○	○	○	○
电路板	○	○	○	○	○	○

本表格依据 SJ/T 11364 的规定编制。

O: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572-2011 规定的限量要求以下。

X: 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572-2011 规定的限量要求。



保修说明

AMON 阿蒙小树怪毛绒音响售后服务严格依据《中华人民共和国消费者权益保护法》、《中华人民共和国产品质量法》实行售后三包服务, 详情请咨询购买商家或星期五罐头官方。

非保修说明条例

1. 未经授权的维修、误用、碰撞、疏忽、滥用、进液、事故、改动、不正确的使用非本产品配件;
2. 撕毁、涂改标贴、防伪标记等行为;
3. 已超过三包有效期;
4. 因不可抗拒力造成的损坏;
5. 人为原因导致本产品及其配件出现性能故障。

合格证

生产日期

检验员



操作说明注意事项

- 切勿严重撞击主机；
- 切勿接触苯、稀释剂等化学药品请不要靠近强磁场、电场下使用；
- 请避开直射光线或发热器具；
- 切勿自行拆卸、修理、改造；
- 切勿以较大音量长时间收听，以免对听力造成不良影响，切勿用清水清洁本机，请用稍稍湿润的布清洁本机表面即可；低电压使用时可能引起声音失真并及时充电，长时间不使用请断开电源；
- 蓝牙功能与常见的智能手机、平板电脑等兼容，但根据您所使用的设备或应用程序的不同，可能不支持某些功能；
- 低电量电压不足会导致设备功能异常，请及时充电。

环保说明

环保提示说明：本产品内置可充电锂电池，若本产品或其中部件报废，请勿将其与生活垃圾一起打包处理，可送至回收废旧电池的垃圾箱、垃圾站或回收站，以得到安全有效的处置，防止对环境造成污染。

产品保修卡

承蒙惠购星期五罐头产品，谨致谢意！

我们将根据您保修卡上的有关条款,在确认您的购买凭证后提供有限保修服务,请妥善保管本保修卡,在维修时请您出示。

如需维修服务，请于周一至周五 9: 00-18: 00（法定节假日除外）与我们的服务团队联系！

售后电话：0755 - 2314 8478

通信地址：深圳市宝安区新安街道海旺社区兴化一路（延伸段）19号（前海HOP国际）2006

重要提示：保修期从最初的购买之日开始计算，保修期限 1 年

产品信息		用户名称	
产品型号		用户地址	
购买日期		联系电话	
购买渠道		维 修 人	

故障描述

签名 (盖章)

FCC Warning Statement: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.