

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Karaoke Po Space Capsule Audio

DZ-015



Product Instruction Manual

Thank you for choosing our products and I hope you enjoy your musical journey

• SAFETY INSTRUCTION

PLEASE READ THIS MANUAL CAREFULLY BEFORE USE AND KEEP IT FOR FUTURE REFERENCE
 01.Keep away from heat, sun exposure and sharp objects.
 02.Stay away from the open fire.
 03.Don't insert any metal objects. Avoid short circuit.
 04.Don't repair the product by yourself, but contact the authorized repairer.
 05.Avoid products from getting caught in the rain,Spray.
 06.If the product is overheated. Damaged or fell into liquid. Please stop using.
 07.Use products according to standards and regulations.

• PACKAGING ACCESSORIES


01.DZ-015 Audio*1 02.DZ-015 Microphone (According to the purchased package equipped)
 03.TYPE-C charging cable*1 04.Product description*1

• INTERNAL BATTERY

01.Built-in rechargeable battery takes 2-3 hours to complete the charging and discharge cycle.
 02.Don't continue charging a fully charged battery. Overcharging will shorten the battery life.
 03.If the full load is placed, it may be a little lost.
 04.Placing the product in a place that is overheated or too cold will shorten the product life.


• CHARGING FUNCTION

01.Plug in the TYPE-C charging cable and connect the charger at the other end.
 02.The product's LED charging indicator light is always on in red, that is, the sound is charging normally.
 03.When the product is fully charged, the LED red light is off.



• OPERATION FUNCTION

- ① Power on / Power off
- ② Previous Song/Sound Plus
- ③ Next song/Sound reduction
- ④ FM mode
- ⑤ Ambient Light
- ⑥ TYPE-C charging port
- ⑦ LED charge lamp
- ⑧ The USB superior disk port
- ⑨ TF card port
- ⑩ The AUX audio access port
- 01.Turn on/off button, long press the O-shaped button, prompt "Bluetooth mode" it is, boot complete to enter the Bluetooth mode.
- 02.②Short press to go to previous song, long press to increase volume
- 03.③Short press and enter the next song, long press the volume reduction
- 04.④Short press to enter radio mode, short press FM again to exit radio mode
- 05.⑤If you need to turn on the radio mode, you need to insert the radio antenna. You need to insert the TYPE-C line in the sound socket. Do not insert it on the changer at the other end of the line.
- 06.⑥Charging the speaker via TYPE-C charging cable
- 07.⑦LED charging indicator to determine charging status
- 08.⑧Insert the USB flash drive and turn on the U disk when the shutdown state, then automatically play the music in the U disk after booting
- 09.⑨In the shutdown state, then turn on when the TF card is inserted, the audio in the TF card is automatically played after turning on
- 10.⑩When turned on, insert the audio line automatically into AUX mode



• MICROPHONE INSTRUCTIONS

- ① Power on key
- ② + Key
- ③ - Key
- ④ Microphone key
- ⑤ Bluetooth charging indicator
- ⑥ Type-c charging port
- ② + Key : Short press to switch microphone volume up /Reverb volume increase/acompaniment volume increase/Long press Control the next music.
- ③ - Key : Short press to switch microphone volume down /Reverb volume decrease /acompaniment volume decrease /Long press Control the previous music
- ④ Microphone key: short press to switch the microphone mode / male to female / female to male / beast sound / doll sound.
- Double click to eliminate the original sound on/off; long press the microphone on/off
- ⑤ Bluetooth / charging indicator :blue light / red light
- ⑥ Type-c charging port :DC5V / charging

• MICROPHONE FUNCTION

Support Bluetooth connection to play music / support TF card to play music/ karaoke sound reinforcement function / built-in reverberation sound effect function / headphone output function.

• TROUBLESHOOTING

Failure phenomenon	Possible reasons	Solution
Unable to search Bluetooth	The battery is not powered off	Charge the audio
Unable to pair Bluetooth	The audio has been paired with another device and has not entered pairing mode	Turn off other paired devices Search again and pair

• TECHNICAL SPECIFICATIONS

Product name	Karaoke Po Space Capsule Audio
Product Model	DZ-015
Bluetooth Name	BT-015
Product material	ABS
Charging voltage	5V/1A
Bluetooth battery capacity	1000mAh
Speaker	5.3
Speaker power	5W
Microphone battery capacity	800mAh
Audio size	110*59*94mm
Execution standard	GB 8898-2011

Thank you for your support!

CE CE RoHS