

Portable Projector

※User Manual※

Attention

Please read this manual carefully before use and keep it for future reference.

- 1.The projector is non dustproof or waterproof.
- 2.In order to reduce the risk of fire and electric shock, do not expose the projector to rain and fog.
- 3.Please use the original power adapter. The projector should work under specified rated power supply.
- 4.When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain. Children should use the projector under the supervision of adults.
- 5.Do not cover the vents of projector. Heating will reduce the life of projector and cause danger.
- 6.Regularly clean projector vents, or dust may cause cooling malfunction.
- 7.Do not use the projector in greasy, damp, dusty or smoky environment. Oil or chemicals will cause malfunction.
- 8.Please handle with care during daily use.
- 9.If the projector is not used for a long time, please cut off the power.
- 10.Non professionals are prohibited from dismantling, testing, and repairing the projector of this equipment on their own

Multi point TOF focusing omnidirectional trapezoidal function

1.Pay attention to the autofocus and automatic trapezoidal functions. Please adjust the machine angle to $\geq 15^\circ$ before triggering.

2.After each focusing action is completed, if you are not satisfied with the trapezoidal effect, you can follow the prompts in the following picture when a pop-up window appears. Press the OK button on the remote control to fine tune the four corners of the trapezoidal screen. Fine tune the clarity by pressing (F+, F-).

3. It is recommended to control the horizontal left/right/pitch angle within 20° for optimal results. After exceeding the range, there will be a dynamic image pop-up prompt. When the pop-up appears, press the "OK" key and enter manual trapezoidal correction mode.

4.In manual trapezoidal mode, press the directional keys to adjust the screen angle, and press the "OK" key to confirm the next corner position.

Structure Description

The following equipment pictures and functional descriptions are for reference only, and the actual product shall prevail. If any modifications are subject to change without prior notice, and our company reserves the right to final interpretation.

Power ON/OFF

Power On
Long press Power button on projector for 3 seconds.

Power Off
When the projector is power-on, press and hold the power button on the projector or the remote control for 3s to power off.

Remote Control Function Description

Power	UP	Mute
Left	OK	Right
Down	Volume+	Volume-
Menu	Back	signal source
Focus+	Volume-	HOME
	Focus-	

Focus Adjustment

When turning on the projector, moving the machine or adjusting the angle will trigger the automatic trapezoid and focus functions. You can also use the focus button on the remote control to adjust the lens position to a clear state on the projector screen.

Bluetooth remote control paired steps:

- 1, hold down the left and right keys do not let go, indicator lights start flashing, bluetooth radio open
- 2, Bluetooth options will automatically search to "JIN" click on the connection, the connection will be successful after the prompt

Bluetooth connect

Long press the button as shown in the figure to enter pairing mode and wait for the connection to be completed

Launcher UI

Note: For the setting of video display, refer to the actual display

OSD Language

Setting - System Settings - OSD Lang > To choose your language.

Note: The language display interface may be one of the following, please refer to the actual display

Home Background

Select the desired main background in the upper right corner of the interface

Projector Mode

Setting - System Settings - Flip > To select different mode according to your application scenario. Four modes are available < Front Table, Front Ceiling, Back Table, Back Ceiling >.Auto focus and trapezoidal function can be optionally turned on or off

Media Player

Insert the U disk and click the USB icon on the homepage to read the local video & music & photo & Book.

HDMI Signal

Connect projector and external sourcing device by HDMI cable. Enter HDMI on the homepage, the signal from the sourcing device will be transmitted to projector and cast out.

On-screen image

Ios system

Android screen projection

1. Connect the projection device and the mobile phone to the same network.
2.Open the screen mirroring interface on your phone and click on the word "Android_****".
3. Select the device name to complete the screen projection.

Note: There are two projection interfaces, please refer to the actual display, and follow the prompts

Safety instructions

- Please pay attention to important information related to the operation and maintenance of the projector. You should read this information carefully to avoid problems. Following safety instructions will increase the life of projector.
- Please consult the qualified personnel for installation and repair services, and do not use damaged wires, accessories and other peripherals.
- Projector should be kept away from flammable, explosive, strong electromagnetic interference (large radar stations, power stations, substations) etc. Strong ambient light (avoid direct sunlight), etc.
- Do not cover projector vents.
- Please use the original power adapter.
- Keep adequate ventilation and make sure vents are not covered to avoid projector overheating.
- When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain.
- Do not bend or drag the power cord.
- Do not put power cord under projector or any heavy objects.
- Do not cover other soft materials on power cord.
- Do not heat the power cord.
- Avoid touching power adaptor with wet hands.

Disclaimer

This manual is general instructions, The pictures and functions in this manual should subject to the actual product. Our company is devoting to improve product performance, we reserve the right to modify product functions and interface described in this manual without notice.

Singing karaoke and lighting

This product supports karaoke function, and the following three methods are feasible:

1. The machine comes with a karaoke APP for singing.
2. The karaoke function can be used on the same screen as the phone.
3. It can be connected to a Bluetooth speaker to use the karaoke function.

The product also comes with colorful lights

Attention:

Please do not look directly into the lens when projecting to prevent the strong light doing harm to your eyes. Kids should use the projector under the supervision of adults.

microphone

After the microphone is turned on, it will automatically connect to the projector. Press and hold the power button, and the green indicator light will flash. After successfully connecting to the projector, the green indicator light will remain on.

Microphone sound mode options: KTV - Magic Sound - Doll Sound - Original Sound

When using a microphone, approach the pickup area.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.