

SPEAKER


User manual
BUFER_1249



Please read this manual carefully and
keep it for future reference.

1. Buttons

- A. Switch to turn the device on and off.
- B. TYPE C port: Loudspeaker battery charging port.
- C. LED indicator
- D. Speaker



2. Bluetooth Connection

If this is the first time you are using the loudspeaker, you will need to link it to your mobile device by activating the loudspeaker's Bluetooth mode. Access the Bluetooth mode of your mobile device and search among the available devices for the following: 1249. Select that device, and then the loudspeaker and mobile device will be connected. Once they are connected, the speaker will emit a sound confirming that the connection has taken place. After this first connection, the speaker will automatically connect to your device in subsequent uses.

3. Functions

A. Turning on and off:

To turn on the appliance, slide the on/off button to the ON position and you will hear a confirmation sound. To turn the speaker off, move the button to the OFF position.

NOTE: Pause, play or skip song functions must be activated from your mobile device.

B. Charging

To charge the loudspeaker, connect the USB cable to the computer or to the power supply via an adapter. The other end of the cable must be connected to the Type C port.

4. Warnings

- A. Do not expose the loudspeaker to direct sunlight or close to heat sources.
- B. Keep away from rain or extreme humidity conditions.
- C. Do not use damp cloths to clean them, clean them only with dry cloths.
- D. This product has a lithium battery. Do not dispose of it in a conventional garbage container.
- E. Avoid dropping the device as this could damage it.
- F. In the event the device stops working, we recommend you consult a specialist for repair.
- G. To avoid the risk of short circuit, do not insert metal objects into the loudspeaker slots.

5. Troubleshooting.

Errors	Solutions
The Bluetooth pilot does not turn on.	Recharge the loudspeaker, the battery may be running low. Once recharged, turn it on again.
Audio playback is interrupted intermittently.	Check that the loudspeaker and your mobile device are not too far apart, or that there is no obstacle between the two.
The audio is distorted / the volume is too low.	Recharge the loudspeaker battery and/or check the volume of your mobile device.
Difficulty linking loudspeaker and mobile device.	Turn off loudspeaker and turn it on again. If there are too many Bluetooth devices available, turn them off and try again.

FCC warning statements:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.

6. Specifications:

- Model: 1249
- Bluetooth version 5.0
- Recharge voltage: DC 5V.
- Rechargeable lithium battery 300mAh
- Operating distance: up to 10 metres.
- Frequency: 150Hz – 20KHz.
- Sensitivity: 90db ± 2db.
- USB charging cable included



The reference symbol on both the product and its user manual indicates that at the end of the useful life of electrical and/or electronic equipment, these must be recycled separately from your household waste. There are adequate means to collect this type of material for proper recycling. For more information, contact your local authority.

CE FC RoHS

MADE IN CHINA

Imported by: Gorfactory S.A
Carretera Santomera / Abanilla Km 8,8
30620 Fortuna, Murcia, Spain.