

产品型号	G117
蓝牙版本	5.3
传输半径	10米
音乐时间	约4小时
充电接口	TYPE-C
充电时间	约1.5小时

1. 打开充电仓，L/R耳机自动进入蓝牙配对模式，等待连接。
2. 打开手机上的蓝牙，搜索设备名G117，点击进入连接。
(语音提示：L/R耳机连接提示音)

1. 用一只手按住耳朵，把耳机挂在耳朵上。
2. 旋转调整耳机喇叭位置，上下移动直到耳机完全贴合耳朵的轮廓。
3. 注意区分L/R的佩戴位置，如果拿反则佩戴不上去。

待连接状态
耳机红灯跟蓝灯交替快闪

[illegible]

请勿在移动中使用BLUETOOTH®设备使用场所而定，使用可能会妨碍移动设备正常工作。

请勿在下列情况下使用BLUETOOTH®设备，因为这可能会妨碍您的听力，为了交通安全，请勿在驾车或骑行时使用任何设备。

请勿在以下环境使用蓝牙设备可能会导致危险的场所使用设备例如：
铁路交叉点、火车站台、行人横道及建筑工地。

请勿在本机上施加机械性施加压力，否则可能会导致本机在长期存放中发生故障。

体内植入医疗设备可能会导致设备操作错误，穿着天然材料制成的衣服，可防止电流传导。

请勿将耳机靠近易燃液体或易燃物。

请勿使用柔软的材料包裹耳机。

请勿让耳机暴露在水中，耳机并不防水，切勿尝试遵守以下预防措施。

当心不要让耳机落入液体或其他液体中，如果发生此类事故，请立即取出耳机。

如果在潮湿的环境下使用设备，可能会导致设备短路。

如果有任何关于本产品的任何问题或疑问，而本说明中未涵盖，请联系您的经销商。

本产品在使用过程中如果出现故障,我们将按照如下程序进行处理:

2. 此次产品故障发生及维修事宜,如出现以下情况,即使保修期已过,我们也将提供免费维修:

(1) 如果是有不可抗力因素,且故障也是由此造成;

(2) 如果产品超过保质期时间,发生故障而进行维修或更换;

(3) 说明(使用说明书)中说明的注意事项等正常使用;

(4) 其他因造成设备故障的设备故障、损坏,或者由于使用不当造成的故障损坏。(5) 因火灾、地震、火灾、水灾、雷击或由其他火灾、污染、腐蚀、电压异常等造成的故障损坏。(6) 热敏感材料和零件,更敏感零件

3. 可用时间零件或零件或零件进行维修。此外,维修更换的零件和我们的售后服务。

因此,我们使用本产品造成损失,我们将不予赔偿。

保修条款:

本产品自购买之日起,享有的一年保修期。

原产品的故障发生时,本保修保证书及有效销售凭证,符合下列条件时方可进行保修:

1. 您的设备必须按照本产品使用说明书正确使用;

2. 本保修卡不适用于人为、意外(火灾、外力挤压、坠落等)或者自然灾害(地震、台风、雷电等)所致的故障或损坏等。

3. 本保修卡遗失后不再补发, 请和销售凭证一同妥善保管。

产品名称:	
型号:	
购买时间:	
姓名:	
联系电话:	
购买地点:	
经销商名称及地址:	

请将此凭证妥善保管。若您的设备需要售后服务, 请联系您所购入设备的经销商。

符合下列条件的中国公民可以成为人民陪审员：

(1) 年满二十三周岁有选举权，并且(2) 本职业或者有其他专长。符合上述条件的中国公民可以被推荐为人民陪审员。

本条所称的“其他专长”是指具有法律以外的其他专门知识或者技能。例如，具有医学、文学、艺术、自然科学等方面的专门知识或者技能。

人民陪审员在担任人民陪审员期间，应当遵守下列规定：

(1) 不得兼任人民代表大会常务委员会的组成人员，不得兼任行政机关、审判机关以及法律规定的其他组织的组成人员；

(2) 不得兼任律师、公证员或者其他法律职业人员的职务；

(3) 不得兼任企业、事业单位或者其他组织的负责人；

(4) 不得兼任其他影响公正履行陪审职责的职务。


人民陪审员在担任人民陪审员期间，应当遵守下列规定：

(1) 不得兼任人民代表大会常务委员会的组成人员，不得兼任行政机关、审判机关以及法律规定的其他组织的组成人员；

(2) 不得兼任律师、公证员或者其他法律职业人员的职务；

(3) 不得兼任企业、事业单位或者其他组织的负责人；

(4) 不得兼任其他影响公正履行陪审职责的职务。



Model	G117
Bluetooth version	5.3
Transmission Radius	10M
Music time	About 4 hours
Charging interface	TYPE-C
Charging time	About 1.5 hours

1. Open the charging bin, U/R headphones automatically enter Bluetooth pairing mode, waiting for connection.
2. Open the charging bin, U/R headphones automatically enter Bluetooth pairing mode, waiting for connection.

1. Hold Your Ear with one hand and hang the headset over your ear.
2. Rotate the headphone horn and move it up and down until the headphone fits the ear contour perfectly.
3. Pay attention to distinguish L/R wearing position, if the reverse will not wear up..

The headphones flash red and blue lights alternately

[illegible]

1. Depending on the condition of the radio waves and the location where the BLUETOOTH device is used, it may not work on mobile phones.
2. Listening to this phone at high volume may affect your hearing. For traffic safety, please do not use this phone while driving or cycling on a road.
3. Please do not use the BLUETOOTH device in crowded places, such as environmental sound can cause danger, such as railway intersections, train stations, pedestrian crossings, and construction sites.
4. Please do not place any objects, especially pressurized containers, in the BLUETOOTH device. Pressurized containers, such as this phone, as may cause explosion or fire during long-term storage.
5. The accumulation of static electricity in the body may cause slight ear pain. Wearing clothes made of natural materials can minimize the impact.
6. Do not use the BLUETOOTH device in the vicinity of flammable or explosive materials.
7. Please use a soft cloth to clean the headphones.
8. Do not expose the headphones to water. The headphones are not IP rated.
9. Do not use the BLUETOOTH device in the vicinity of fire.
10. (Be careful not to let the headphones fall into the sink or other containers containing water.
11. (Do not use headphones in damp areas or harsh weather, such as rain or snow.)
9. If you frequently use after using the BLUETOOTH device, please use frequently using the BLUETOOTH device. If the problem persists, please contact your local distributor.
10. If you have any questions or concerns about this phone that is not covered in this manual, please contact your local dealer.

If the product breaks down during the warranty period, we will carry out the maintenance free of charge according to this manual:

This document can be re-issued please take good care of it. If the product is damaged due to the following reasons, the following circumstances will be charged:

(1) If no warranty card is shown (2) If the purchase date can not be confirmed

(3) If the product exceeds the warranty time, the fault occurs and the cause is not confirmed

(4) misuse (according to the normal use of the instructions and other relevant documents)

(5) Failure of damage to equipment due to other causes, or failure or modification to improve maintenance or modification (6) fire, lightning, flood, lightning or other natural disasters, pollution, salt, abnormal voltage caused by such factors or damage caused by other reasons

(7) Replacement of parts or replacement parts can be used for maintenance. In addition, repair and replacement of old parts and wear parts are not included in the warranty.

We shall not indemnify you for the loss caused by failure to use this product.

Warranty:

Product warranty:

Warranty period from the date of purchase, and valid a one-year warranty period.

Warranty products in the repair certificate and valid sales certificate. It is accordance with the following terms can be warranty.

1. Your equipment must be used correctly according to the instructions.

This warranty card is not applicable to faults or damages caused by human activities, accidents or natural disasters (falloff, falling etc.) or natural disasters (earthquake, typhoon, lightning, etc.). This warranty card will not be issued after it is lost. Please properly keep it together with the unit.

Product name: _____
 Model: _____
 Purchase time: _____
 Post number: _____
 Contact number: _____
 Place of purchase: _____
 Dealer name and address: _____

Please keep this voucher properly. If your equipment needs warranty service, please contact the dealer of your equipment you purchased.

Warning: The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference, including interference that may cause undesired operation.

NOTE: This device has been tested and found to comply with the requirements for compliance with the user's authority to operate the equipment. However, the user is responsible for ensuring that the device complies with all applicable requirements for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to licensed radio communications.

Operation of this device with certain accessories, power lines, and can radiate radio frequency energy and, if not installed and used properly, a hazard to life and property may exist. Refer to the accompanying documentation for more information on radio communications. However, there is no guarantee that interference will not occur in a specific installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Plug the device into a circuit different from that to which the receiver is connected.
- Consult the dealer or a qualified radio/TV technician for help.

NOTE: This device and its accessories must not be used for medical purposes.

CAUTION: The device has been tested and found to comply with the FCC requirements for use in the home. The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.