


<p><b>Instruction manual</b></p> <p><b>1、Appearance view</b></p>  <p><b>2、Hardware description:</b></p> <ol style="list-style-type: none"> <li>1. HDMI: HD output</li> <li>2. Mic power support: 5V / 2A, 5V / 1A, 5V / 0.5A</li> <li>3. Handle interface: wired handle, wireless handle, one second-hand handle, USB2.0 Interface</li> <li>4. Indicator light: blue indicator light is on when</li> </ol>	 <p><b>connecting to the power supply</b></p> <p>5. Support maximum 128G expansion TF Card</p> <p><b>3、Function description</b></p> <ol style="list-style-type: none"> <li>1. Supporting languages: Simplified Chinese, traditional Chinese, English and other 23 languages</li> <li>2. Support functions: collection, history, search</li> <li>3. Support simulator: CPS; GB; GBC; GBA; MD; SPC; PC; PS1; Atari</li> </ol> <p><b>4、Main menu function</b></p> <ol style="list-style-type: none"> <li>1. List: all the Games in the folder will be displayed on this page, with up and down selection and left and right page turning (in what simulator the game is in, there will be prompts on the screen)</li> <li>2. History: after playing, the game record will be in this interface</li> <li>3. Search: filter the game according to the game name uppercase letters (Note: case insensitive)</li> </ol> 	<p><b>2. Classification:</b> identify all simulators contained in the machine</p>  <p><b>4. Collection:</b> your favorite games can be added to the collection list</p>  <p><b>5. Search:</b> filter the game according to the game name uppercase letters (Note: case insensitive)</p> 	<p><b>a. game</b></p> <ol style="list-style-type: none"> <li>1. Press the direction key to select the game name and press the start / a key to enter the game</li> <li>2. Press B in the game list to return to the home page</li> <li>3. Holding down the SELECT/START key at the same time in the game brings up a game menu that allows the user to Pause/save/load/exit the game</li> </ol> <p><b>b. Settings</b></p>  <p><b>1. Handle press Select key to enter setting list, language, key tone, search local file, restore default setting and exit, system information, exit setting</b></p> <p><b>5、Hardware function definition</b></p> <p><b>6. Detailed parameters</b></p> <table border="1"> <tr> <td>game</td> <td>Support: CPS, PC, GB, GBC, MD, SPC, PS1; Atari arcade game</td> </tr> <tr> <td>Power supply</td> <td>5V/1A, 5V/2A, 5V/0.5A</td> </tr> <tr> <td>extend</td> <td>Support TF card expansion, maximum 128GB</td> </tr> <tr> <td>Video output</td> <td>HDMI HD output</td> </tr> </table>	game	Support: CPS, PC, GB, GBC, MD, SPC, PS1; Atari arcade game	Power supply	5V/1A, 5V/2A, 5V/0.5A	extend	Support TF card expansion, maximum 128GB	Video output	HDMI HD output	<p><b>remarks:</b></p> <ol style="list-style-type: none"> <li>1. The picture of the machine is for reference. The shell of the machine is subject to the material object. The instructions are only for reference. The software upgrade of the machine is subject to the material object.</li> <li>2. If there is any change in the product content or parameters, please refer to the content products without notice.</li> <li>3. The machine is not allowed to fill it at the factory. All external files (audio, video, game, pictures, etc.) must be deleted immediately after the demonstration. The company will not take any responsibility for this.</li> <li>4. Charging method: please use the output 5V-1A charger, connect the data cable to the USB port of the machine for power on.</li> <li>5. Executive standard: gbt17658.1-2012, gb6898-2011, GB / t13837-2012</li> <li>6. Children between 6.0 and 14 years old need to be accompanied by an adult to use this product.</li> <li>7. Download instructions: please download the game according to the formats supported by the machine, and put it in the corresponding folder of the machine</li> </ol> <p><b>Warranty</b></p> <ol style="list-style-type: none"> <li>1. Within seven days from the date of sale, in case of performance failure, the body and package of the goods must be intact, and the same type of goods can be replaced (subject to inspection), but not including artificial damage</li> <li>2. The goods are guaranteed for one year from the date of sale, with lifelong maintenance, and the accessories are not covered by the warranty</li> </ol> <p><b>WARNING</b></p> <p>Asphyxiation hazard-all packing materials(such as duct tape plastic bags, plastic film, binding wire, etc.) should not be exposed to children under 3 years of age to avoid suffocation hazards and should be used under adult supervision</p> <p>When the ambient temperature is less than or equal to 0 °C, the machine shall be moved indoors and placed at room temperature for 2 hours before use</p> <p><b>Packaging accessories</b></p> <table border="1"> <tr> <td>Color box</td> <td>Machine</td> <td>USB line</td> <td>Instinct control</td> <td>Systems handle</td> <td>receive</td> <td>HDMI extension cable</td> </tr> <tr> <td><input checked="" type="checkbox"/></td> </tr> </table> <p><b>Product warranty card</b></p> <table border="1"> <tr> <td>User name</td> <td>Gender</td> <td>Age</td> </tr> <tr> <td>Shipping address</td> <td>contact number</td> <td>Zip code</td> </tr> <tr> <td>Place of purchase</td> <td colspan="2">User signature</td> </tr> <tr> <td>Date of purchase</td> <td colspan="2">Sales order No.</td> </tr> <tr> <td>Product name and specification</td> <td colspan="2">Serial No.</td> </tr> <tr> <td>Dealer signature</td> <td colspan="2"></td> </tr> </table>	Color box	Machine	USB line	Instinct control	Systems handle	receive	HDMI extension cable	<input checked="" type="checkbox"/>	User name	Gender	Age	Shipping address	contact number	Zip code	Place of purchase	User signature		Date of purchase	Sales order No.		Product name and specification	Serial No.		Dealer signature								
game	Support: CPS, PC, GB, GBC, MD, SPC, PS1; Atari arcade game																																											
Power supply	5V/1A, 5V/2A, 5V/0.5A																																											
extend	Support TF card expansion, maximum 128GB																																											
Video output	HDMI HD output																																											
Color box	Machine	USB line	Instinct control	Systems handle	receive	HDMI extension cable																																						
<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>																																						
User name	Gender	Age																																										
Shipping address	contact number	Zip code																																										
Place of purchase	User signature																																											
Date of purchase	Sales order No.																																											
Product name and specification	Serial No.																																											
Dealer signature																																												

**使用说明手册**

**1. 外观视图**





**4. 指示灯:** 插入电源有黄色指示灯亮  
**5. 支持最大128G扩展TF卡**

**3. 功能描述**

- 文件语言: 中文简体, 中文繁体, 英文等 23 国语言
- 文件功能: 收藏, 历史, 搜索
- 文件格式: CPS; GBC; GBA; MD; SPC; PC; PS1; ATARI

**4. 主菜单功能**

- 列表: 文件夹所有游戏会在此界面显示, 上下选择, 左右翻页 (游戏在什么目录中, 屏幕中上会有提示)
- 分类: 识别机器包含的所有游戏

**2. 硬件说明:**

- HDMI: 高清输出
- 麦克风输入: 5V/2A, 5V/1A, 5V/0.5A
- 手柄接口: 有线手柄, 无线手柄, 一拖二手柄, USB2.0接口

**4. 指示灯:** 插入电源有黄色指示灯亮  
**5. 支持最大128G扩展TF卡**

**3. 功能描述**

- 文件语言: 中文简体, 中文繁体, 英文等 23 国语言
- 文件功能: 收藏, 历史, 搜索
- 文件格式: CPS; GBC; GBA; MD; SPC; PC; PS1; ATARI

**4. 主菜单功能**

- 列表: 文件夹所有游戏会在此界面显示, 上下选择, 左右翻页 (游戏在什么目录中, 屏幕中上会有提示)
- 分类: 识别机器包含的所有游戏

**2. 硬件说明:**

- HDMI: 高清输出
- 麦克风输入: 5V/2A, 5V/1A, 5V/0.5A
- 手柄接口: 有线手柄, 无线手柄, 一拖二手柄, USB2.0接口



**3. 历史:** 玩过以后的游戏记录会在此界面  
**4. 收藏:** 按照游戏名称对游戏进行筛选 (注: 不区分大小写)

**5. 设置:** 按照游戏名对游戏进行筛选 (注: 不区分大小写)

**6. 游戏:**

- 方向键选中游戏菜单, 按 START/A 键进入游戏

**2. 硬件说明:**

- HDMI: 高清输出
- 麦克风输入: 5V/2A, 5V/1A, 5V/0.5A
- 手柄接口: 有线手柄, 无线手柄, 一拖二手柄, USB2.0接口

**3. 功能描述**

- 文件语言: 中文简体, 中文繁体, 英文等 23 国语言
- 文件功能: 收藏, 历史, 搜索
- 文件格式: CPS; GBC; GBA; MD; SPC; PC; PS1; ATARI

**4. 主菜单功能**

- 列表: 文件夹所有游戏会在此界面显示, 上下选择, 左右翻页 (游戏在什么目录中, 屏幕中上会有提示)
- 分类: 识别机器包含的所有游戏

**2. 硬件说明:**

- HDMI: 高清输出
- 麦克风输入: 5V/2A, 5V/1A, 5V/0.5A
- 手柄接口: 有线手柄, 无线手柄, 一拖二手柄, USB2.0接口

**3. 功能描述**

- 文件语言: 中文简体, 中文繁体, 英文等 23 国语言
- 文件功能: 收藏, 历史, 搜索
- 文件格式: CPS; GBC; GBA; MD; SPC; PC; PS1; ATARI

**4. 主菜单功能**

- 列表: 文件夹所有游戏会在此界面显示, 上下选择, 左右翻页 (游戏在什么目录中, 屏幕中上会有提示)
- 分类: 识别机器包含的所有游戏

**2. 硬件说明:**

- HDMI: 高清输出
- 麦克风输入: 5V/2A, 5V/1A, 5V/0.5A
- 手柄接口: 有线手柄, 无线手柄, 一拖二手柄, USB2.0接口

**5. 设置:**

1. 手柄按 SELECT 键进入设置列表, 语音, 音效音, 游戏机文件操作, 读取识别度并退出, 系统信息, 退出设置。

**6. 执行标准:** GB/T2055.1-2012, GB8898-2011, GB/T13837-2012  
**7. 0至14岁以下儿童首次使用时请在成人陪同下使用本产品。**

**8. 下载说明:** 请将机器所支持的格式下载游戏。在放倒机器时应水平放置不可

**9. 保修条款:**

- 商品自售出之日起七日内, 如发生性能故障, 商品机身及包装必须保持完整, 可换同样型号商品 (须经鉴定), 但不包括人为损坏。
- 商品自售出之日起一年, 机身损坏, 配件不在我保修范围内。
- 保修服务只在正常使用下有效, 一切人为损坏 (包括自行拆卸, 使用不当) 不在我保修范围内。
- 维修时需提供本卡, 未能提供本卡或私自修改本卡, 本公司有权拒绝维修。

**10. 警告:** 窒息危险-所有包装物料 (如胶带、塑料袋、塑胶片、捆綁线、标签) 以及机内细小配件, 勿让3岁以下儿童接触, 以免发生窒息危险, 并在成人监护下使用。

当本机断电时, 请勿立即拔出电源线, 以免发生触电危险。

**11. 产品配件**

彩盒	机器	USB线	说明书	合格证	无线手柄	接收器	HDMI延长线
*1	*1	*1	*1	*1	*2	*1	*1

**12. 产品保修卡**

用户名	性别	年龄
通信地址	邮编	
联系电话	销售单号	
购买地点	身份证号	
购买日期	品名及规格	
经销商姓名	机身编号	
经销商签名	用户名	

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.  
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction