

Manual

The Apple® Find My® network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone®, iPad®, Mac®, or the Find Items app on Apple Watch®.

To use the Apple Find My app to locate the item, the latest version of iOS®, iPadOS®, or macOS® is recommended. The Find Items app on Apple Watch requires the latest version of watchOS®.

Use of the works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device on use of this product or its compliance with safety and regulatory standards.



When Your Item Is Lost

- When Your Item Is Lost:
 - Under "Lost Mode" tap the "Enable" button. A screen detailing "Lost Mode" will pop up, tap "Continue". You can enter your phone number or email address and tap "Next". You may enter a message that will be shared with the person that finds your item. Tap "Activate" to enable "Lost Mode".
 - Note: When "Lost Mode" is enabled, your item will be locked and you will not be able to use it.
 - Note: When "Lost Mode" is enabled, your item will be locked and you will not be able to use it.

Getting Started

1. Check For Updates
To get the latest version of the app, go to the App Store and check for updates of iOS, iPad OS, or macOS is recommended.


2. Power On
Press your item's function button once to turn on - it should beep once indicating it is powered on.



3. Add Your Item Locator

3.1 Start the App
Open Find My App on your supported iPhone or iPad.

3.2 Connect your Item Locator



Remove your Item Locator

- Ensure "Lost Mode" is disabled, tap "Remove Item" tab, a summary will open, tap "Remove" to confirm.

Reset your Item Locator

- After successfully removing the item locator from the app, press the function button four times and hold a firm time until you hear a ringing chime. The item locator is now reset and ready to pair to a new device.

Step1: Select the "Items" tab then tap the "Add Item" tab - symbol (Figure 1)



How to replace the Battery:

- Use your fingernail or the small gap on the side of your item locator to carefully pry open the back cover.
- Remove the battery with a new CR2025 battery 3V (positive pole upwards).
- Carefully insert the item locator.



Unwanted Tracking Detection:

- If your iPhone detects that an unknown item locator is traveling with you, it will send you a notification. A sound will start playing, so you will be able to find it. These alerts are only activated when an item locator is not connected to its owner's phone, so your partner's item locator will not trigger a sound if they are with you.

Battery Indicator

- Press the function button once to turn it on. It should a ringing chime indicating it is powered on.

Step2: Tap "Other Supported Items".



Important tips


- When pairing a device with Find My app, the phone will link to the Apple server. Pairing may be blocked if network problems, the Apple server is down, or the device is not compatible with the app. As switching between Wi-Fi and mobile. The first pairing may take a long time, please wait patiently.
- When "Lost Mode" is enabled, DO NOT REMOVE ITEM in the app. Your item locator will be locked and cannot be paired to a new device.
- The battery usage time varies depending on personal usage habits. Frequent use of the call function can accelerate battery consumption.



Regulatory Safety Information

- Warning: The battery must be kept out of the reach of children. Due to chemical burns and potential hospitalization, swallowing may cause serious injury or death. If this chip accidentally swallows the battery, please call the rescue phone immediately and seek medical advice in time.

5. Function Introduction



Locate your Item

- When your item is lost, tap "Play Sound" to make your item locator beep when it is nearby.
- Find your item locator's location.


Your item locator's last known location will appear on the map as easily you choose during set up. Tap "Directions" to navigate to the last known location.

Find Item When Out of Range

- Enable the "Notify when Left Behind" toggle, you will receive a notification when you leave your item locator behind and it is no longer in range of your device.

When your item locator is found, you will receive a notification when your item locator is found. You will receive a notification when your item locator is found.

- Note: "Notify When Found" can only be activated when your item locator is out of range.



FCC Statement

- This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment does not guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.



- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference, and
 - (2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirements.

The device can be used in portable exposure condition without restriction.

使用说明

Apple Find My 网络提供了快速、安全的方式，可以解锁 iPhone、iPad、Mac 上的 Find My 设备或 Apple Watch 上的 Find My 设备。

要在 Apple Find My 应用程序中使用此功能，建议启用最新版本的 iOS、iPadOS 或 macOS，Apple Watch 上的“查找项目”应用程序需要最新版本的 watchOS。

将 Works with Apple 徽标一起使用，意味着产品的设计符合用于解锁中使用的技术。并非所有产品都符合此标准。以兼容 Apple Find My 的设备列表为准。苹果设备不支持设备的操作或“产品”列表或设备。其是否符合安全标准由制造商决定。



解锁设备时

- 在“无设备”下，点击“启用”，将设备从一个无设备模式解锁。您也可以输入设备电话或任何其他设备地址。解锁设备后，设备将进入下一步。
- 在“无设备”下，点击“启用”，将设备从一个无设备模式解锁。您也可以输入设备电话或任何其他设备地址。解锁设备后，设备将进入下一步。

操作说明

1. 检查更新
更新到 Apple Find My 的最新版本。建议启用最新版本的 iOS、iPadOS 或 macOS。

2. 开机
按一下设备的物理按钮即可开机。听到铃声后，表示已开机。



3. 添加设备

- 3.1 打开 Apple
在 Apple 网站上打开 Apple 应用程序。

- 3.2 添加设备



移除设备时

- 在“无设备”下，点击“移除”，将设备从一个无设备模式移除。您也可以输入设备电话或任何其他设备地址。移除设备后，设备将进入下一步。

如何更有效地使用设备

1. 检查更新
更新到 Apple Find My 的最新版本。建议启用最新版本的 iOS、iPadOS 或 macOS。

2. 开机
按一下设备的物理按钮即可开机。听到铃声后，表示已开机。



3. 添加设备

- 3.1 打开 Apple
在 Apple 网站上打开 Apple 应用程序。

- 3.2 添加设备

如何更有效地使用设备

- 在“无设备”下，点击“移除”，将设备从一个无设备模式移除。您也可以输入设备电话或任何其他设备地址。移除设备后，设备将进入下一步。

如何更有效地使用设备

1. 检查更新
更新到 Apple Find My 的最新版本。建议启用最新版本的 iOS、iPadOS 或 macOS。

2. 开机
按一下设备的物理按钮即可开机。听到铃声后，表示已开机。



3. 添加设备

- 3.1 打开 Apple
在 Apple 网站上打开 Apple 应用程序。

- 3.2 添加设备

如何更有效地使用设备

- 在“无设备”下，点击“移除”，将设备从一个无设备模式移除。您也可以输入设备电话或任何其他设备地址。移除设备后，设备将进入下一步。

如何更有效地使用设备

1. 检查更新
更新到 Apple Find My 的最新版本。建议启用最新版本的 iOS、iPadOS 或 macOS。

2. 开机
按一下设备的物理按钮即可开机。听到铃声后，表示已开机。



3. 添加设备

- 3.1 打开 Apple
在 Apple 网站上打开 Apple 应用程序。

- 3.2 添加设备

如何更有效地使用设备

- 在“无设备”下，点击“移除”，将设备从一个无设备模式移除。您也可以输入设备电话或任何其他设备地址。移除设备后，设备将进入下一步。

如何更有效地使用设备

1. 检查更新
更新到 Apple Find My 的最新版本。建议启用最新版本的 iOS、iPadOS 或 macOS。

2. 开机
按一下设备的物理按钮即可开机。听到铃声后，表示已开机。



3. 添加设备

- 3.1 打开 Apple
在 Apple 网站上打开 Apple 应用程序。

- 3.2 添加设备

如何更有效地使用设备

- 在“无设备”下，点击“移除”，将设备从一个无设备模式移除。您也可以输入设备电话或任何其他设备地址。移除设备后，设备将进入下一步。

如何更有效地使用设备

1. 检查更新
更新到 Apple Find My 的最新版本。建议启用最新版本的 iOS、iPadOS 或 macOS。

2. 开机
按一下设备的物理按钮即可开机。听到铃声后，表示已开机。



3. 添加设备

- 3.1 打开 Apple
在 Apple 网站上打开 Apple 应用程序。

- 3.2 添加设备

