


X30SE

快速使用手册



使用产品前请仔细阅读本说明书


使用须知

1. 请勿将本产品置于高温环境，内有充电锂电池；
2. 请使用额定电压的电源给本产品充电；
3. 请固定好本产品主机，避免跌落导致主机和电池损坏；
4. 请勿尝试拆卸产品，避免造成产品损坏；
5. 如果长时间不使用本产品，请将其储存在干燥的环境中，并每月为耳机充电一次，避免极端的温度和灰尘。

产品规格

| | |
|------|----------|
| 蓝牙名称 | X30SE |
| 蓝牙版本 | 5.3 |
| 蓝牙距离 | 15-30米 |
| 工作时间 | 50小时 |
| 待机时间 | ≥500天 |
| 充电接口 | TYPE-C |
| 电池容量 | 1200mAh |
| 充电时长 | 约1~2小时 |
| 充电电压 | 5V 1A/2A |
| 电池类型 | 聚合物锂电池 |
| 防水等级 | IP67 |

产品介绍



指示灯说明

| | |
|--------|----------------|
| 开机 | ● 蓝灯快闪 |
| 关机 | ●→○ 红灯再熄灭 |
| 蓝牙待连接 | ● 蓝灯快闪 |
| 蓝牙连接成功 | ●● 蓝灯慢闪 |
| 充电 | ●→● 红灯常亮, 充满变蓝 |

操作说明

开机/关机

开机: ①键长按3秒, 听到“开机”提示音, 状态灯蓝灯快闪。
关机: ①键长按3秒, 听到“关机”提示音。
重启: ①键长按10秒, 设备重启。

蓝牙连接

②键长按3秒开机, 状态灯蓝灯快闪, 耳机进入配对状态, 打开手机蓝牙搜索, 点击设备名称“X30SE”连接耳机, 听到“连接成功”提示音, 指示灯变为蓝灯慢闪, 表示蓝牙配对成功。

蓝牙同时连两部手机

耳机先连接第一台手机的蓝牙然后断开蓝牙, 继续连接第二台手机的蓝牙(不需要再断开), 再打开第一台手机的蓝牙直接在界面点击设备“X30SE”连接即可。

暂停播放/歌曲切换/音量加减

暂停播放: ②键短按(按一下)暂停播放。
歌曲切换: 旋转开关向左旋转“○”1次, 切换下一曲;
旋转开关向右旋转“○”1次, 切换上一曲。
音量加减: 旋转开关向左旋转“○”后不松, 音量减小;
旋转开关向右旋转“○”后不松, 音量增加。

来电通话

接听: ②键短按接听(关闭/开启自动接听功能时都可按接听)。
拒接: ②键长按拒接挂断。
回拨: ②键双击(快速按两下), 回拨最近通话最后一人。

来电自动接听(关闭/开启)

关闭: 旋转开关向左连续转2次, 提示“嘟”一声为关闭;
开启: 旋转开关向左连续转2次, 提示“嘟嘟”两声为打开。

操作说明

启动手机语音AI助手

连接手机蓝牙后, 单击功能键可启动手机语音AI助手。
(第一次使用智能助手一定要点同意访问手机内容, 否则使用不了, 如无提示不用理会)

语音播报电量

旋转开关向右连续转2次, 语音播报设备当前电量。

中英文语音切换


开机状态下, 双击功能键切换中文/英文语音提示。

恢复蓝牙出厂设置

开机状态下, 长按功能键5秒, 清除蓝牙配对信息。


注意: 开机后蓝牙未连接时, 5分钟后将自动关机

产品清单



X30SE

USER MANUAL




Please read this manual carefully before using the product

Notice for Use

1. Do not place this product in high-temperature environments; it contains a rechargeable lithium battery.
2. Please use rated voltage power supply to charge the product.
3. Secure the main unit of the product to avoid damage to the main unit and battery caused by falling.
4. Do not attempt to disassemble the product to avoid damage.
5. Charge the headset once a month and keep it away from extreme temperatures and dust.

Product Introduction



Product Standard

| | |
|--------------------|-------------------------|
| Bluetooth name | X30SE |
| Bluetooth version | 5.3 |
| Bluetooth range | 15-30 m |
| Working time | 50 h |
| Standby time | ≥500 days |
| Charging interface | TYPE-C |
| Battery capacity | 1200mAh |
| Charging time | About 1~2 h |
| Charging voltage | 5V 1A/2A |
| Battery type | Polymer lithium battery |
| Waterproof grade | IP67 |

Operation Instruction

Power On/Off

Power On: Long-press for 3s, hear the "power on" prompt, and the status light will flash blue quickly.
 Power Off: Long-press for 3s, hear the "power off" prompt.
 Restart: Long-press for 10s to restart the device.

Bluetooth Connection

Press and hold to power on, turn on phone Bluetooth, click on search for Bluetooth devices, and find the device named "X30SE" Bluetooth click to connect.

Connecting Two Phones Simultaneously

First connect the headset to the Bluetooth of the first mobile phone and then disconnect it, continue to connect to the Bluetooth of the second mobile phone (no need to disconnect it again), then turn on the Bluetooth of the first mobile phone and directly tap the device "X30SE" on the interface to connect it.

Pause Play/Song Switch/Volume Adjustment

Pause Play: Short press (click) to pause play.
 Song Switch:
 Rotate the switch left "↶" once to switch the next song;
 Rotate right "↷" once to switch the previous song.
 Volume Adjustment:
 Rotate the switch left "↶" and hold to decrease volume;
 Rotate right "↷" and hold to increase volume.

Incoming Calls

Answer: short press to answer the call(call could be able to answered when the automatic answer function is on or off).
 Reject: long press the button refused to hang up.
 Callback: Double-click to redial last contact.

Automatic Call Answering (On/Off)

Off: Turn the rotation switch to the left twice, "Du" indicates that the automatic answering function is turning off;
 On: Turn the switch to the left twice in succession, "DuDu" indicates that the automatic answering function is opening.

Operation Instruction

Activate Mobile Voice AI Assistant

After connecting to the Bluetooth on mobile phone, click function button to activate the voice AI assistant. (When using the AI assistant for the first time, you must click agree to access the content of the mobile phone. Ignore this if no reminder is prompted)

Voice Broadcast of Battery Level

Rotate the switch right twice consecutively to have the device voice-broadcast the current battery level.

Chinese-English Voice Switch


In the power-on state, double-click the function button to switch between Chinese and English voice prompts.

Restore Bluetooth Factory Settings

In the power-on state, long press the function button for 5s to clear the Bluetooth pairing information.

Note: If the Bluetooth is not connected after start up, the device will auto - power off in 5 minutes.

Product List



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.