

Music Wearable Devices Manual

Matters needing attention

1. Please keep away from acidic, alkaline, and pointed items for use and storage
2. Please keep the equipment dry
3. Please keep the equipment clean and add desiccant after use
4. Please take out the headphones before washing
5. Do not disassemble, modify, or modify the equipment separately
6. Do not throw or drop

Charge

Insert the USB port of the micro into the headphones. At this time, the LED light will turn red. When the LED light turns blue, it indicates that the Wireless headphones are fully charged. Please unplug the data cable.

Power on

Press the power button for 2-3 seconds, and the Wireless earphone LED lights will alternately flash red and blue.

Shutdown

In the power on state, press the power on button for 2-3 seconds. When the LED flashes red for 3 times, the red light goes out and the Wireless headphones are turned off. Wireless connection instructions:

Power on and Wireless connection

1. Press the power on button for 2-3 seconds, and the LED lights will alternately flash red and blue. Turn on the mobile phone Blue function and search for the Blue name "Y60" to pair. If the pairing is successful, the blue LED will slowly flash.

Auto pairing

After the first pairing is successful, the next time Wireless headphones and mobile Blue function are used, they will automatically connect without the need to search for a new connection.

Pause and Play

When playing music, pressing the power button once is the pause function, and pressing it again is the play function. When a phone call is made, pressing the power button once is the answer function, and when a phone call is made, pressing the power button once is the end function. Press the "fast forward" button to switch to the next song, and press the "fast rewind" button to switch to the previous song. Long press the "Fast Forward" button to decrease the volume, and long press the "fast rewind" button to increase the volume

Parameters

Pairing name: Y60

Wireless solution: Blue Message

Wireless transmission distance: 10 meters

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.