




IC-W2 产品说明书

尺寸: 280*100mm 单页尺寸: (70*100mm)

材质: 128克铜版纸, 双面印刷

	Product Features	Apple Watch charging	Samsung Watch charging	Attention and Troubleshooting
				Specifications
 MAGNETIC WIRELESS CHARGER WITH USB-C INPUT Model: 2733366  Thank you for choosing the RadioShack Magnetic Charger 2733366! We appreciate your purchase and hope you enjoy its quality. To get the most out of your device, please read these instructions carefully and keep this guide for future reference	<ol style="list-style-type: none">1. The charger provides dual-sided wireless charging for both Apple Watch and Samsung Watch, ensuring it is small and easy to carry.2. The i side powers up the Apple Watch, whereas the S side provides direct charging for the Samsung Watch.3. You can only charge one watch at a time; you cannot charge both watches simultaneously.			 1. Avoid vigorous extrusion or collision. 2. To prevent short circuits, avoid disassembling, exposing to flames, or wetting the device while it's powered on. 3. To prevent circuit damage, avoid using the product in extreme temperatures, high humidity, or harsh environments. 4. Keep magnetic strips or chip cards (such as ID and bank cards) away from the charging pad to avoid losing functionality. 5. Check the connection: Check that the charger is connected to the correct adapter. 6. Check the case: Remove the case or any accessories that may interfere with charging. 7. Check the position of the device: Place the device in the center of the charging platform, without obstacles