

折后尺寸：68*100mm；105G双铜+单K，双面印刷。



POWER BANK

model 2309285

FCC ID: 2BDXE-2309285

USER MANUAL



Illustration

1

radioshack

2

4

Stand

3

Power button

5

iWatch wireless charger

6

LED light indicator

1. Wireless charger

2. iWatch wireless charger

3. Power button

4. Stand

5. Type-C In/Out

6. LED light indicator


Specifications

Size	106.6x69.6x21.2mm
Model No.	2309285
Capacity	10000mAh/38.5Wh
Type-C Input	PD18W(5V/3A, 9V/2A, 12V/1.5A)
Type-C Output	PD20W(5V/3A, 9V/2.22A, 12V/1.5A)
Wireless Output	5W, 7.5W, 10W Max
iWatch Output	2.5W Max
Total Output	5V/3A Max

Operation Instructions

Wireless Charging:

To charge your phone wirelessly, place on your Power bank 2309285 a compatible device (iPhone 12 and above can be attracted via magnetic force) on the charger. Press the power button to activate the power bank; the LED will illuminate to indicate that it's on. Charging will start automatically after 4.5 seconds. The wireless LED indicator will light up after an additional 3 seconds, while the power LED will remain lit throughout the charging process.




Type-C Charging:

Connect a Type-C cable to the 2309285 power bank, with the other end plugged into your mobile device. The 2309285 will automatically charge your mobile charging process.

Recharging the 2309285 Power Bank:

To recharge the power bank, connect a USB cable to a USB adapter. Then, plug the other end into the Type-C input port on the power bank. Finally, connect the USB adapter to an outlet to begin charging.



Attention

Please read all instructions thoroughly before using the product. To ensure safety and longevity, avoid exposing the product to direct sunlight and high temperatures. Never place the product on wet surfaces or those that have been cleaned with solvents. Handle the product with care: do not puncture, throw, drop, bend, or modify it in any way. If you notice any unusual smells, heating, distortions, or other abnormalities, discontinue use immediately. Keep the product out of the reach of children to prevent accidents and ensure safety.

CORRECT DISPOSAL FOR THIS PRODUCT

This marking signifies that this product should not be discarded with regular household waste. To safeguard the environment and human health from the adverse effects of improper waste disposal, please recycle it responsibly. By doing so, you contribute to the sustainable reuse of material resources. To return your used device, utilize designated return and collection systems, or reach out to the retailer from whom you purchased the product. They can assist you in ensuring this product is recycled in an environmentally safe manner.

Caution:

There is a risk of fire and burns. To ensure safety, please do not open, crush, heat above 60°C, or incinerate this product. Always adhere to the manufacturer's instructions for safe handling and usage. Your safety is our priority.

FCC WARNING:

FCC RF exposure statement:The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.



POWER BANK

modelo 2309285

FCC ID: 2BDXE-2309285

MANUAL DE USUARIO



ilustración

1

radioshack

2

4

Stand

3

Botón de encendido

5

Cargador inalámbrico iWatch

6

Indicador de luz LED

1. Cargador inalámbrico

2. Cargador inalámbrico iWatch

3. Botón de encendido

4. Stand

5. Entrada/salida tipo C

6. Indicador de luz LED


Especificaciones

Dimensiones	106.6x69.6x21.2mm
Modelo	2309285
Capacidad	10000mAh/38.5Wh
Entrada Tipo-C	PD18W(5V/3A, 9V/2A, 12V/1.5A)
Salida Tipo-C	PD20W(5V/3A, 9V/2.22A, 12V/1.5A)
Salida Inalámbrica	5W, 7.5W, 10W Max
Salida de reloj	2.5W Max
Salida Total	5V/3A Max

Instrucciones de operación

Carga inalámbrica:

Para cargar su teléfono de forma inalámbrica, coloque en su banco de energía 2309285 un dispositivo compatible (el iPhone 12 y superior se puede atraer mediante fuerza magnética). Presione el botón de encendido para activar el banco de energía; el LED se iluminará para indicar que está encendido. La carga se iniciará automáticamente después de 4.5 segundos. El indicador LED inalámbrico se iluminará después de 3 segundos adicionales, mientras que el LED de encendido permanecerá encendido durante todo el proceso de carga.




Carga tipo C:

Conecte un cable tipo C al banco de energía 2309285, con el otro extremo conectado a su dispositivo móvil. El 2309285 cargará automáticamente tu móvil.

Recarga del banco de energía 2309285:

Para recargar el banco de energía, conecte un cable USB a un adaptador USB. Luego, conecte el otro extremo al puerto de entrada tipo C del banco de energía. Finalmente, conecte el adaptador USB a una toma de corriente para comenzar a cargar.



Atención

Lea detenidamente todas las instrucciones antes de usar el producto. Para garantizar la seguridad y la longevidad, evite exponer el producto a la luz solar directa y a las altas temperaturas. Nunca coloque el producto sobre superficies mojadas o que hayan sido limpiadas con disolventes. Manipule el producto con cuidado: no lo perforo, arroje, deje caer, doble ni lo modifique de ninguna manera. Si nota olores inusuales, calentamiento, distorsiones u otras anomalías, deje de usarlo inmediatamente. Mantenga el producto fuera del alcance de los niños para evitar accidentes y garantizar la seguridad.

ELIMINACIÓN CORRECTA DE ESTE PRODUCTO

Esta marca significa que este producto no debe desecharse con la basura doméstica común. Para salvaguardar el medio ambiente y la salud humana de los efectos adversos de la eliminación inadecuada de residuos, recíclelos de manera responsable. De este modo, contribuyes a la reutilización sostenible de los recursos materiales. Para devolver tu dispositivo usado, utiliza los sistemas de devolución y recolección designados, o comuníquese con el minorista al que compraste el producto. Pueden ayudarlo a garantizar que este producto se recicle de manera segura para el medio ambiente.

Precaución:

Existe riesgo de incendio y quemaduras. Para garantizar la seguridad, no abra, triture, caliente a más de 60 °C ni incinere este producto. Siga siempre las instrucciones del fabricante para un manejo y uso seguros. Su seguridad es nuestra prioridad.

ADVERTENCIA DE LA FCC:

Este dispositivo cumple con la parte 15 de las Reglas de la FCC. El funcionamiento está sujeto a las dos condiciones siguientes:
1. Este dispositivo no puede causar interferencias dañinas, y
2. Este dispositivo debe aceptar cualquier interferencia recibida, incluidas las interferencias que puedan causar un funcionamiento no deseado. Cualquier cambio o modificación no aprobado expresamente por la parte responsable del cumplimiento podría anular la autoridad del usuario para operar el equipo. Este equipo ha sido probado y cumple con los límites para un dispositivo digital de Clase B, de conformidad con la parte 15 de las Reglas de la FCC. Estos límites están diseñados para proporcionar una protección razonable contra interferencias dañinas en una instalación residencial. Este equipo genera usos y puede irradiar energía de radiofrecuencia y, si no se instala y utiliza de acuerdo con las instrucciones, puede causar interferencias dañinas en las comunicaciones por radio. Sin embargo, no hay garantía de que no se produzcan interferencias en una instalación en particular. Si este equipo causa interferencias dañinas en la recepción de radio o televisión, lo cual se puede determinar apagando y encendiendo el equipo, se recomienda al usuario que intente corregir la interferencia mediante una o más de las siguientes medidas:
-Reorientar o reubicar la antena receptora.
-Aumentar la separación entre el equipo y el receptor.
-Conecte el equipo a una toma de corriente en un circuito diferente al que está conectado el receptor.
-Consulte al distribuidor o a un técnico experimentado en radio/TV para obtener ayuda.