

使用说明书

S20

产品型号: S20

产品型号: S20
播放时间: 约4小时
有效距离: ≥ 10 米
充电时间: 约1小时

版本: 5.3
通话时间: 约4
喇叭: 铜环13m

1.充电盒*1 2.左右耳机*1
3.产品手册*1 4.充电线*1

充电时间：约1小时
输入电压：5V/500mAh

打开充电仓盖,取出右耳耳机,将耳机喇叭端轻轻放入右耳耳道,再轻轻摆动耳机不晃动为宜。用同样方法佩戴左耳耳机。

1. 开机

- (1) 打开充电仓盖子, 取出耳机自动开机, 耳机红蓝灯闪烁
- (2) 耳机在关机状态, 长按耳机触摸板3秒开机

2. 关机

- (1) 将耳机放回充电仓, 耳机自动关机充电
- (2) 耳机在开机状态下, 长按耳机触摸板5秒关机

4. 打开充电仓盖子，取出耳机自动开机，红蓝灯闪烁，进入自动组队状态，其中一个耳机灯灭，表示组队成功。

4. 打开设备无线列表，搜索找到“S20”

单击连接“S20”即可连接。如连接失败，将耳机放回充电仓盖上盖子，然后重复上面操作步骤即可。

· 双耳同时离开与设备正常连接距离后，蓝牙耳机进入回连无线耳机状态，5分钟内未完成回连成功，双耳将自动关机。

5、耳机开机之后，未连接手机之前，双耳任意一边自动切换中英文语言（单中文或单英文的产品无此功能）

首次连接设备后，下一次耳机重启开机，会自动连接上一次配对设备

- 播放/暂停 音乐
- 音乐状态下,轻触2次,耳机1下
- 播放上一曲
- 音乐状态下,轻触2次,耳机2下
- 播放下一曲
- 音乐状态下,轻触2次,耳机1下
- 音乐状态下,轻触2次,音量加
- 音乐状态下,轻触2次,音量减
- 接听电话
- 来电时,轻触1次,耳机1下
- 拒接电话
- 来电时,轻触1次,耳机2下
- 静音助手
- 连接状态下,长按任意键1.5s
- 进入静音助手状态

充电:耳机放入充电盒自动充电
指示灯亮红灯,充满后红灯熄灭
盒低电:数码管个位数闪烁
盒充电:数码管个位数闪烁,充满100停止

1、问：怎么只有一个耳机有声音？
答：将两个耳机同时放回充电仓，关盖充电，然后在取出看是否恢复双耳机模式。
如未恢复，恢复出厂设置即可解决。

2、问：手机无法连接耳机？
答：将手机上配对的 S20 删除，再进行配对连接即可。

3、问：怎么听歌/通话没有声音？
答：安卓手机在手机连接记录的右边有一个设置图标，点击进入，将两个音频选项取消勾选再重新选择，手机在设置调用辅助功能进入音频选项方式，选择自动，可能会出现卡顿，断断续续，更换手机或者重新配对连接可以恢复正常。

4、问：怎么有卡顿/断接？
答：如果使用耳机时，周边有大量的 Wi-Fi 设备，4G 信号，大功率电器等等产生干扰，可能会出现卡顿，断接情况，更换手机或者重新配对连接可以恢复正常。

- 1、请使用正规来源有安全认证的充电器进行充电
- 2、使用耳机时适量的调节音量大小以免损伤听觉
- 3、正确使用产品避免高空摔落或重度挤压
- 4、儿童请在成人陪同下使用避免误食
- 5、远离高温或潮湿等极端环境
- 6、请勿拆卸本产品

Operating instruction

S20

Product parameters are laboratory test data, the specific data is subject to the use of data

Electronic vital display

Indicator light

ZhongZhi plate

The horn

The contact points of the charging

Product model: S20 Version: 5.3
Running time: about 4 hours Call time: approximately 4 hours
Effective distance: ≥ 10 m Horn: copper ring 13mm
Charging time: about 1 hour

1. Charging case *1 2. Left and right earphones *1
3. Product manual *1 4. Charging cable *1

charging ask: about one hour
the input voltage: 5 v / 500 mah

pen the charging cover, take out the right ear headphones, the headset speakers. Swing gently gently into the right ear, ear, headset not rock is advisable. Use the same method to wear ear headphones.

- 1) Open the cover of the charging case, the earphone will start up automatically, and the earphone blue light will flash red
- 2) When the headset is off, touch the touch pad of the headset for 3 seconds to start the headset

- 1) Put the earphone back into the charging bin and close the cover. The earphone will be turned off and charged
- 2) When the headset is on, touch the touch pad of the headset for 5 seconds to turn it off

Open the cover of the charging bin, take out the phones and start up automatically. The red and blue lights flash, and enter the state of automatic team location.

Open the device Wireless list and search for "S20".

click "S20" to connect. If the connection fails, push the earphone back into the charging bin and cover the bin. Then, click "S20" again to connect. Repeat the above steps.

When both ears leave the normal connection distance of the device at the same time, the headset will enter the wireless headset connection state. If the connection is not successful within 5 minutes, the headset will automatically shut down.

When the device is connected for the first time, the headset will automatically connect to the last device when it is restarted next time.

- Play/Pause
- Music Tap L/R earphone 1 while playing music
- Let's play the last one
- When the music is playing, tap the R headset 2
- Let's play the next one
- Tap 1. headset 2 times while playing
- In the music state, tap 3 times 1. volume + in music state, tap 3 times R volume minus
- Refuse to answer the phone
- Tap the L/R headset twice when an incoming call comes in
- Voice assistant
- When connected, hold down any earphone for 1.5 seconds and release to enter the voice assistant state

Charging: headsets in the charging box automatically
Light after charging indicator red, full of the
Charging box of low electricity: digital tube
Single digits flashing
Charging box: digital tube single
Digits flashing, full of 100 to stop

Q: How can I use only one earphone has sound?

A: Put the two earphones back into the charging bin at the same time, close the cover to charge, and then take them out to see whether the dual-ear mode is restored.

Q: If the fault is not rectified, restore the fault to factory Settings

Q: The phone can't connect to the headset?

A: Delete the paired S20 on the mobile phone, and then make the wired connection.

Q: How can I listen to music/talk without sound?

A: Android phones have a setting icon on the right side of the phone connection record. Click enter to select two audio/select and then re-select. Enter audio call mode in Setting General Accessibility, and select Automatic, if it is automatic when other options, and then change to automatic, if not restored. Delete the pairing record retry attempt.

Q: Why is there a stutter/stutter?

A: If you use headphones, there are a lot of Wi-Fi devices, 4G signals, high power appliances and so on interference, stuttering and discontinuous conditions may occur, and the connection can be restored by changing the environment or re-pairing.

1. Please use a charger with safety certification from a formal source for charging
2. Adjust the volume of headphones to avoid damage to hearing
3. the correct use of the product to avoid falling from high or heavy extrusion
4. Children should be accompanied by adults to avoid accidental ingestion
5. Stay away from extreme environments such as high temperature or humidity
6. Do not disassemble the product

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.