

尺寸:75*55mm

<p>说 明 书 Manual</p> 	<p>① 连接方法</p> <ol style="list-style-type: none"> 打开耳机盒盖，取出耳机，靠近已解锁的手机 Open the headphone box cover, take out the headset, and close to the unlocked mobile phone 等待8秒左右打开蓝牙 Wait eight seconds or so to turn on Bluetooth 搜索蓝牙名称点击连接 Search for Bluetooth name and click connect 自动回连：在手机没有删除连接过耳机配对名，取出耳机可自动回连 AUTO-CONNECT: The phone does not delete the connection through the headset matching name, take out the headset can automatically connect back <p>② 主要参数</p> <table border="1"> <tr> <td>频率响应</td> <td>20HZ-20KHZ</td> <td>配对名</td> <td>Y1</td> </tr> <tr> <td>耳机控制</td> <td>触摸控制</td> <td>产品重量</td> <td>50g</td> </tr> <tr> <td>支持协议</td> <td>a2dp\avrcp\java\vp\avrcp\hfp\hsp\l2cap\cmll\avrcp\l2cap\prof\hfp\sub\l2cap\prof\hfp</td> <td>产品尺寸</td> <td>55.2*51*19.8mm</td> </tr> <tr> <td>充电盒充电</td> <td>Type-C充电线</td> <td>包装清单</td> <td>无线耳机套装；充电线；说明书</td> </tr> </table> <p style="text-align: center;">1</p>	频率响应	20HZ-20KHZ	配对名	Y1	耳机控制	触摸控制	产品重量	50g	支持协议	a2dp\avrcp\java\vp\avrcp\hfp\hsp\l2cap\cmll\avrcp\l2cap\prof\hfp\sub\l2cap\prof\hfp	产品尺寸	55.2*51*19.8mm	充电盒充电	Type-C充电线	包装清单	无线耳机套装；充电线；说明书	<p>③ 主耳点触方式</p>  <p>暂停/播放/接听/挂断(触摸一下) Pause/play/Answer / end (touch) 唤醒siri/ 拒接电话 (长按2秒) Wake up Siri/ Reject Call(Long Press 2 seconds) 下一曲 (三击) Next song(Three strikes) 加音量 (双击) Increase reduction (Double Tap)</p> <p style="text-align: center;">2</p>	<p>④ 副耳点触方式</p>  <p>暂停/播放/接听/挂断(触摸一下) Pause/play/Answer / end (touch) 唤醒siri/ 拒接电话 (长按2秒) Wake up Siri/ Reject Call(Long Press 2 seconds) 上一曲 (三击) Last song(Three strikes) 减音量 (双击) Volume the volume (Double Tap)</p> <p style="text-align: center;">3</p>				
频率响应	20HZ-20KHZ	配对名	Y1																				
耳机控制	触摸控制	产品重量	50g																				
支持协议	a2dp\avrcp\java\vp\avrcp\hfp\hsp\l2cap\cmll\avrcp\l2cap\prof\hfp\sub\l2cap\prof\hfp	产品尺寸	55.2*51*19.8mm																				
充电盒充电	Type-C充电线	包装清单	无线耳机套装；充电线；说明书																				
<p>⑤ 充电仓说明</p>  <p>1、隔30秒以上进行保护，需重新关盖再开盖可以正常打火 2、打火持续时间8秒会保护灭火 3、充电时绿灯闪烁从第一格灯随电压上升，灯往上闪 直到第四格灯，全亮不闪烁代表充满电 4、耳机放进充电仓会自动唤醒充电 充满电充电仓一起关断 1. For protection every 30 seconds or more, it is necessary to close the cover again before opening it to ignite normally. 2. After ignition, the ignition is 8 seconds, which will protect and extinguish the fire. 3. When charging, the green light flashes as the voltage rises from the first grid light, and the light flashes upwards until the fourth grid light. If all lights are on and not flashing, it means it is fully charged. 4. Putting headphones into the charging compartment will automatically wake up, fully charge, and turn off the charging compartment together</p> <p style="text-align: center;">4</p>	<p>⑥ 使用注意事项</p> <ol style="list-style-type: none"> 日常使用中耳机充电面会沾上灰尘等脏污的东西可以使用棉签清理耳机充电接触面。 Use a cotton swab to clean the charging surface of the earphone, which will be stained with dirt. 耳机需按要求正确规范的使用，注意使用环境对耳机的影响，为保证连接顺畅，建议手机和耳机之间的距离在8米范围内。 Earphone should be used correctly according to the requirement. Pay attention to the influence of environment on earphone. In order to ensure smooth connection, it is suggested that the distance between the phone and earphone should be within 8 meters. 如耳机有连接不上或通訊不畅等其它问题，请勿私自拆卸耳机本体及其配件，否则不予保修。请不要使用超过额定安培数的充电头给耳机充电。 If the headset does not connect or poor communication and other problems, please remove the headset itself and its accessories, otherwise no warranty do not use more than the rated ampere charging head to the headset. 为了保证你正常使用耳机，请确保耳机的电量充足。 To make sure you're using your headphones properly, make sure they're fully charged. <p style="text-align: center;">5</p>	<p>⑦ 保修</p> <p>Pause耳机基本功能 Basic function of earphone</p> <ol style="list-style-type: none"> 产品如有任何功能问题，均可享受保修服务，联系客服。 If the product has any functional problems, can enjoy the warranty service, contact customer service. 人为损坏、摔坏、人为刮花、进水、无保修卡者不在保修范围内。 Artificial damage, broken, artificial scratch, water, no warranty card is not within the scope of the warranty. 客户必须填写所有必要资料(客户姓名、地址、电话、购买日期等) Customer must fill in all necessary information (customer name, address, telephone number, date of purchase, etc.). 保修服务需在保修卡并按要求操作即可保修，否则不保修 Warranty service in the warranty card and according to the requirements of operation can be warranty, otherwise no warranty <table border="0"> <tr> <td>产品型号:</td> <td>_____</td> </tr> <tr> <td>Model:</td> <td>_____</td> </tr> <tr> <td>客户姓名:</td> <td>_____</td> </tr> <tr> <td>Name of client:</td> <td>_____</td> </tr> <tr> <td>联系电话:</td> <td>_____</td> </tr> <tr> <td>Contact number:</td> <td>_____</td> </tr> <tr> <td>客户地址:</td> <td>_____</td> </tr> <tr> <td>Client address:</td> <td>_____</td> </tr> <tr> <td>购买日期:</td> <td>_____</td> </tr> <tr> <td>Date of purchase:</td> <td>_____</td> </tr> </table> <p style="text-align: center;">6</p>	产品型号:	_____	Model:	_____	客户姓名:	_____	Name of client:	_____	联系电话:	_____	Contact number:	_____	客户地址:	_____	Client address:	_____	购买日期:	_____	Date of purchase:	_____	<p>⑧ 温馨提示</p> <ol style="list-style-type: none"> 如果你的耳机充电中存在发烫严重或烧坏的情况可以看是不是使用大于5V2A功率的充电头，大于的话需要更换小于5V2A的充电头。 当左右耳机出现只有一边有声音的时候请把两只耳机重新放入充电盒，耳机自动关机，打开手机找到对应名，点击取消蓝牙配对，打开充电盒，取出耳机，靠近已解锁的手机，等待8秒左右打开手机蓝牙搜索蓝牙配对名点击连接。 耳机听不到声音 <ol style="list-style-type: none"> 确认耳机处于工作状态 确认耳机的音量大小是否合适 确认耳机是否与手机正常连接 确认耳机在正常的工作范围 如果听到耳机有断续的情况：有些地方信号干扰大，蓝牙耳机会出现干扰蓝牙底噪的情况会出现断续情况走到别的地方断开重新连接即可解决。 <ol style="list-style-type: none"> 耳机离手机距离超出8米以上或中间有障碍物时，会影响信号传输 周边有大功率发射设备时，会影响信号传输 紧密空间也会影响信号传输（电子城等） <p style="text-align: center;">7</p>
产品型号:	_____																						
Model:	_____																						
客户姓名:	_____																						
Name of client:	_____																						
联系电话:	_____																						
Contact number:	_____																						
客户地址:	_____																						
Client address:	_____																						
购买日期:	_____																						
Date of purchase:	_____																						

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.