

S30 Pro Translator Device

PRODUCT MANUAL

QUICK OPERATION GUIDE

First of all thank you for using our products! This device supports WiFi, please select WiFi according to the actual use environment.

Wireless network environment

Some applications need to be connected to the network.

Setting method:

Click the "Settings" menu, open the "WLAN" to view the available network, select the wireless network, and enter the password to connect.

Click on the "Settings" menu, select the "Bluetooth" option, and then click the Bluetooth on/off button to activate the Bluetooth function.

④ Start/Shut down/Restart

Boot Up:

Long press the power button for more than 2 seconds, the screen will display the startup animation to the translation interface, and you can use it normally.

Shutdown:

Press and hold the power button for more than 2 seconds. In the dialog box that pops up, select the "Shutdown" option to shut down the device.

Restart:

Press and hold the power button for more than 2 seconds. The restart/shutdown icon is displayed on the screen. Select the restart icon to restart the device.

0 Turn the screen on or off

Turn the screen on or off manually:

When the screen is off, press the power button to open the screen; When the screen lights up, press the power button to turn off the screen;

Set the automatic shutdown time:

Click on the "Settings" menu and then click on the "Automatic shutdown" option to adjust the shutdown duration.

Set the sleep time:

Click on the "Settings" menu and then click on the "Sleep" option to adjust the sleep duration.

Main interface

The main interface of the device is the main function entrance of the device.

There are 16 main functions:

Online translation, offline translation, simultaneous recording, ChatGPT, input learning, exchange rate	translation, conversation translation, group translation, mobile conversion, unit	translation, photo translation, smart translation, language conversion, World
---	---	---

(Conversation translation, photo translation, world clock and other functions are optional, please refer to the actual model)

Status bar

The top of the device screen displays some status information of the device, such as time, Bluetooth, WiFi network, power and other status information.

EQUIPMENT UPGRADE

The device will be updated from time to time. If your device cannot be updated, the possible reasons are as follows: ① The current version is the latest version, and there is no new upgrade package.

② Check whether the network connection of the device is normal. You can receive the upgrade notification only when the network connection is normal.

③ Do not perform any operation during the system installation. In this way, the system installation may be interrupted and the upgrade may fail. As a result, the system cannot be used normally.

NOTE ON CHARGING AND BATTERY USE ① Before charging, ensure that

the charging port is clean and free of dirt.

② When connecting the charging cable to the charging port, ensure that the charging cable is properly connected. Do not forcibly connect the charging cable.

③ This product does not come with a power adapter. If consumers use a power adapter for power supply, they should purchase a power adapter that is certified and meets the requirements of the standard.

④ If the battery is overheated, discolored, deformed, bulging, or leaking during use, charging, or storage, stop using the battery to avoid safety problems.

⑤ When charging, because the battery temperature will rise, do not put together with flammable materials, so as not to cause fire. Batteries must not be exposed to conditions such as sunlight, fire, or similar overheating.

⑥ Do not disassemble, squeeze, heat or burn the built-in battery of this product, or use sharp objects, screwdrivers, etc. to tie or pry the battery, the above operations will cause the battery fire.

⑦ To reduce the risk of electric shock in children, please charge this product under the guidance of a parent or other guardian.

SAFETY PRECAUTIONS

Do not place the device in an environment where the temperature is too low or too high (below -10°C or above 50°C) for a long period of time. Extreme temperatures may deform the device and shorten the service life of the device.

Do not use the device during thunderstorms; Do not place the device

in water;

Keep the device and all accessories away from children and pets to avoid choking or other serious consequences due to accidental ingestion.

MAIN FUNCTION INTRODUCTION

Online translation

Click on the native or foreign language option at the top of the online translation page and select the language to be translated;Long press the voice button,release the voice button after entering,and you can achieve language translation between languages.

(This function needs to be used in an environment with network connection)

① Click on the translated content in the screen,you can broadcast the translated

content by voice;

② The mother tongue input key corresponds to the translation language on the left,and the foreign language input key corresponds to the right language;

③ The clearer the voice input,the more accurate the recognition;

④ The native language and foreign language of some models correspond to the blue and red color of the keys.

Offline translation

This feature can accurately translate even in environments without a network,and the usage method is the same as the online translation function.

Conversational translation

Click on the native language or Foreign language option at the top of the Session translation page to select the language you want to translate.

You can start translating conversations in real time,automatically recognizing the input language without any action during communication,and then quickly translating.

(This function is optional,please refer to the actual model)

One-click translation

No need to distinguish the language,automatically recognize the input content,and accurately translate it.No need to distinguish A/B voice keys,improve translation efficiency.

(This function is optional,please refer to the actual model)

⑩Photo translation

Support online photo translation/offline photo translation.

How to use:

① Click the language icon at the top of the photo translation page to enter the language selection list and select the required language;

② Tap the screen to focus on the text you want to translate;

③ Tap the Shoot button at the bottom of the screen;

④ Crop the image to keep only the content area that needs to be translated;⑤ After adjusting the area,click the Confirm button to display the translation result.

(This function is optional,please refer to the actual model)

®Simultaneous interpretation

Click the icon in the upper right corner of the simultaneous interpretation page, and the two-dimensional code window will pop up. Use Chrome, PayPal, WeChat and other software to scan the two-dimensional code on the translator, and then receive the translation results on the translator simultaneously.

®Group translation

By using the QR code or ID number on the device, create multi machine groups with other AI translation machine users to achieve cross regional and cross language communication.

0Smart recording

Click the language option at the top of the smart recording page, select the language you want to record and translate, click the microphone button at the bottom of the screen to start recording and translate in real time, press again to end the recording translation, and then choose whether to save this recording.

SChatGPT

Click the icon in the upper right corner of the screen to set the communication language and writing speed;

Click the icon in the bottom right corner of the screen to create a new dialog; Click the icon in the lower left corner of the screen to switch to keyboard input or voice input conversation content, AI voice assistants answer your questions.

Enter translation

Select the language you want to translate and enter the translated content in the text box to translate it. Click the home icon to play the translated content repeatedly.

Phone translation

Using Chrome, PayPal, WeChat and other software to scan the QR code on the translator, you can translate the conversation.

Click the icon in the upper right corner of the translation page of the mobile phone to set the translation language, automatic playback, etc.

Click the icon in the upper right corner of the translation page on the mobile terminal to set the translation language.

Language learning

Click the language option in the upper right corner of the screen, select the language you want to learn, and long press the sound recording key to record, the sound recording key can be accurately translated, click the icon to the right of the translated content to enter the follow through page, press and hold the sound recording key to start the follow through page, the sound recording key will score the follow through, and you can also play the standard sound or recorded follow through content.

EQUIPMENT UPGRADE

The device will be updated from time to time. If your device cannot be updated, the possible reasons are as follows: ① The current version is the latest version, and there is no new upgrade package.

② Check whether the network connection of the device is normal. You can receive the upgrade notification only when the network connection is normal.

③ Do not perform any operation during the system installation. In this way, the system installation may be interrupted and the upgrade may fail. As a result, the system cannot be used normally.

NOTE ON CHARGING AND BATTERY USE ① Before charging, ensure that

the charging port is clean and free of dirt.

② When connecting the charging cable to the charging port, ensure that the charging cable is properly connected. Do not forcibly connect the charging cable.

③ This product does not come with a power adapter. If consumers use a power adapter for power supply, they should purchase a power adapter that is certified and meets the requirements of the standard.

④ If the battery is overheated, discolored, deformed, bulging, or leaking during use, charging, or storage, stop using the battery to avoid safety problems.

⑤ When charging, because the battery temperature will rise, do not put together with flammable materials, so as not to cause fire. Batteries must not be exposed to conditions such as sunlight, fire, or similar overheating.

⑥ Do not disassemble, squeeze, heat or burn the built-in battery of this product, or use sharp objects, screwdrivers, etc. to tie or pry the battery, the above operations will cause the battery fire.

⑦ To reduce the risk of electric shock in children, please charge this product under the guidance of a parent or other guardian.

SAFETY PRECAUTIONS

Do not place the device in an environment where the temperature is too low or too high (below -10°C or above 50°C) for a long period of time. Extreme temperatures may deform the device and shorten the service life of the device.

Do not use the device during thunderstorms; Do not place the device

in water;

Keep the device and all accessories away from children and pets to avoid choking or other serious consequences due to accidental ingestion.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential

installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

