

# **26" ATV / UTV SOUND BAR**

*FEATURES BUILT-IN CLASS A/B AMPLIFIER AND  
MULTICOLOR ILLUMINATION OPTIONS*

**User Guide**

These instructions cover the following part number:

**SK4000 / SK6000 / SK8000**

# INDEX

Information to the User.....	2
Before You Start.....	3
Getting to Know Your Sound Bar .....	4
BT Operation .....	5-6
Streaming Music.....	7
AUX Input.....	8
USB Input.....	9
Remote Control.....	10
Installation.....	11
Troubleshooting .....	12
Wire Diagram / Specifications .....	13

Thank you for purchasing ATV/UTV Sound Bar.

Please read through these instructions carefully so you will know how to operate your model properly.

After you have finished reading the instructions, keep this document in a safe place for future reference.

### **THIS PACKAGE CONTAINS:**

- (1) SOUND BAR All-Terrain Speaker System ----- 
- (2) Mounting Kit ----- 
- (3) Power Accessory Extension Adaptor ----- 
- (4) Remote Control ----- 
- (5) User Manual ----- 

## BEFORE YOU START

### IMPORTANT SAFETY PRECAUTIONS

- Do not operate mobile equipment while driving a motorized vehicle. Safe driving and safety consideration of others should always be your highest priority.
- In the event you should notice smoke, strange noises or odor from this product, or any other abnormal signs, immediately turn off the power. Using this product in this condition may result in permanent damage to the system.
- Set your volume control at a low setting, then slowly increase the sound until you can hear it comfortably without distortion or ear discomfort.

### BE SURE TO OBSERVE THE FOLLOWING GUIDELINES:

- Do not turn up the volume too loud that you can't hear what's around you.
- Use caution or temporarily discontinue use in potentially hazardous situations.

### INSTALLATION PRECAUTIONS

- Servicing of this product by persons without professional training and experience in electronic equipment and motorized vehicle accessories may be dangerous and could expose you to the risk of electric shock, injury or other hazards.
- Contact BULLY customer service for any installation, service questions or requests.
- SOUND BAR can be powered from a vehicle's cigarette lighter auxiliary power port, or hardwired directly to the battery through an optional relay / accessory switch.
- When wiring directly to the vehicle's battery, be sure to disconnect the batteries negative terminal wire before starting any wiring procedures, it is suggested that an optional fuse and fuse holder (not included) with minimum rating of 10 Amps be in line with the positive battery terminal.
- The ground cable length should not exceed 18-inches (see wiring diagram).
- The SOUND BAR has a weather resistant design. It should not be submerged in or under water under any circumstances.
- Use only the installation parts provided with the SOUND BAR.
- Wash with a mild soap or detergent and lukewarm water using a clean sponge or a soft cloth. Rinse well with clean water.


### VERY IMPORTANT

- DON'T clean in hot sun or on very hot days.
- DON'T use abrasive or highly alkaline cleaners on the main body.
- DON'T scrape the main body with razor blades, or other sharp instruments.
- DON'T ever use, gasoline, acetone or carbon tetrachloride.




CAUTION: Using other mounting methods may void this warranty.

## GETTING TO KNOW YOUR SOUND BAR



- ① 3.5mm AUX-INPUT
- ② RCA Output
- ③ USB Jack
- ④ Cigarette Power Cable Adaptor
- ⑤ Led Power Indicator
- ⑥ Control Panel

## BT OPERATION



### PAIRING & DISCOVERING A NEW BT CONNECTION

1. Power on the **SOUND BAR** by plugging in the male cigarette lighter adaptor into **(4)** a female cigarette lighter receptacle.
2. Press the **(9)** button. The **SOUND BAR** will automatically go into pairing mode.

#### ANDROID users:

- a. Go into the **Settings Menu** of your device
- b. Enter the **BT Menu**
- c. **TURN ON BT** and press **SCAN**
- d. **SOUND BAR** will now be displayed under **AVAILABLE DEVICES**
- e. If prompted, enter passcode: **0000**


#### iOS users:

- a. Go into the **Settings Menu** of your device
- b. Enter the **BT Menu**
- c. **TURN ON BT** and press **SCAN**
- d. **SOUND BAR** will now be displayed
- e. If prompted, enter passcode: **0000**

**NOTE:** You have 2 minutes before you must restart this procedure over again.

3. If **SOUND BAR** is not seen, repeat the above steps to refresh the **Device List**
4. When the connection is successful, you are now ready to stream music from your favorite media player to the **SOUND BAR**.

## BT OPERATION




### RECONNECTION

1. Power on the **SOUND BAR** and your last paired BT device.
2. Press the ⑨ button. The unit will now automatically reconnect.
3. If your device was previously paired with the **SOUND BAR**, but it wasn't the last paired device:
  - a. Ensure no other devices are currently paired
  - b. Enter the on your device being paired
  - c. **SOUND BAR** will display under **AVAILABLE DEVICES**
  - d. Choose the **SOUND BAR** to reconnect
4. If the device is out of range from the **SOUND BAR**, it will disconnect automatically:
  - a. The **SOUND BAR** will automatically reconnect to the device once back in range.



**TIPS:** To avoid battery exhaustion, be sure to occasionally run the vehicle's engine while using this product. Using this product without running the engine can drain the battery.

## STREAMING MUSIC



### MULTIFUNCTION CONTROLLER BLUETOOTH OPERATION

1. Press the **12 PLAY/PAUSE** once to start playing music or press the **PLAY** button from your device's touchscreen.
2. To skip songs or advance, press the **11 NEXT TRACK** button.
3. To select the previous song, press the **7 PREVIOUS TRACK** button.


### VOLUME CONTROL

4. To raise the volume, press the **10 VOLUME UP** button or use your device's controls.
5. To lower the volume, press the **8 VOLUME DOWN** button or use your device's controls.



**TIPS:** For maximum audio performance, ensure your device BT volume is set to a minimum 75% level before stowing.

## AUX INPUT




### AUX-IN OPERATION

1. Power on the **SOUND BAR** by plugging in the male cigarette lighter adaptor into (4) a female cigarette lighter receptacle.
2. Press the (9) button. The **SOUND BAR** will automatically go in to **AUX** mode.
3. Connect the integrated 3.5mm **AUX-IN** cable (1) to your device's headphone jack.
4. Route the wire back to **SOUND BAR**, and secure your device.

### VOLUME CONTROL

5. To raise the volume, press the (10) **VOLUME UP** button or use your device's controls.
6. To lower the volume, press the (8) **VOLUME DOWN** button or use your device's controls.

## USB INPUT



### USB IN OPERATION


1. Power on the **SOUND BAR** by plugging in the male cigarette lighter adaptor into **④** a female cigarette lighter receptacle.
2. Press the **⑨** button. The **SOUND BAR** will automatically go into arbitrary pattern.
3. Insert the USB Flash drive on **③** and play the music automatically.
4. Press the **⑫ PLAY/PAUSE** once to start playing music or pause.
5. To skip songs or advance, press the **⑪ NEXT TRACK** button.
6. To select the previous song, press the **⑦ PREVIOUS TRACK** button.
7. To raise the volume, press the **⑩ VOLUME UP** button or use your device's controls.
8. To lower the volume, press the **⑧ VOLUME DOWN** button or use your device's controls.



**TIPS:** USB can play music formats MP3 and WMA.  
USB can provide 1A current.

## REMOTE CONTROL

### GETTING TO KNOW YOUR REMOTE




- ① RGB Remote
- ② Power On / Off
- ③ Mode Up
- ④ Auto Demo
- ⑤ Speed Up
- ⑥ Brightness Up
- ⑦ Brightness Down
- ⑧ Mode Down
- ⑨ Color Down
- ⑩ Color Up
- ⑪ Speed Down

- 1) RF controller range: Up to 25ft (LoS)
- 2) Do not obstruct the RF remote with metal
- 3) Always keep away from small children
- 4) Do not store in direct sunlight

## INSTALLATION


- Use the supplied adjustable bracket to secure to rails.
- Always recheck bracket before every ride.




## TROUBLESHOOTING

TROUBLE	CAUSE	SOLUTION
Unit will not turn on	The fuse is blown	Check / replace the fuse
	Main acc switch not engaged	Turn switch to on position
No sound is heard	Device volume is low / muted	Turn the volume level up
	Device is paused or muted	Check your devices playing / volume status
Cannot pair Bluetooth	The Bluetooth function of the device is not enabled	Refer to the user manual of the device for how to enable the Bluetooth function
The audio quality is poor after connection with a Bluetooth enabled device	The Bluetooth reception is poor	Move the device closer to the audio system or remove any obstacle between the device
Unit has become unresponsive	Power glitch or interference	Disconnect power for 10 seconds to reset

## DIMENSIONS



## WIRE DIAGRAM



## SPECIFICATIONS

**BT**  
Version: 5.0w/ EDR  
A2DP  
Range: 33ft (10m)

**AMPLIFIER**  
Frequency Response: 40Hz-22kHz

**GENERAL**  
Operational power: 12VDC(10-16V allowable)  
MAX Current Draw: 8A  
Replacement Fuse: 10A AGC TYPE  
Color: Black

SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

**FCC Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

**RF Exposure Statement**

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

**Your complete satisfaction is our number one goal.**

Your satisfaction is why we're in business. If for any reason your experience with our product was anything less than satisfactory, please reach out to us. We'd love to have the opportunity to provide the product experience and service you deserve.

**Votre entière satisfaction constitue notre objectif principal.**

Nous sommes en affaires pour assurer votre satisfaction. Si jamais, pour quelque raison que ce soit, votre expérience avec un de nos produits ne s'avère pas entièrement satisfaisante, n'hésitez pas à communiquer avec nous. Nous ne demandons pas mieux que d'avoir l'occasion de vous procurer l'expérience et le service auxquels vous avez droit.

**Su completa satisfacción es nuestra meta número uno.**

Su satisfacción es la razón por la que estamos en el negocio, si por alguna razón su experiencia con nuestro producto no fue satisfactoria, comuníquese con nosotros, nos encantaría tener la oportunidad de brindarle la experiencia y el servicio que usted se merece.