

Cappsu




Music Player Quick Guide

Product Parameters

Display: TFT display
USB specification: Support USB2.0, USB3.0
Memory: 8GB
TF card slot: support 4GB-128GB
Music format: MP3, WMA, WAV, APE, FLAC, OGG
Recording format: WAV, MP3
Image format: JPEG, BMP, GIF JPEG, BMP, GIF
Video format: AVI, AMV AVI, AMV
Headphone specification: 3.5 mm

Operation buttons introduction



Basic Operation

1. Power on/off operation, press and hold the >|| key on the front of the product for about 3 seconds, it can be turned off or on.
2. Bluetooth connection operation, turn on the Bluetooth function of the Bluetooth device you want to connect, enter the menu and press the >|| key to enter the Bluetooth function and turn on the Bluetooth switch. Select search device, see your device name in the list, select connect. After connecting successfully, you can manage your Bluetooth device in the device list.

3. volume control, when playing music, video or FM, you can press VOL+ or VOL- to adjust the volume, or rotate the INTELLIGENT key to adjust the volume.
4. music playback, after powering on the device, enter the menu and select music application press >|| key to enter, select all songs, select the song you want and press >|| key to play it
5. Music file transfer, use USB cable to connect this product to your computer, you can see the storage disk on your computer. You can directly copy the desired music files to the storage disk without any third party program.

Recording Operation

1. start recording, enter the menu and press >|| key to enter the recording function, select start recording, the machine starts recording, press M key to exit the recording process and select save recording
2. recording settings, enter the menu and press >|| key to enter the recording function, select recording settings, you can set the recording bit rate, recording format, recording scene, voice-activated recording, monitor recording and so on.

Music Playback Settings

1. Loop Mode Setting, during playback, long press >|| key to enter Setting menu, enter Loop Mode Setting, you can set Sequence Play, Random Play, Single Play, Repeat All.
2. Equalizer setting, during playback, long press >|| key to enter setting menu, enter equalizer, you can choose Off, Rock, Funk, Hip Hop, Jazz, Classical, Electronic, Custom.
3. variable speed playback setting, long press >|| key to enter setting menu during playback, enter variable speed playback setting, you can set +8 to -8.
4. delayed shutdown setting, during playback, press the >|| key twice quickly to return to the playback menu, enter the acceptance shutdown, and you can set the timer shutdown.
5. A-B Repeat Setting, during playback, press the side A-B key to set the starting point, but when the playback reaches the end point to be set, press the A-B key again to set the end point.

Attention

1. Do not use it in extremely hot, cold or humid environments.
2. To avoid errors, do not upload or download files while it is being formatted.
3. If you use it as a removable hard disk, please backup your files to avoid losing your files.
4. Please do not disassemble the product by yourself.
5. Please turn off the power of the product when inserting or removing the TF card.

Translated with [DeepL.com](https://www.DeepL.com) (free version)

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.