


Thank you for choosing FOCUS V. For your consideration,
please use the QR Codes below to view our line of
products and accessories.



FOCUS V

CARTA
SPORT

User Manual



CARTA SPORT

Your new CARTA SPORT is designed for effortless sessions wherever life takes you. With one-button simplicity, Bluetooth connectivity, and support for all INTELLI-CORE® atomizers, this sleek device delivers power and convenience. The innovative CARTA CONNECT removable airpath ensures easy cleaning and endless possibilities. Plus, every session earns you V REWARDS points to level up your experience. Join the #FocusFam and share your journey with the community—we can't wait to see where your CARTA SPORT takes you!

FOCUS V

START UP	1
THE APP	3
TIME AND TEMP SETTING	5
PRESETS	7
SESSION START	9
BATTERY CARE	11
CLEANING	13
TIPS AND TRICKS	17
SAFETY INFO	19
WARRANTY	21

START UP

Turning On Your CARTA SPORT:

Press the V button five times to power on. The device will display a startup LED animation.

Turning Off Your CARTA SPORT:

Press the V button five times to shut down your device.

Standby/Auto Off:

After 5 minutes of no use: LEDs turn off, entering standby mode.
Press any button to exit standby mode.
By default, the device automatically turns off after 10 minutes of inactivity.



CONNECTING TO APP

To connect your device to your smartphone via Bluetooth:

Download the App: Scan the provided code or search for FOCUS V app to install on your device.

Turn On CARTA SPORT: Power up your device.

Enable Bluetooth: Ensure Bluetooth is activated on your phone.

Launch & Connect: Open the FOCUS V app, which will automatically search for available devices and prompt you to select one. The default device name is "CARTA SPORT".


Confirmation: Both the app and device will indicate a successful connection.

Take Control: You can now use the app to customize and manage your CARTA SPORT.

Available on:



Earn Points, get new device features, exclusive rewards, deals, and more!



CONNECT AIRPATH

CONNECT is a fully removable airpath built for easy cleaning, precise reclaim management, and flexibility. Made from 100% silicone and designed for hassle-free maintenance and seamless compatibility, CONNECT's built-in channels make reclaim problems a thing of the past, while allowing for unprecedented compatibility with glass tops.



Removal:
Uninstall the glass top and atomizer before removal. Carefully pull the front of CONNECT out first, then pull firmly from the center to remove completely.

Installation:
Remove atomizer and glass top before installation. Align the airpath with the base and gently snap the rear section into position first, then push the front down ensuring proper fitment. Careful not to tear the silicone. Reinstall the atomizer and then the glass top to complete the setup.

LED AND SESH PRESETS

Adjusting Sesh Presets

Press the V button once to display the color of your current preset. Press it again to switch to the next preset.

Adjusting LED Presets

Your Focus V CARTA SPORT has five LED presets available to select from.

Press the V button three times rapidly to cycle through your saved LED animations.

Customize your SESH and LED presets with the FOCUS V app.



Concentrate
365°F - 635°F
20s - 120s

Herb
275°F - 500°F
120s - 240s



Concentrate Presets:

- 1: **BLUE** 480F, 60s
- 2: **YELLOW** 495F, 55s
- 3: **GREEN** 515F, 50s
- 4: **PURPLE** 535F, 45s
- 5: **RED** 565F, 40s

Herb Presets:

- 1: **BLUE** 340F, 240s
- 2: **YELLOW** 350F, 240s
- 3: **GREEN** 370F, 240s
- 4: **PURPLE** 390F, 240s
- 5: **RED** 410F, 240s

START YOUR SESSION

After powering on CARTA SPORT and configuring your session settings, double-tap the V button to start your session. Your CARTA SPORT will vibrate, and the LED indicators will signal the session has started.

Upon reaching the chosen temperature, the device will vibrate again, signaling the start of your session's countdown.

NOTE:

During the session sequence, you can double-tap the V button to extend the session by 10 seconds.

To cancel your session, press the V button once at anytime during the countdown sequence.

V BUTTON FUNCTION:

- 1 click = Cycle temp. presets
- 2 clicks = Start/extend sesh
- 3 clicks = Cycle LED presets
- 4 clicks = Check battery level
- 5 clicks = Power ON/OFF



BATTERY AND CHARGING

SPECS:

Li-ion Polymer Battery
2720mAh - 7.4V

Charging current should not exceed 5V/2A.
Only use approved AC/DC adapter.

- Avoid direct sunlight, heat, or fire.
- Do not remove, disassemble, or modify the battery.
- Avoid excessive physical shock or vibration.
- Do not immerse in water.
- Keep in a cool, dry, and well-ventilated environment.
- Only use the approved, appropriate power source.
- Do not charge the battery for more than 4 hours.
- The battery should be charged within proper temperature, current, and voltage ranges specified.
- Please follow local regulations for proper disposal of batteries.



Battery level
indicator:

GREEN $\geq 75\%$

BLUE $\geq 50\%$

YELLOW $\geq 25\%$

RED $\geq 10\%$

NOTE: ALWAYS FULLY
CHARGE THE DEVICE BEFORE
USING FOR THE FIRST TIME



USB
TYPE C




LITHIUM
POWER

CLEANING

MAKE SURE THE ATOMIZER IS COOL AND SAFE TO TOUCH BEFORE HANDLING

Regular cleaning and maintenance are essential for the optimal performance and longevity of your FOCUS V CARTA SPORT. After every dab, make sure to swab away excess material. This will minimize the need for frequent deep cleaning, as outlined below.

Scan the QR code to view our video guide.



Cleaning Part 1: Glass Tops

Ensure your Focus V CARTA SPORT is powered off before starting the cleaning process.

Gently remove the glass top from its base.

Empty any leftover water, then give it a gentle rinse with warm water.

Fill the glass top with 70% Isopropyl Alcohol.

Securely cover the openings with the included stopper or your fingers, ensuring no spillage.

Shake the glass with vigor, allowing the alcohol to dissolve residues or stains.

Empty the alcohol, give the glass top a thorough rinse with water, and dry it. Once dry, you can reattach it to the device.

Cleaning Part 2: Airpath and Base

Start by removing the glass top and atomizer. Carefully remove CONNECT airpath.

Dampen a lint-free wipe with 70% Isopropyl Alcohol, and gently clean any visible residues from the base. Quickly dry the base immediately after wiping, avoiding prolonged liquid contact.

Pay special attention to the atomizer contacts and airpath. A cotton swab dipped in alcohol works best for these areas. Be gentle around the buttons and the entirety of the base. Finish by wiping down with a dry lint-free cloth.

Cleaning the CONNECT Airpath

Remove the glass top and atomizer, then detach the CONNECT airpath from the base. Use isopropyl alcohol to thoroughly clean the airpath, focusing on the reclaim channels. A cotton swab or small brush can help remove buildup in the channels. Rinse with warm water and allow the airpath to fully dry before reassembly. Ensure all parts are clean and dry, then snap the airpath back into position above the base. Reattach the atomizer and glass top.

Cleaning Part 3: Atomizer

Before you begin, ensure you have 70% Isopropyl Alcohol on hand.

Initiate by gently cleaning the threads of your FOCUS V **CARTA SPORT's** atomizer using a cotton swab moistened with the 70% Isopropyl Alcohol.

Detach all silicone parts from the atomizer. Delicately swab the inside of the atomizer chamber with 70% Isopropyl Alcohol.

Submerge only the atomizer in the 70% Isopropyl Alcohol and allow to soak for 5 minutes. Gentle agitation can help in thorough cleaning.

After soaking, remove the atomizer and allow it to air-dry completely. Inspect closely; if residues persist, consider repeating the process.

Once completely dry and cleaned, reassemble your atomizer. Ensure all components are secure and pristine. For best results, run a brief, low-temperature session before regular use.

TIPS & TRICKS

Loading:

- The recommended loading size is 0.1 to 0.3g to avoid overfilling. If you want to vaporize more, we recommend running multiple sessions.
- Avoid loading material on sides or near top of chamber. Use the FOCUS V SABER Electronic Dab tool to ensure proper loading and minimal waste.

Inhaling:

- Slow, smooth pulls provide the most consistent vapor production.
- If your feeling restricted airflow, make sure the atomizer is clean, the glass top is aligned properly and the carb cap is clear from obstructions.
- If you want to modulate airflow, you can do so by slightly covering your carb cap opening.
- Adjust your timer settings to properly match the length of your hit and not more. This saves battery life and prevents overheating.

Personalize:

- Use the App to customize sesh and LED presets to configure your device the way you like it.
- Explore custom accessories from focusv.com and the community to further personalize your experience.

Clean Up:

- Keep your chamber clean by using a swab to absorb leftover residue after every session.
- Warm 70% Isopropyl Alcohol works better at dissolving residue.
- Check your atomizer contacts and airpath regularly.
- Never use any abrasives or highly caustic cleaners on your device.

Battery Care:

- Make sure the device is off when not in use.
- Keeping the battery from discharging below 60% will prolong the lifespan of the cells.
- Do not charge longer than is needed.
- Only use an approved USB power source.

IMPORTANT SAFETY INFORMATION

Use at your own risk.

Always insert your glass top at an angle. (Inserting it flat can result in your **CARTA SPORT**'s base cracking)

Do not overfill the glass top with water.

Do not blow air into the glass top when it is filled with water and attached to your **CARTA SPORT**'s base.

Do not overload the wax chamber. Overflow of concentrate can cause spill over to the atomizer, damaging heating element.

To avoid damage, please keep the interior of your atomizer cleaned and properly maintained.

Allow the chamber adequate time to cool before touching it.

Never touch your atomizer while it is in use.

Do not overcharge your battery/device. Never use a damaged battery/device.

Never leave the device charging unattended.

Never expose your batteries/device to extreme temperatures

Do not expose batteries/device to liquids.

Always charge batteries/device on a fireproof surface.

Immediately stop use if the batteries produce an unusual odor, emit heat, smoke, change in color or shape, or appear irregular in any way.

Keep away from pets and/or children.

WARRANTY

CARTA SPORT Base: 1 Year
INTELLI-CORE Atomizer: 6 Months

All claims must be made through FOCUS V Customer Support.

Focus V warrants this device against any defects in materials used to produce this product for a period of one year, from the retail purchase date. This warranty can only be used by the original end-user. If a claim is received and determined to be valid, Focus V will either repair the product defect or exchange the product. The Limited Warranty Period begins on the original purchase date. A claim under this warranty is only eligible if it is made within the claim period.

Defective products must be returned and received by our warehouse within 30-days of the original delivery. Customers will be responsible to pay for shipping defective products after the 30-day period. We will pay for shipping on all domestic replacement orders to the customers.

*If the product passes inspection upon arrival the customer is entitled to pay for return shipping.

This Limited Warranty will NOT apply under the following circumstances:

- If damage is cosmetic, including scratches, dings and use of chemicals on the base, or if issue is caused by normal wear and tear. (For example, Limited Warranty does not cover the standard degradation of atomizers or batteries.)
- Where customer's failure to properly maintain the Product is cause of issues. Customers should note that atomizers are replaceable parts with an expected life of 3 – 6 months, and they require regular cleaning and maintenance.
- If Focus V determines that the Product has been improperly used, altered or tampered with in any way. Customer assumes the responsibility to follow instructions provided in user's manual. Examples of misuse include: Using incorrect charging hardware, Overcharging the unit, Overfilling the unit, Disassembling the base, Subjecting to extreme conditions, etc.
- If the customer misrepresents their information, alters or removes the product's serial number, or submits a fraudulent warranty claim.
- For any Focus V Products that are resold by the customer or that are purchased from unauthorized resellers.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.