

Projector



※User Manual※



Attention

Please read this manual carefully before use and keep it for future reference.


- 1.The projector is non dustproof or waterproof.
- 2.In order to reduce the risk of fire and electric shock, do not expose the projector to rain and fog.
- 3.Please use the original power adapter. The projector should work under specified rated power supply.
- 4.When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain. Children should use the projector under the supervision of adults.
- 5.Do not cover the vents of projector. Heating will reduce the life of projector and cause danger.
- 6.Regularly clean projector vents, or dust may cause cooling malfunction.
- 7.Do not use the projector in greasy, damp, dusty or smoky environment. Oil or chemicals will cause malfunction.
- 8.Please handle with care during daily use.
- 9.Please cut off the power if the projector is out of use for long time.
- 10.Non-professionals are forbidden to disassemble the projector for testing and maintenance.

Structure Description

This manual is for reference only. It is subject to change without prior notice. Hotack reserves the right of final interpretation.




Remote Component and Functions



Power ON/OFF

Power On
Long press Power button on projector for 3 seconds.
Power Off
When the projector is power-on, press and hold the power button on the projector or the remote control for 3s to power off.




Focus Adjustment

When projector is on, adjust sharpness by focus wheel on the back of projector.




Launcher Ui




Wi-Fi

Wifi Setting > To choose the network and type the password that you want to connect to.




About this machine

Setting-Device Preferences>About.Local machine information can be viewed




Application

Hone page-ly Apps.All installed appscan be viewed.



OSD Language

Setting-Device Preferences-LanguageTo choose your language Langusg




Home Background

Hone page-Projector Setting-WallpapersChoose the Home Background you want.




Projector Mode

Home page-Projector Setting-Keystone Adjust-Projection ode > To select different mode according to your application scenario. Four modes are available < Front Table, Front Ceiling, Back Table, Back Ceiling >.




Factory Restore

Setting-Device Preferences-Reset > To reset system. he user data will be cleared.




Trapezoid

Home page-Projector Setting-Keystone Adjust-Trapezoid>You can adjust the four points of the pictureseparately to ensure that the picture achieves the




Media Player

Insert the U disk and click the USB icon on the homepage to read the local video & music & photo & Book.



HDMI Signal

Connect projector and external sourcing device by HDMI cable. Enter HDMI on the homepage, the signal from the sourcing device will be transmitted to projector and cast out.



01 Turn on the TV screen casting function




Open Zeasn cast TV version on TV;

02 Connect to screencast




Method 1. Connect your phone and TV to the same Wi-Fi, search for and connect to the name displayed by Zeasn cast on the TV;



Method 2. Scan the code to connect, scan the QR code displayed by Zeasn cast on the TV side of the mobile phone to complete the connection;

03 Use screencast



After the connection is established, the screen of the mobile phone can be mirrored to the TV in real time. At this time, open other applications, you can cast the screen to play mobile games, video chat to the screen, cast mobile phone files, cast the screen to any mobile interface such as fitness, preschool education, etc.;

【Safety instructions】

• Please pay attention to important information related to the operation and maintenance of the projector. You should read this information carefully to avoid problems. Following safety instructions will increase the life of projector.

• Please consult the qualified personnel for installation and repair services, and do not use damaged wires, accessories and other peripherals.

• Projector should be kept away from flammable, explosive, strong electromagnetic interference (large radar stations, power stations, substations) ,etc. Strong ambient light (avoid direct sunlight), etc.

• Do not cover projector vents.

• Please use the original power adapter.

• Keep adequate ventilation and make sure vents are not covered to avoid projector overheating.

• When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain.

• Do not bend or drag the power cord.

• Do not put power cord under projector or any heavy objects.

• Do not cover other soft materials on power cord.

• Do not heat the power cord.

• Avoid touching power adaptor with wet hands.

【Disclaim】

This manual is general instructions, The pictures and functions in this manual should subject to the actual product. Our company is devoting to improve product performance, we reserve the right to modify product functions and interface described in this manual without notice.

Please keep your device properly.We are not responsible for any loss caused by wrong operation of software/hardware or repairing or any other reasons. We are not responsible for any loss of any third party claims.

This manual has been carefully checked by professional engineer, please understand for any inevitable omissions.



Attention:

Please do not look directly into the lens when projecting to prevent the strong light doing harm to your eyes. Kids should use the projector under the supervision of adults.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for Compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help important announcement .

Radiation Exposure Statement

To comply with FCC RF exposure compliance requirements, this grant is applicable to only mobile configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.