

English

OWS User's manua



V5.3
Stereo music headphones

Safety guidelines:

1. Do not disassemble or modify the device for any reason, otherwise the headset may malfunction or burn out.
2. Do not let the device come into contact with liquid, otherwise it will cause serious damage to the device.
3. Do not place the device in an environment where the temperature is too low or too high (below 0°C or above 45°C).
4. Do not use the device in thunderstorm weather. Thunderstorms can cause the device to work abnormally and interrupt signals.
5. Do not use mobile power to charge, otherwise the earphone may malfunction or burn out. Do not use a charger above 1A for charging, otherwise the earphone may malfunction or burn out. [The above 6 points of damage are not covered by the warranty, please know]

Start using:

Hold down the multifunctional touch on the surface of the headset for up to 5 seconds (See the product schematic diagram mark for details) Until the indicator light shows the blue and red light flashing alternately Then open the phone search [mini] to connect the device Press the touch button for 5 seconds Let go until the indicator light appears blue, red and red light flashing alternately



【 Function Operation instruction 】

Monaural specification

Power on: Touch the power button for 3 seconds
Shutdown: Touch the shutdown button for 5 seconds
Unnumbered redial: Continuously touch the power button three times (when the phone is connected)
Next: continuously touch the power button twice
Play/Pause: Touch the power button once
Answer/Hang up: Touch the power button once
Reject an incoming call: Touch the power button for 2 seconds
Siri / Voice Assistant: Touch the power button for 2 seconds
Earphone factory default English prompt tone, if you need to switch Chinese
(When the headset is not connected, touch the headset power button for 5 times continuously)

【 Light flashing indicator 】

Startup state: red and blue lights alternately flash
Shutdown status: The red light blinks three times
Waiting for pairing: the red and blue lights flash alternately
Matching success: Red and blue lights off
Charging: The red light is always on
Fully charged: Blue light is always on
Boot search mode: the red and blue lights flash alternately

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.