


三脚架自拍杆



使用说明

产品指示说明



蓝牙遥控电池更换

注: 不支持连续拍摄功能



遥控器操作说明

1. 长按遥控器按键开机, LED指示灯闪烁等待配对;
2. 打开手机蓝牙搜索蓝牙名, 配对成功后遥控器LED灯灭;
3. 遥控键开机后如果5分钟无手机配对, 会自动关机;
4. 配对成功后, 如果10分钟无操作拍摄, 遥控器将进入休眠模式, 点击按键可以唤醒自动拍摄, 休眠模式下10分钟无唤醒将自动关机;
5. 长按遥控器按键关机, LED快速闪烁后关机灯灭。

产品参数

主材质	不锈钢
手机夹子尺寸	2.9-4.5英寸
产品收缩长度	185mm
产品伸展长度	690mm
产品尺寸	46x36x185mm
电池	CR1632(可替换)

温馨提示:

本产品使用遥控器操作替代原来在手机点击拍摄方式, 适配iOS与安卓系统。(安卓系统需在手机相机设置里设置音量键为拍照功能, 以确保本产品使用正常。苹果系统无需设置, 连接蓝牙即可正常使用。)




中国制造/Made in China

SELFIE STICK INTEGRATED TRIPOD



INSTRUCTIONS

Product instructions



Bluetooth remote battery replacement

Note: Continuous shooting is not supported



Remote control instructions

1. Long press the remote button to power on, LED indicator will blink.
2. Search and pair with bluetooth name on your cellphone.
3. The remote control will automatically shut down in 5 mins if not paired.
4. The remote control will automatically sleep in 10 mins without any operation, and auto shut down after another 10 mins if not awoken.
5. Long press the remote button to power off, LED indicator flashes 3 times, then shut down.

Product parameters

Main Material	stainless steel
mount holder	2.9-4.5"
Retracted length	185mm
Extended length	690mm
Product size	46x36x185mm
Battery	CR1632(replaceable)

Reminder:

The Wireless selfie stick tripod uses remote control to take photos instead of clicking on your cellphone camera app, compatible with Android and iOS smart phones (for Android phones only set your volume Key function as capture in camera app setting for the selfie stick to work properly)




中国制造/Made in China

三脚架带灯自拍杆



使用说明

产品指示说明



蓝牙遥控电池更换

注: 不支持连续拍摄功能



遥控器操作说明

1. 长按遥控器按键开机, LED指示灯闪烁等待配对;
2. 打开手机蓝牙搜索蓝牙名, 配对成功后遥控器LED灯灭;
3. 遥控键开机后如果5分钟无手机配对, 会自动关机;
4. 配对成功后, 如果10分钟无操作拍摄, 遥控器将进入休眠模式, 点击按键可以唤醒自动拍摄, 休眠模式下10分钟无唤醒将自动关机;
5. 长按遥控器按键关机, LED快速闪烁后关机灯灭。

产品参数

主材质	不锈钢
手机夹子尺寸	2.9-4.5英寸
产品收缩长度	185mm
产品伸展长度	690mm
产品尺寸	46x36x185mm
电池	CR1632(可替换)

温馨提示:

本产品使用遥控器操作替代原来在手机点击拍摄方式, 适配iOS与安卓系统。(安卓系统需在手机相机设置里设置音量键为拍照功能, 以确保本产品使用正常。苹果系统无需设置, 连接蓝牙即可正常使用。)




中国制造/Made in China

SELFIE STICK INTEGRATED TRIPOD



INSTRUCTIONS

Product instructions



Bluetooth remote battery replacement

Note: Continuous shooting is not supported



Remote control instructions

1. Long press the remote button to power on, LED indicator will blink.
2. Search and pair with bluetooth name on your cellphone.
3. The remote control will automatically shut down in 5 mins if not paired.
4. The remote control will automatically sleep in 10 mins without any operation, and auto shut down after another 10 mins if not awoken.
5. Long press the remote button to power off, LED indicator flashes 3 times, then shut down.

Product parameters

Main Material	stainless steel
mount holder	2.9-4.5"
Retracted length	185mm
Extended length	690mm
Product size	46x36x185mm
Battery	CR1632(replaceable)

Reminder:

The Wireless selfie stick tripod uses remote control to take photos instead of clicking on your cellphone camera app, compatible with Android and iOS smart phones (for Android phones only set your volume Key function as capture in camera app setting for the selfie stick to work properly)



中国制造/Made in China

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.