

Important Safety Information:

1. Avoid operating the device near heating elements.
2. Do not bend the blade or pins of plug.
3. If there is any strange sound, smoke or odor, unplug immediately.
4. Do not disassemble (It may cause fire or electric shock).
5. Do not insert any sharp objects into the venting hole of the product (it may cause fire or electric shock).
6. Ensure adapter is plugged in fully and securely.
7. Keep clean the power plug and the outlet(Dirt may cause a short circuit and fire).
8. Keep the product out of reach of children.
9. Do not operate the adapter with wet hand. (It may cause electric shock)
10. Switching Power Adaptor intended for use with Information technology equipment.
11. The appliance is suitable for Non-tropical climate only.
12. The maximum ambient temperature during use of the appliance must not exceed 25 degree C.
13. The ventilation must not be impaired by covering the appliance with items such as newspapers, table cloths, curtains, etc.
14. Naked flame sources, such as candles, must not be placed on the appliance.
15. The appliance and the mains-socket must all times be easily accessible.
16. Device USES a maximum altitude of 2000 meters.
17. The appliance does not require much attention. If you want to clean it, please use only dry cloths or a brush.
18. The product cannot charge the battery.
19. This product cannot be used as a travel charger.
20. Indoor use only.



FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation

This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Informations de sécurité importantes :

1. Évitez d'utiliser l'appareil à proximité d'éléments chauffants.
2. Ne pliez pas la lame ou les broches de la fiche.
3. S'il y a un son, de la fumée ou une odeur étrange, débranchez immédiatement.
4. Ne pas démonter (cela peut provoquer un incendie ou un choc électrique).
5. N'insérez aucun objet pointu dans le trou d'aération du produit (cela pourrait provoquer un incendie ou un choc électrique).
6. Assurez-vous que l'adaptateur est complètement et solidement branché.
7. Gardez propres la fiche d'alimentation et la prise (la saleté peut provoquer un court-circuit et un incendie).
8. Gardez le produit hors de portée des enfants.
9. N'utilisez pas l'adaptateur avec les mains mouillées. (Cela peut provoquer un choc électrique)
10. Adaptateur d'alimentation à découpage destiné à être utilisé avec un équipement informatique.
11. L'appareil convient uniquement aux climats non tropicaux.
12. La température ambiante maximale pendant l'utilisation de l'appareil ne doit pas dépasser 25 degré C.
13. La ventilation ne doit pas être entravée en recouvrant l'appareil avec des objets tels que des journaux, des nappes, des rideaux, etc.
14. Les sources de flammes nues, telles que les bougies, ne doivent pas être placées sur l'appareil.
15. L'appareil et la prise de courant doivent toujours être facilement accessibles.
16. L'appareil UTILISE une altitude maximale de 2000 mètres.
17. L'appareil ne nécessite pas beaucoup d'attention. Si vous souhaitez le nettoyer, veuillez utiliser uniquement des chiffons secs ou une brosse.
18. Le produit ne peut pas charger la batterie.
19. Ce produit ne peut pas être utilisé comme chargeur de voyage

20. Utilisation en intérieur uniquement.

