

CONTACT US

Email | support@aurizen.com

Phone | +1-867-218-4830 (Mon-Fri, 9:00 to 17:00 EST)

*If you need assistance outside these hours, please email us for assistance.

Aurizen

Google TV

Hey Google

EAZZE D1 MAX

USER MANUAL

ENGLISH

Tutorial Videos

CONTENTS	
Troubleshooting Guide	01
Read Before Use	02
In The Box	03
Product Overview	03
Projector	03
Remote Control	04
Quick Start	05
1. Projector Installation	05
2. Power On/Off	06
3. Remote Control Pairing	06
4. Setup Wizard	07
5. Image Adjustment	07
Projector Connection And Input Source	11
WiFi Connection	12
Google Assistant	12
Google Cast™	12
BT Speaker Mode	14
More Settings	14
Projection Distance And Size	15
Specification	16

ENGLISH

01-19

IN THE BOX

PROJECTOR OVERVIEW

IR Receiver

Adjustment Sensor

Keypad

Lens

OK

Back

Up

Power Button

Left

Down

Right

Remote Control

1 Power: Press to power on/switch to standby mode/wake up/press and hold for 3s to power off

2 Google Assistant: Press and hold and talk

3 User Profile: Press to see profile page

4 OK: Confirm a selection/pause/resume

5 Back: Return to previous page

6 Focus Adjustment: Press to adjust focus

7 Mute

8 Streaming Apps: Direct access to streaming apps

9 Indicator Light

10 Input Source: Press to choose from input sources

11 Settings: Press to access dashboard

12 Navigation: Control cursor on the screen

13 HD Quick Switch: Press to switch directly to the HD input signal

14 Home: Access homepage

Volume +/-

* Please install 2 AAA batteries (not included) into the remote control before use.

QUICK START

1. Projector Installation

Notes:

Go to **Homepage** > **Dashboard** > **All settings** > **Projector** > **Advanced Settings** > **Projection Mode** to select the corresponding projection mode, so images can be projected correctly.

Mounting Screw, M5 x 4 (not included)

2. Power On/Off

Notes:

When the projector is on, press the power button once to put it into standby mode, press it again to wake it up.

Please use the power adapter provided in the box to prevent product damage.

3. Remote Control Pairing

Turn on the projector, and wait for the pairing prompt on the screen, bring the remote control within 330 ft (100 m) of the projector, then simultaneously press and hold the **OK** and **Home** buttons. Wait for the pairing to complete.

Remote Indicator Light Status

Not paired: Single red flash after button press

Pairing: Flashing blue

Paired: Single blue flash after button press

4. Setup Wizard

Follow the visual guide to choose your preferred language, select your region, and sign in with your Google Account or use the basic TV mode.

5. Image Adjustment

Tip: For optimal automatic image adjustment and correction, place the projector with no more than a 20° tilt vertically or horizontally toward the screen or wall.

Focus

1. Auto Focus: The projector automatically adjusts focus when moved to maintain a clear image. You can also trigger auto focus by going to **Homepage** > **Dashboard** > **All settings** > **Projector** > **Focus** > **Auto Focus**.

Keystone Correction

1. Auto Keystone Correction: The projector automatically corrects the keystone distortion when moved to maintain a rectangular image. You can also trigger auto keystone correction by going to **Homepage** > **Dashboard** > **All settings** > **Projector** > **Keystone Correction** > **Auto Keystone Correction**.

2. Manual Keystone Correction: Go to **Homepage** > **Dashboard** > **All settings** > **Projector** > **Keystone Correction** > **Manual Keystone Correction** to manually correct the image shape by four points.

Intelligent Screen Fit

Go to **Homepage** > **Dashboard** > **All settings** > **Projector** > **Advanced Settings** > **Fit to Screen** to enable the projector to adjust the projected image to fit the screen.

Intelligent Obstacle Avoidance

Go to **Homepage** > **Dashboard** > **All settings** > **Projector** > **Advanced Settings** > **Avoid Obstacles** to enable the function. The projector will automatically adjust the projected image to avoid any objects on the projection surface during the correction process.

Image Size & Position

Go to **Homepage** > **Dashboard** > **All settings** > **Projector** > **Keystone Correction** > **Image Adjustment** to adjust the image size and image position.

PROJECTOR CONNECTION AND INPUT SOURCE

Connect your device to the projector correctly, then select the right input source.

WiFi CONNECTION

Connect your projector to your router's WiFi by going to **Homepage** > **Dashboard** > **All settings** > **Network** > **Internet**.

GOOGLE ASSISTANT

Your TV is more helpful than ever. Use your voice to find movies, streaming apps, play music and control the TV. Ask Google Assistant to find a specific title, search by genre, or get personalized recommendations. Even get answers on screen, control smart home devices, and more. Press the Google Assistant button on the remote to get started.

GOOGLE CAST™

Google Cast is a platform that lets you stream your favorite entertainment from your phone, tablet or laptop right to your projector. Easily control your TV with apps you already know and love from your iPhone®, iPad®, Android™ phone or tablet, Mac®, Windows® laptop, or Chromebook.

To use Google Cast, please ensure you are using a Google Cast-enabled app and follow the instructions below.

1. Connect your device and the projector to the same wireless network.

2. Open the streaming app on your device.

3. Tap a video and tap the casting icon.

4. Select EAZZE D1 MAX to connect. The projector will display the video from your device.

BT

Note: Due to copyright restrictions, certain content from streaming apps cannot be cast to the projector via Google Cast, iOS screen mirroring or Android screen mirroring. To stream this content, install the same apps directly from the **Apps** tab on the projector.

* Screen Mirroring Using the Google Home App (Only for Android Devices): You can mirror your entire Android device screen onto the projector screen.

1. Ensure that you have installed the Google Home app on your device.

2. Ensure that both your device and the projector are connected to the same wireless network.

3. Open the Google Home app and go to the **Device** tab. Find and select EAZZE D1 MAX as the name of your projector. If you have renamed it.

4. On the device page, tap **Cast my screen** and confirm when prompted. Your device's screen will be mirrored on the projector screen.

* Screen Mirroring Using the AirScreen App: You can mirror the entire screen from your iOS/Android device onto the projector screen.

1. Ensure that both your device and the projector are connected to the same wireless network.

2. Search and install AirScreen on the **Apps** tab - AirPlay is available on your projector.

3. Open AirScreen app and follow the on-screen instructions to complete the process.

Tip: Feel free to search for and install other screen mirroring apps as needed.

Note: Due to copyright restrictions, certain content from streaming apps cannot be cast to the projector via Google Cast, iOS screen mirroring or Android screen mirroring. To stream this content, install the same apps directly from the **Apps** tab on the projector.

BT SPEAKER MODE

This projector can function as a BT speaker by connecting your mobile device to it through a BT connection.

Step 1: Go to **Homepage** > **Dashboard** > **All settings** > **Projector** > **BT Speaker Mode** to make the projector ready for a BT connection.

Step 2: Access your mobile devices BT settings and activate BT. Search for EAZZE D1 MAX in the available devices list to use your mobile device with the projector.

Tip: To exit the BT Speaker Mode, simply press the **Back** button on the remote control for 2 seconds.

MORE SETTINGS

1. Factory Mode: Go to **Homepage** > **Dashboard** > **All settings** > **Display & Sound** > **Display** to select from **User**, **Standard**, **Video Sports**, **Movie Game**, and **Energy Saving**.

Color Temperature

Go to **Homepage** > **Dashboard** > **All settings** > **Display & Sound** > **Display** > **Expert Settings** > **Color Temperature** to select from **User**, **Cool**, **Standard**, and **Warm**.

Lightroom Mode

Go to **Homepage** > **Dashboard** > **All settings** > **Projector** > **Energy & Performance** > **Brightness Mode** to select from **Standard**, **ECO**, and **High Performance**.

Reset

Go to **Homepage** > **Dashboard** > **All settings** > **System** > **About** > **Reset** to restore the projector to factory settings.

System & Product Info

Go to **Homepage** > **Dashboard** > **All settings** > **System** > **About** to check system & product information.

PROJECTION DISTANCE AND SIZE

* For optimal image quality, we recommend a projection size of 100". Position the projector 11.38ft (3.47m) away from the wall or screen.

* The recommended projection distance varies with different projector contents. Please adjust the distance between the wall/screen and the projector as needed.

* Ambient darkness will improve the clarity of the projected images.

Important: You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Information:

The radio signal power of this device meets the limits of FCC radio frequency exposure limits. This device should be operated with a minimum separation distance of 20cm (8 inches) between the equipment and a person only.

The remote control has been evaluated to meet general RF exposure requirements; it can be used in portable exposure condition without restriction.

Canada compliance statement (Conformité réglementaire canadienne):

The device complies with interference, emission and absorption Canadian radio equipment RSS standards. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Operateur et utilisateur RSS-2300 MHz: le présent appareil ne doit pas interférer avec les services radio et doit accepter toute interférence radio qu'il provoque, y compris toute interférence qui pourrait causer le fonctionnement inadéquat de l'appareil.

The device should be operated with a minimum separation distance of 25 cm (10 inches) between the equipment and a person's body.

The remote control has been evaluated to meet general RF exposure requirements; it can be used in portable exposure condition without restriction.

Le présent appareil est conforme aux CNR d'interférence, d'émission et d'absorption des ondes radioélectriques du Canada. L'opération est soumise aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique, y compris le brouillage qui pourrait entraîner le fonctionnement inadéquat de l'appareil.

Le présent appareil est conforme aux CNR d'interférence, d'émission et d'absorption des ondes radioélectriques du Canada. L'opération est soumise aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique, y compris le brouillage qui pourrait entraîner le fonctionnement inadéquat de l'appareil.

Dispositivo a Frequenza Radioelettrica:

La presente dispositivo rispetta le norme CEI 17-25 (limiti di esposizione alle interferenze radio). L'operazione è soggetta alle seguenti due condizioni: (1) il presente dispositivo non deve causare interferenze, e (2) il presente dispositivo deve accettare qualsiasi interferenza radio, compresa l'interferenza che potrebbe causare il funzionamento inadeguato del dispositivo.

La presente dispositivo è conforme alle norme CEI 17-25 (limiti di esposizione alle interferenze radio). L'operazione è soggetta alle seguenti due condizioni: (1) il presente dispositivo non deve causare interferenze, e (2) il presente dispositivo deve accettare qualsiasi interferenza radio, compresa l'interferenza che potrebbe causare il funzionamento inadeguato del dispositivo.

The product complies with FCC (CE) 15 (DOCSIS 3.0/DOCSIS 3.1).

The product label and configuration information are located at the bottom of the product.

Dolby Audio

Only Dolby Audio and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories.

NETFLIX

Netflix is a trademark of Netflix, Inc.

CE

Notice: Consumer Product Electronics Co., Ltd. declares that this radio equipment is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <https://aurizen.com/pages/declaration>

Product consumption

Power consumption

Standby mode <0.5W

Network standby mode <0.5W

Standby mode <0.5W

Network standby mode <0.5W

Time to enter the condition automatically

FC

The above complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and the receiver.

- Connect the equipment into a outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.