

vibesonly.com

Weight: 128g

Length: 3.5"

Largest width: 2.5"

Narrowest width: 1"

Total Height: 2" including handle

Made in China

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Vibes Only™

**Poppy
Palm Vibe**

Instruction Manual

This is a novelty device only, not for medical use. It is not intended for use in the diagnosis of disease or other conditions, or in the cure, mitigation, treatment, or prevention of disease, nor does it claim to in any way.

Never lose the grip on your orgasm...

This compact vibrator puts the ultimate pleasure in the palm of your hand. Crafted with a special finger-grip handle for your ease and comfort, simply lie back and enjoy the beauty of an effortless orgasm. It's one of our softest and squishiest toys, but with the powerful rumbling motor – she may be small but she certainly is mighty.

Use it in manual mode or turn up the heat by controlling it in the Vibes Only app.

Why you'll love the Poppy:


- Connects to the Vibes Only app
- Ultra soft squishy silicone for your comfort
- Custom designed handle to never lose your grip
- 5 levels of vibration and 3 patterns (unlock more in the Vibes Only app)
- Medical-grade, body-safe silicone
- Water resistant



Connect with Bluetooth

Get connected

Scan this code to download the Vibes Only app on your phone.



Inside the app:

- Custom controller so you can control your vibrator with your phone, plus more patterns and intensities (free feature)
- Battery estimator so you always know what kind of juice your device has (free feature)
- Our Long Distance Lover feature which allows someone else to control your vibrator from anywhere in the world (subscription feature)
- Extensive library of erotic audio stories which you can opt to connect your vibrator to, then it will vibrate in tandem with the pace of the story (subscription feature with some sample stories for free)

Start vibing

This vibrator comes partially charged. To get it all the way up, charge before use.



On your device, hold down each power button for two seconds to turn on.

Your Bluetooth will be enabled when the device turns on. The light will flash to indicate it is discoverable.

The app will detect your device. Select it, and your vibrator is synced!



To adjust intensity and patterns manually: Click the buttons to enjoy various sensations.

Power your vibrator

Charging instructions

If your vibe is feeling a little lowkey, it may be time for a charge.

Due to the unique design, each Vibes Only model charges slightly differently.

First, flip your Poppy upside down so that the handle is on a flat surface and the magnetic charging points are facing up. This will ensure your magnetic charger can stay connected.

Then, plug your USB cord into a standard charging block (high-power charging blocks may damage the battery).

Connect the magnetic charging points to the matching points on your vibrator. The light on your device will flash to indicate that it's charging.

When it is fully gassed up (approx. 2.5 hrs) the light will change to a steady glow.



Care for your vibrator ...and it will love you back!

Care instructions

We can't recommend using a water-based lubricant enough, such as Vibes Only Juiced Up. Avoid using a silicone-based lubricant as this could kill your vibrator. If you must use a silicone-based lubricant, perform a patch test first.

After every use, sanitize your toy with our Clean-her foaming toy cleanser, or you may use warm water and antibacterial soap. Dry thoroughly with a clean towel or air dry. Store in a cool, dry place and keep your vibrator away from toys made of other materials. Remember to charge periodically to maintain the battery life.

What not to do

- Use with oil-based massage oils or lubricants as it may damage the silicone.
- Leave your vibrator in direct sunlight or ever expose it to extreme heat.

Troubleshooting

Your vibrator's light does not pulse when the charger is connected? This could be why:

- Battery is fully charged (go off!)
- Battery is drained and will require several minutes to recognize that it is being charged.
- Charger is not properly connected. Check your charging block and charging cable.

Your vibrator does not connect with your phone when the button is pressed?

- Battery is drained and your device requires charging.
- Make sure you give Vibes Only permission to access Bluetooth in your phone settings.
- The Bluetooth on your phone is not enabled. Make sure to enable, or reset your phone if needed.
- You have exceeded the 10 seconds required for your vibrator to 'find' a device. Reset both your vibrator and your phone by turning off, waiting 30 seconds, then turning on. Now try again making sure your phone has fully restarted, with the Bluetooth switched on.

If you experience any other problems with your Vibes Only product or have any questions regarding operation, visit www.vibesonly.com or please contact help@vibesonly.com.

What's your vibe?

Discover more:



@VibesOnly



vibesonly.com

