





## Restrict Band NVNT ac20 5180MHz Peak



## Restrict Band NVNT ac20 5180MHz Average



Shenzhen LCS Compliance Testing Laboratory Ltd.


Add: 101, 201 Bldg A &amp; 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China

Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com


Scan code to check authenticity



## Restrict Band NVNT ac20 5240MHz Peak



## Restrict Band NVNT ac20 5240MHz Average



Shenzhen LCS Compliance Testing Laboratory Ltd.


Add: 101, 201 Bldg A &amp; 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China

Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com


Scan code to check authenticity



## Restrict Band NVNT ac40 5190MHz Peak



## Restrict Band NVNT ac40 5190MHz Average



Shenzhen LCS Compliance Testing Laboratory Ltd.


Add: 101, 201 Bldg A &amp; 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China

Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com


Scan code to check authenticity



## Restrict Band NVNT ac40 5230MHz Peak




## Restrict Band NVNT ac40 5230MHz Average






## Restrict Band NVNT ac80 5210MHz Peak



## Restrict Band NVNT ac80 5210MHz Average



Shenzhen LCS Compliance Testing Laboratory Ltd.


Add: 101, 201 Bldg A &amp; 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China

Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com


Scan code to check authenticity



## Restrict Band NVNT ac80 5210MHz Peak



## Restrict Band NVNT ac80 5210MHz Average



Shenzhen LCS Compliance Testing Laboratory Ltd.

Add: 101, 201 Bldg A &amp; 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China

Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com

Scan code to check authenticity



## B.5 Frequency Stability

| Condition | Mode | Frequency (MHz) | Antenna | Measured Frequency (MHz) | Frequency Error (Hz) | Deviation (ppm) | Limit (ppm) | Verdict |
|-----------|------|-----------------|---------|--------------------------|----------------------|-----------------|-------------|---------|
| NVNT      | ac20 | 5180            | Ant0    | 5180                     | 0                    | 0               | 25          | Pass    |
| NVNT      | ac20 | 5200            | Ant0    | 5200                     | 0                    | 0               | 25          | Pass    |
| NVNT      | ac20 | 5240            | Ant0    | 5240                     | 0                    | 0               | 25          | Pass    |
| NVNT      | ac40 | 5190            | Ant0    | 5189.96                  | -40000               | -7.71           | 25          | Pass    |
| NVNT      | ac40 | 5230            | Ant0    | 5230                     | 0                    | 0               | 25          | Pass    |
| NVNT      | ac80 | 5210            | Ant0    | 5209.92                  | -80000               | -15.36          | 25          | Pass    |




Shenzhen LCS Compliance Testing Laboratory Ltd.  
Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China  
Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com  
Scan code to check authenticity




## Test Graphs

## Freq. Stability NVNT ac20 5180MHz Ant0




## Freq. Stability NVNT ac20 5200MHz Ant0






## Freq. Stability NVNT ac20 5240MHz Ant0




## Freq. Stability NVNT ac40 5190MHz Ant0






## Freq. Stability NVNT ac40 5230MHz Ant0



## Freq. Stability NVNT ac80 5210MHz Ant0






| Condition | Mode | Frequency<br>(MHz) | Antenna | Measured Frequency<br>(MHz) | Frequency Error<br>(Hz) | Deviation<br>(ppm) | Limit<br>(ppm) | Verdict |
|-----------|------|--------------------|---------|-----------------------------|-------------------------|--------------------|----------------|---------|
| NVNT      | ac20 | 5180               | Ant1    | 5179.98                     | -20000                  | -3.86              | 25             | Pass    |
| NVNT      | ac20 | 5200               | Ant1    | 5199.94                     | -60000                  | -11.54             | 25             | Pass    |
| NVNT      | ac20 | 5240               | Ant1    | 5239.98                     | -20000                  | -3.82              | 25             | Pass    |
| NVNT      | ac40 | 5190               | Ant1    | 5189.96                     | -40000                  | -7.71              | 25             | Pass    |
| NVNT      | ac40 | 5230               | Ant1    | 5229.92                     | -80000                  | -15.3              | 25             | Pass    |
| NVNT      | ac80 | 5210               | Ant1    | 5209.92                     | -80000                  | -15.36             | 25             | Pass    |






## Test Graphs

## Freq. Stability NVNT ac20 5180MHz Ant1




## Freq. Stability NVNT ac20 5200MHz Ant1






## Freq. Stability NVNT ac20 5240MHz Ant1




## Freq. Stability NVNT ac40 5190MHz Ant1






## Freq. Stability NVNT ac40 5230MHz Ant1



## Freq. Stability NVNT ac80 5210MHz Ant1





## B.6 Duty Cycle


| Condition | Mode | Frequency (MHz) | Antenna | Duty Cycle (%) | Correction Factor (dB) | 1/T (kHz) |
|-----------|------|-----------------|---------|----------------|------------------------|-----------|
| NVNT      | a    | 5180            | Ant0    | 96.94          | 0.13                   | 0.72      |
| NVNT      | a    | 5200            | Ant0    | 96.87          | 0.14                   | 0.72      |
| NVNT      | a    | 5240            | Ant0    | 96.94          | 0.13                   | 0.72      |
| NVNT      | n20  | 5180            | Ant0    | 96.7           | 0.15                   | 0.78      |
| NVNT      | n20  | 5200            | Ant0    | 96.7           | 0.15                   | 0.78      |
| NVNT      | n20  | 5240            | Ant0    | 96.62          | 0.15                   | 0.78      |
| NVNT      | n40  | 5190            | Ant0    | 93.53          | 0.29                   | 1.57      |
| NVNT      | n40  | 5230            | Ant0    | 93.68          | 0.28                   | 1.57      |
| NVNT      | ac20 | 5180            | Ant0    | 96.64          | 0.15                   | 0.78      |
| NVNT      | ac20 | 5200            | Ant0    | 96.7           | 0.15                   | 0.78      |
| NVNT      | ac20 | 5240            | Ant0    | 96.7           | 0.15                   | 0.78      |
| NVNT      | ac40 | 5190            | Ant0    | 93.68          | 0.28                   | 1.53      |
| NVNT      | ac40 | 5230            | Ant0    | 93.82          | 0.28                   | 1.53      |
| NVNT      | ac80 | 5210            | Ant0    | 88.04          | 0.55                   | 3.09      |






## Test Graphs

## Duty Cycle NVNT a 5180MHz Ant0




## Duty Cycle NVNT a 5200MHz Ant0






## Duty Cycle NVNT a 5240MHz Ant0




## Duty Cycle NVNT n20 5180MHz Ant0






## Duty Cycle NVNT n20 5200MHz Ant0



## Duty Cycle NVNT n20 5240MHz Ant0



Shenzhen LCS Compliance Testing Laboratory Ltd.


Add: 101, 201 Bldg A &amp; 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China

Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com


Scan code to check authenticity



## Duty Cycle NVNT n40 5190MHz Ant0




## Duty Cycle NVNT n40 5230MHz Ant0






## Duty Cycle NVNT ac20 5180MHz Ant0




## Duty Cycle NVNT ac20 5200MHz Ant0






## Duty Cycle NVNT ac20 5240MHz Ant0




## Duty Cycle NVNT ac40 5190MHz Ant0






## Duty Cycle NVNT ac40 5230MHz Ant0



## Duty Cycle NVNT ac80 5210MHz Ant0






| Condition | Mode | Frequency (MHz) | Antenna | Duty Cycle (%) | Correction Factor (dB) | 1/T (kHz) |
|-----------|------|-----------------|---------|----------------|------------------------|-----------|
| NVNT      | a    | 5180            | Ant1    | 96.87          | 0.14                   | 0.72      |
| NVNT      | a    | 5200            | Ant1    | 96.94          | 0.13                   | 0.72      |
| NVNT      | a    | 5240            | Ant1    | 96.94          | 0.13                   | 0.72      |
| NVNT      | n20  | 5180            | Ant1    | 96.7           | 0.15                   | 0.78      |
| NVNT      | n20  | 5200            | Ant1    | 96.7           | 0.15                   | 0.78      |
| NVNT      | n20  | 5240            | Ant1    | 96.7           | 0.15                   | 0.78      |
| NVNT      | n40  | 5190            | Ant1    | 93.53          | 0.29                   | 1.57      |
| NVNT      | n40  | 5230            | Ant1    | 93.53          | 0.29                   | 1.57      |
| NVNT      | ac20 | 5180            | Ant1    | 96.7           | 0.15                   | 0.76      |
| NVNT      | ac20 | 5200            | Ant1    | 96.76          | 0.14                   | 0.76      |
| NVNT      | ac20 | 5240            | Ant1    | 96.68          | 0.15                   | 0.76      |
| NVNT      | ac40 | 5190            | Ant1    | 93.68          | 0.28                   | 1.53      |
| NVNT      | ac40 | 5230            | Ant1    | 93.68          | 0.28                   | 1.53      |
| NVNT      | ac80 | 5210            | Ant1    | 88.04          | 0.55                   | 3.09      |






## Test Graphs

## Duty Cycle NVNT a 5180MHz Ant1



## Duty Cycle NVNT a 5200MHz Ant1



Shenzhen LCS Compliance Testing Laboratory Ltd.


Add: 101, 201 Bldg A &amp; 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China

Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com


Scan code to check authenticity



## Duty Cycle NVNT a 5240MHz Ant1




## Duty Cycle NVNT n20 5180MHz Ant1






## Duty Cycle NVNT n20 5200MHz Ant1




## Duty Cycle NVNT n20 5240MHz Ant1






## Duty Cycle NVNT n40 5190MHz Ant1




## Duty Cycle NVNT n40 5230MHz Ant1






## Duty Cycle NVNT ac20 5180MHz Ant1




## Duty Cycle NVNT ac20 5200MHz Ant1






## Duty Cycle NVNT ac20 5240MHz Ant1




## Duty Cycle NVNT ac40 5190MHz Ant1





## Duty Cycle NVNT ac40 5230MHz Ant1



## Duty Cycle NVNT ac80 5210MHz Ant1

