

Bedside table instruction manual

- 1、Please handle the valuables with care, and first check whether the appearance is in good condition after unpacking.
- 2、Open the drawer and take out the accessories inside: 4 feet, screws, power adapter.
- 3、Install the feet: Put a soft cushion on the ground, put the cabinet upside down, put the four feet on the four corners of the cabinet, the corners of the feet are aligned with the corners of the cabinet, and screw it directly with small screws to fix it.



The corners of the feet are aligned with the corners of the cabinet when viewed from the front

- 4、Connect one end of the power supply to the socket (the small light of the power supply lights up at this time) and the other end to the power interface of the cabinet (the touch switch on the cabinet panel lights up to indicate that the power supply is normally powered on). Click the touch switch light strip to adjust the three colors, long press the touch switch to adjust the brightness of the light strip, and long press the touch switch to turn off the light of the switch when the light strip is off.
- 5、Place the mobile phone with wireless charging function on the center point of the panel to charge the mobile phone. At present, it supports most mobile phones with wireless charging function on the market (some mobile phones are not compatible). Note: Be sure to focus on the center point, wait for a few seconds after placing it, and wait for the device to respond. If there is a mobile phone case that will affect the charging, you can remove it first.
- 6、For the style with fingerprint lock configuration, please refer to the fingerprint lock setting steps on the back.

1. long press until green light on 3 times (enter setting status) remove finger
2. Blue light on (add fingerprints) press sensor for 5~12 times
3. Success : green light on;Fail : red light on ,follow the steps and try again
4. Blue light on, repeat the above steps to register more fingerprints or waiting for exit (allow register 10-20)

Add fingerprints:

Put the same finger on,until green light on 3 times (enter setting system) then remove and register new fingerprints.

E-key function (restore factory)

If you haven't entered your fingerprint.You can insert E-KEY to usb port,put any fingerprint to unlock.

Delete fingerprints and restore factory(Two choices)

Method 1.Long press with the registered fingerprint until red light on then release,green light on mean success

Method 2.Insetting E-key,any fingerprint unlock ,green light on mean success

Low battery tips: When it unlock , red light on, reminder low battery , user should change new battery for the lock.If haven't change battery ,the lock will stop work.

If can't unlock mean running out of battery,can use micro USB inset to pannel USB socket and unlock ,please change the battery after unlock.

Green light on 1 times: unlock/locking

Green light on 3 times: enter setting status

Blue light on: add fingerprints

Red light on: reminder

FCC Warning Statement

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment must be installed and operated with a minimum distance of 15 cm between the radiator and user body.