


IMPORTANT: Please read this manual carefully before using the Life Box Tag.

Usage Requirements:

- (1) To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.
- (2) Two-factor authentication is enabled.
- (3) "Find My" feature on the phone is enabled.
- (4) Bluetooth on the phone is enabled.
- (5) Strong Wi-Fi or cellular network signal is available.
- (6) "Location Services" are enabled: Go to "Settings" > "Privacy" > "Location Services".
- (7) To use "Precise Tracking" and view the most accurate location of the Life Box Tag, please grant location access to "Find My". Go to "Settings" > "Privacy" > "Location Services", then scroll down and tap on "Find My". Select either "While Using the App" or "While Using the App or Widget". Then enable "Precise Location".

1. Get started: Power On/Off:

- (1) Power On: Press the invisible button once. Music indicates powered on.
Check: Press the button twice quickly, 1 beep indicates that your Life Box Tag is power on.
- (2) Power Off: Press and hold the invisible button at least 5 seconds until you hear two beeps.
- (3) Please remove the battery tab before use. Upon removal, a musical sound indicates activation, and now the Life Box Tag is ready for connection.



2. Add Your Life Box Tag:

- (1) Find and open the "Find My" app.
- (2) Tap on the "Items" at the bottom, Tap+, then "Add Other Item", choose "Other Supported Item".
- (3) Once the device named "Life Box Tag" appears, tap "connect" and follow Apple's instructions to complete the setup.

Now You can attach Life Box Tag to your item by using hooks, straps, or leather loops, preventing your belongings from being lost or misplaced.

3. Locate Your Life Box Tag:

- (1) Find Life Box Tag When It's Nearby:
 - Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch.
 - Tap on your Life Box Tag from the list.
 - Tap "Play Sound" to make your Life Box Tag beep.
 - Tap "Stop Sound" to stop the beeps once you find.
- (2) Find Life Box Tag's Location
 - Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch.
 - Tap on your Life Box Tag from the list.
 - Your Life Box Tag's location will appear on the Map with a time stamp of when the item was located.
 - To navigate to the Life Box Tag's location, tap "Directions" to open Apple Maps .

4. Notification:

(1) Enabling "Notify When Left Behind":

- Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch.
- Tap on your Life Box Tag from the list.
- Under "Notifications" enable the "Notify When Left Behind" toggle.
- You will receive a notification when you leave your Life Box Tag behind and it's no longer in range of your device.

(2) Enabling "Notify When Found":

- Under "Notifications", enable the "Notify When Found" toggle.
- When your Life Box Tag is seen by another Find My network device, you will receive a notification of its location.
- Note : "Notify When Found" can only be activated when your Life Box Tag is out of range.

5. Enable "Lost Mode" When Your Life Box Tag is Lost:

- Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch.
- Tap on your Life Box Tag from the list.
- Under "Lost Mode" tap "Enable"
- A screen detailing Lost Mode will pop up, tap "Continue"
- Enter your phone number or email address and tap "Next".
- You may enter a message that will be shared with the person that finds your item.
- Tap "Activate" to enable "Lost Mode"

Note: When "Lost Mode" is enabled, "Notify When Found" is automatically enabled.

Note: When "Lost Mode" is enabled, your Life Box Tag is locked and cannot be paired to a new device.

6. Resetting Life Box Tag

(1) Removing items From the Find My app:

- Open Find My app and select the "Items" tab.
- Tap on your Life Box Tag from the list.
- please ensure "Lost Mode" is disabled.
- Scroll to the bottom of the screen and tap "Remove Item".
- A summary will open, tap "Remove" to confirm.

(2) Factory Reset Your Life Box Tag:

- After successfully removing the Life Box Tag from Find My app, press the Life Box Tag's function button four times rapidly and then hold it a fifth time until you hear a ringing chime.
- The Life Box Tag is now reset and ready to be paired to a new Apple ID.

7. Unwanted tracking:

If any Find My network accessory separated from its owner is seen moving with you over time, you'll be notified in one of two ways:

- (1) If you have an iPhone, iPad, Find My will send a notification to your Apple device. This feature is available on iOS or iPadOS 14.5 or later.
- (2) If you don't have an iOS device or a smartphone, a Find My network accessory that isn't with its owner for a period of time will emit a sound when it's moved.

These features were created specifically to discourage people from trying to track you without your knowledge.

8. Battery Replacement and Statement:

- (1) Open the battery cover along the groove.

- (2) Remove the battery.
- (3) Place a CR2032 battery into the device with the positive side (+) facing forward.
- (4) Press the battery cover with your fingers to insert it into the product, and complete the replacement



Caution: The lost prevention device includes one button battery. If the battery needs to be replaced during the product's lifespan, please use the same model (CR2032) and capacity battery for replacement. When installing, please carefully observe the positive and negative poles of the battery.

Important: Please follow local environmental protection laws and regulations for the proper disposal of used batteries. Please keep the battery out of the reach of children. Do not swallow the battery. If swallowed or inserted into the body, please seek medical attention immediately. If the battery cover is not securely closed, please stop using the device and keep it out of the reach of children.

Battery Statement:

Warning: Do not puncture or burn the battery. This battery does not contain mercury.

Warning: Do not swallow the battery as it poses a risk of chemical burns.

Warning: Using the wrong battery model or an unqualified battery replacement may cause an explosion risk.

Caution: Please recycle the used battery.

9.The Fine Print

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes not expressly approved by the party responsible for compliance could void the user's authority to operate this device. The device has been evaluated to meet general RF exposure requirement, The device can be used in portable exposure conditions without restriction.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

10.Important Safety Information:

Caution: Handle the device with care. It contains highly sensitive electronic components, including the battery. Dropping, burning, puncturing, crushing, disassembling, or exposing it to high temperatures, liquids, or highly concentrated industrial chemicals may result in damage, impaired functionality, or personal injury. Do not use a damaged device.

Choking Hazard: The device, battery, battery cover, and packaging may cause choking or other injuries to infants. Keep these items out of reach of children.

11.Apple Declaration:

The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, Mac, or the Find Items app on Apple Watch.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple

Watch requires the latest version of watchOS.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.