


USER MANUAL

PRODUCT INTRODUCTION

I Packing list



II Product parameters

1. Charging bin parameters


Input voltage: DC5V Battery capacity: 300 mAh
Charging port: Type-C port Standby time: about 120 days
Charging current: 250 mA Charging time: about 2 hours

2. Headset parameters

Bluetooth name:	OW12
Battery capacity:	3.7V / 50mAh
Duration:	About 4~5 hours
Charging time:	about 2 hours
Bluetooth version:	Bluetooth V5.3
Frequency response:	20Hz ~ 20KHz
Support bluetooth protocol:	A2DP1. 3 / AVCTP1.4 / AVDTP1.3 / AVRCP1.5 / HFP1.5 / SPP1.0 / SMP/L2CAP4. 2

PRODUCT APPEARANCE AND FUNCTION

III Product appearance



PRODUCT FUNCTION OPERATION

IV Product Function Operation

Charging indicator light	
Charging the charging compartment	The water lamp of the charging compartment is fully on
The charging compartment is fully charged	The water lamp of the charging compartment is off

Earphone function prompt	
Feature	Operation instruction
Connect your phone	The Bluetooth details page searches for headphones corresponding to the Bluetooth name connection
Voice assistant	Touch L/R Press and hold for 2 seconds to trigger the voice assistant
Play/pause	L/R Touch twice
Answer the phone	L/R Touch 2 times (on call)
Reject a call	L/R long press for 2 seconds (on call)
Hang up the phone	L/R Touch 2 times (during a call)
Up/down switch	L Touch the last song three times ; R touches the next song three times
Add and subtract volume	L earphones touch once to decrease volume, R earphones touch once to increase volume (phone increases volume by one grid) Note: Some Android phones have compatibility issues and require the interface to be equipped with Bluetooth device phone synchronization function.
Display power	Mobile phone display battery column (requires phone compatibility)
disconnect	Put the earphones into the charging compartment and disconnect them. Take them out and they will automatically reconnect
Earphone 3.3V low power alert	Low battery warning sound

FUNCTION OPERATION & PRECAUTIONS

V Matters needing attention

1. Do not use corrosive cleaning agents to clean the product.
2. Do not allow this product to be heated or near fire sources, such as cooking stoves.
3. Do not allow this product to be exposed to direct sunlight for a long time.
4. Do not dispose of this product in the fire to avoid explosion.
5. Do not attempt to disassemble this product for any modification, as it does not contain any repair components.
6. Do not use this product in the rain.
7. If you do not intend to use this product for a long time, please store it in a dry environment and charge the headset at least once a month to extend its life and avoid extreme temperatures and dust.

Attention: The product has a built-in rechargeable battery. Please do not disassemble or replace it by yourself. Use the correct method to charge the device. Do not place the device near a fire source or expose it to direct sunlight, otherwise the battery heating will damage the safety device and cause the battery to explode or burn.

Made in China



WARRANTY CARD

Product model : _____

Purchase date : _____


Agent : _____

Invoice date : _____

Telephone : _____

Customer Name : _____

Postal Code : _____



A diagram illustrating a vertical dimension. A light blue rectangle is shown. To its left, a vertical double-headed arrow indicates a height of 70mm. The text "USER MANUAL" is centered within the rectangle.

PRODUCT INTRODUCTION 01					
 Packing list  Host *1  Instructions*1  Charging cable*1  Certificate*1					
 Product parameters 1. Charging bin parameters Input voltage: DC5V Battery capacity: 300 mAh Charging port: Type-C port Standby time: about 120 days Charging current: 250 mA Charging time: about 2 hours					
2. Headset parameters <table border="1"> <tr> <td>Bluetooth name: A20-OWS</td> </tr> <tr> <td>Battery capacity: 3.7V / 50mAh</td> </tr> <tr> <td>Duration: About 4~5 hours</td> </tr> <tr> <td>Charging time: about 2 hours</td> </tr> </table> Bluetooth version: Bluetooth V5.3 Frequency response: 20Hz ~ 20KHz Support bluetooth protocol: A2DP1.3 / AVCTP1.4 / AVDTP1.3 / AVRCP1.5 / HFP1.5 / SPP1.0 / SMP/L2CAP4.2		Bluetooth name: A20-OWS	Battery capacity: 3.7V / 50mAh	Duration: About 4~5 hours	Charging time: about 2 hours
Bluetooth name: A20-OWS					
Battery capacity: 3.7V / 50mAh					
Duration: About 4~5 hours					
Charging time: about 2 hours					

Host *1

Instructions*

Charging cable*1

Certificate*1

1. Charging bin parameters

Input voltage: DC5V	Battery capacity: 300 mAh
Charging port: Type-C port	Standby time: about 120 days
Charging current: 250 mA	Charging time: about 2 hours

Bluetooth name: A20-OWS
Battery capacity: 3.7V / 50mAh
Duration: About 4~5 hours
Charging time: about 2 hours
Bluetooth version: Bluetooth V5.3
Frequency response: 20Hz ~ 20KHz
Support bluetooth protocol: A2DP1.3 / AVCTP1.4 / AVDTP1.3 / AVRCP1.5 / HFP1.5 / SPP1.0 / SMP/L2CAP4.2

PRODUCT APPEARANCE AND FUNCTION

02

Product appearance

The technical drawing illustrates the OWS Earphone and its charging case. The top part shows the back of the charging case, which is circular. It features a 'Charging indicator light' at the top, a 'Charging pin' in the center, and a 'Type-C interface' at the bottom. The bottom part shows the two earphones inside the case. Each earphone has a 'Touch area' on the top, an 'indicator light' on the side, and a 'Pickup hole' on the front. The earphones are connected to the case by a 'Charging port' and have a 'Horn hole' on the front.

Charging indicator light

Charging pin

Type-C interface

Charging case

Touch area

indicator light

Pickup hole

Charging port

Horn hole

OWS Earphone

Diagram illustrating the back of the device, showing the charging port and indicator light. The components are labeled:

- Charging indicator light
- Charging pin
- Type-C interface

Diagram illustrating the front view of the proposed smart helmet. The components labeled are:

- Touch area
- indicator light
- Pickup hole
- Charging port
- Horn hole

OWS Earphone

PRODUCT FUNCTION OPERATION		04
IV Product Function Operation		
Charging indicator light		
Charging the charging compartment	The water lamp of the charging compartment is fully on	
The charging compartment is fully charged	The water lamp of the charging compartment is off	
Earphone function prompt		
Feature	Operation instruction	
Connect your phone	The Bluetooth details page searches for headphones corresponding to the Bluetooth name connection	
Voice assistant	Touch L/R Press and hold for 2 seconds to trigger the voice assistant	
Play/pause	L/R Touch twice	
Answer the phone	L/R Touch 2 times (on call)	
Reject a call	L/R long press for 2 seconds (on call)	
Hang up the phone	L/R Touch 2 times (during a call)	
Up/down switch	L Touch the last song three times ; R touches the next song three times	
Add and subtract volume	L earphones touch once to decrease volume, R earphones touch once to increase volume (phone increases volume by one grid) Note: Some Android phones have compatibility issues and require the interface to be equipped with Bluetooth device phone synchronization function.	
Display power	Mobile phone display battery column (requires phone compatibility)	
disconnect	Put the earphones into the charging compartment and disconnect them. Take them out and they will automatically reconnect	
Earphone 3.3V low power alert	Low battery warning sound	

Charging indicator light	
Charging the charging compartment	The water lamp of the charging compartment is fully on
The charging compartment is fully charged	The water lamp of the charging compartment is off

Earphone function prompt	
Feature	Operation instruction
Connect your phone	The Bluetooth details page searches for headphones corresponding to the Bluetooth name connection
Voice assistant	Touch L/R Press and hold for 2 seconds to trigger the voice assistant
Play/pause	L/R Touch twice
Answer the phone	L/R Touch 2 times (on call)
Reject a call	L/R long press for 2 seconds (on call)
Hang up the phone	L/R Touch 2 times (during a call)
Up/down switch	L Touch the last song three times ; R touches the next song three times
Add and subtract volume	L earphones touch once to decrease volume, R earphones touch once to increase volume (phone increases volume by one grid) Note: Some Android phones have compatibility issues and require the interface to be equipped with Bluetooth device phone synchronization function.
Display power	Mobile phone display battery column (requires phone compatibility)
disconnect	Put the earphones into the charging compartment and disconnect them. Take them out and they will automatically reconnect
Earphone 3.3V low power alert	Low battery warning sound

V

Matters needing attention

1. Do not use corrosive cleaning agents to clean the product.

2. Do not allow this product to be heated or near fire sources, such as cooking stoves.

3. Do not allow this product to be exposed to direct sunlight for a long time.

4. Do not dispose of this product in the fire to avoid explosion.

5. Do not attempt to disassemble this product for any modification, as it does not contain any repair components.

6. Do not use this product in the rain.

7. If you do not intend to use this product for a long time, please store it in a dry environment and charge the headset at least once a month to extend its life and avoid extreme temperatures and dust.

Attention: The product has a built-in rechargeable battery. Please do not disassemble or replace it by yourself. Use the correct method to charge the device. Do not place the device near a fire source or expose it to direct sunlight, otherwise the battery heating will damage the safety device and cause the battery to explode or burn.

Made in China

CE

FC

1. Do not use corrosive cleaning agents to clean the product.
2. Do not allow this product to be heated or near fire sources, such as cooking stoves.
3. Do not allow this product to be exposed to direct sunlight for a long time.
4. Do not dispose of this product in the fire to avoid explosion.
5. Do not attempt to disassemble this product for any modification, as it does not contain any repair components.
6. Do not use this product in the rain.
7. If you do not intend to use this product for a long time, please store it in a dry environment and charge the headset at least once a month to extend its life and avoid extreme temperatures and dust.

Attention: The product has a built-in rechargeable battery. Please do not disassemble or replace it by yourself. Use the correct method to charge the device. Do not place the device near a fire source or expose it to direct sunlight, otherwise the battery heating will damage the safety device and cause the battery to explode or burn.

Made in China



WARRANTY CARD

06

Product model : _____

Purchase date : _____

Agent : _____

Invoice date : _____

Telephone : _____

Customer Name : _____

Postal Code : _____

PASS

QC 01

Qualified

Eertificate

Examination clerk

This product has been inspected
and found to be qualified

Product model : _____

Purchase date : _____

Agent : _____

Invoice date : _____

Telephone : _____

Customer Name : _____

Postal Code : _____



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.