


360°C Rotating&Vibrating Anal Plug

User Manual

Edgar



Before first use, please read the instructions below carefully.




RoHS IP65 RED

● About this Device:

Edgar is a 360°C Rotating&vibrating anal plug, 3 rotating speed modes allow you to experience another kind of backcourt orgasm. and the 10 frequency vibration mode makes you want to stop. Its shape conforms to the ergonomic design, can be worn invisibly, And secretly enjoy the numbing stimulation anytime, anywhere. The semen lock ring can not only delay the time of ejaculation, but also enjoy the pleasure more lastingly. The wireless remote control operation at a distance of 10 meters is not only convenient, but also hands-free. A sex toy worthy of your favor.

● Product information :

Model NO:	YB-27
Material:	Liquid silicone and ABS
Waterproof:	IP65
Features:	10 vibration patterns and 3 speed modes
Charging Method:	Rechargeable Li-ion Battery, USB Charging
Charging Time:	90 minutes
Usage Time:	50 minutes



● Product description :

- Press for 3 seconds to turn on / off.
- Press shortly to shift vibration and rotation


LED light indication:

Device ON: Solid light ON

Low Battery Warning: Light flashing

On Charging: Light blinking


Fully Charged: Solid light ON



- Press shortly to shift 10 Vibration patterns.

- Press shortly to shift 3 speeds modes.

- Press for 3 seconds to turn on / off.



● Charging Tips:

Make sure this product is fully charged before first use. It will NOT work while charging!

● Disclaimer:

This product is to be used as a novelty for people over the age of 18 only. Users of this item do so at their own risk. It should not be used on a prolonged or frequent basis. Neither nor its retailers assume any responsibility or liability for the use of this product.

This product doesn't claim to cure any disease or STI.

© Warranty Terms & Conditions:

This product warrants this device for a period of one year, after the date of original purchase against defects due to faulty workmanship or materials. If you experience any factory/assembly defects, please contact us and we will do our best to solve your issues as soon as possible.

Caution: please do not take your vibrator apart by yourself or by an unauthorized repair shop, as your warranty will automatically expire.

© Safety Tips:

Avoid sharing this device with others due to hygiene concerns. Only water based lubricant is recommended to use with this product. Do not use massage oils or hand cream as lubricants for this device, as you will damage its silicone soft touch surface. Stop using this device if its tip is chipped or broken or has sharp edges.

© Cleaning and Storage:


Please note that the remote controller is not waterproof. Always clean your device thoroughly before and after each use. Clean your device with an antibacterial toy cleaner. Alternatively, you can wash the device with warm water and soap, rinse with clean hot water and pat dry with a clean towel. Hard detergents, disinfectants, acetone or alcohol are not recommended to use to clean your device. Store your device in a clean and dry space and keep it out of children's reach.

Applicable for ALL products, the model may be changed for improvements without notice.

360°C Rotierender & Vibrierender Analplug

Benutzerhandbuch

Edgar



Bitte lesen Sie vor dem ersten Gebrauch die folgenden Anweisungen sorgfältig durch.




RoHS IP65 RED

• Über dieses Gerät:

Edgar ist ein um 360°C rotierender und vibrierender Analplug. 3 rotierende Geschwindigkeitsmodi ermöglichen es Ihnen, eine andere Art von Hinterhoforgasmus zu erleben. Und der 10-Frequenz-Vibrationsmodus macht Lust aufs Aufhören. Seine Form entspricht dem ergonomischen Design, kann unsichtbar getragen werden und genießt jederzeit und überall heimlich die betäubende Stimulation. Der Samenverschlussring kann nicht nur den Zeitpunkt der Ejakulation verzögern, sondern auch das Vergnügen länger genießen. Die drahtlose Fernbedienungsbedienung aus einer Entfernung von 10 Metern ist bequem und freihändig. Ein Sexspielzeug, das Ihrer Gunst würdig ist.

• Produktinformation :

Modell Nr.:	YB-27
Material:	Liquid silicone and ABS
Wasserdicht:	IP65
Eigenschaften:	10 Vibrationsmuster und 3 Geschwindigkeitsmodi
Lademethode:	Wiederaufladbarer Li-Ionen-Akku, USB-Aufladung
Ladezeit:	90 Minuten
Nutzungsdauer:	50 Minuten



● Produktbeschreibung:

- Zum Ein-/Ausschalten 3 Sekunden lang drücken.
- Kurz drücken, um Vibration und Rotation zu ändern.

LED-Lichtanzeige:


Gerät EIN: Dauerlicht EIN

Warnung bei niedrigem

Batteriestand: Licht blinkt

Beim Laden: Licht blinkt


Vollständig aufgeladen: Dauerlicht AN



- Drücken Sie kurz, um zwischen 10 Vibrationsmustern zu wechseln.

- Kurz drücken, um zwischen 3 Geschwindigkeitsmodi zu wechseln.

- Zum Ein-/Ausschalten 3 Sekunden lang drücken.



● Ladetipps:

Stellen Sie sicher, dass dieses Produkt vor dem ersten Gebrauch vollständig aufgeladen ist. Während des

● Haftungsausschluss:

Dieses Produkt darf als Neuheit nur von Personen über 18 Jahren verwendet werden. Benutzer dieses Artikels tun dies auf eigenes Risiko. Es sollte nicht über einen längeren Zeitraum oder häufig verwendet werden. Weder noch seine Händler übernehmen Verantwortung oder Haftung für die Verwendung dieses Produkts.

Dieses Produkt erhebt keinen Anspruch auf Heilung von Krankheiten oder sexuell übertragbaren Krankheiten.

© Garantiebedingungen:

Dieses Produkt gewährt für dieses Gerät eine Garantie von einem Jahr ab dem ursprünglichen Kaufdatum gegen Mängel, die auf fehlerhafte Verarbeitung oder Materialien zurückzuführen sind. Sollten bei Ihnen Fabrikations-/Montagemängel auftreten, kontaktieren Sie uns bitte und wir werden unser Bestes tun, um Ihre Probleme so schnell wie möglich zu lösen. Achtung: Bitte nehmen Sie Ihren Vibrator nicht selbst auseinander. Wenden Sie sich an eine nicht autorisierte Reparaturwerkstatt, da Ihre Garantie automatisch erlischt.

© Sicherheitstipps:

Aus hygienischen Gründen vermeiden Sie es, dieses Gerät mit anderen zu teilen. Für dieses Produkt wird nur Gleitmittel auf Wasserbasis empfohlen. Verwenden Sie keine Massageöle oder Handcremes als Gleitmittel für dieses Gerät, da Sie dadurch die Silikon-Soft-Touch-Oberfläche beschädigen. Benutzen Sie dieses Gerät nicht mehr, wenn die Spitze abgesplittert oder gebrochen ist oder scharfe Kanten aufweist.

© Reinigung und Lagerung:

Bitte beachten Sie, dass die Fernbedienung nicht wasserdicht ist. Reinigen Sie Ihr Gerät vor und nach jedem Gebrauch gründlich. Reinigen Sie Ihr Gerät mit einem antibakteriellen Spielzeugreiniger. Alternativ können Sie das Gerät mit warmem Wasser und Seife waschen, mit klarem heißem Wasser abspülen und mit einem sauberen Handtuch trocken tupfen. Die Verwendung von harten Reinigungsmitteln, Desinfektionsmitteln, Aceton oder Alkohol zum Reinigen Ihres Geräts wird nicht empfohlen. Bewahren Sie Ihr Gerät an einem sauberen und trockenen Ort auf und bewahren Sie es außerhalb der Reichweite von Kindern auf.

Gilt für ALLE Produkte. Das Modell kann ohne Vorankündigung zur Verbesserung geändert werden.

FCC warning statements:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.