



Use instruction

Thank you for choosing our toy product. To ensure a smooth experience, please read the following instructions carefully before use. This will help you better understand the product and operate it properly.

IMPORTANT NOTICE:

● **This is an electronic product.**
Not suitable for children under 8 years old. All electronic products should be used with caution to prevent electric shock.

● **Use only under adult supervision.**

WARNING: Do not modify or alter this product. Any modifications will void your right to use the product.


Product Contents: 4WD Drift RC Car ×1 Remote Controller ×1
Built-in Rechargeable Lithium Battery Pack ×1 TYPE-C USB Charging Cable ×1

● Feature:

1. Charging Time: approx. 20 minutes
2. Play Time: approx. 30 minutes
3. Functions: Forward, Reverse, Turn Left, Turn Right
4. Frequency: 2.4GHz

How to Charge?

1. Insert the TYPE-C plug into the car's charging port.
2. Plug the other end into a USB port such as a phone charger or computer.
3. The indicator light stays red while charging and turns off when fully charged.



Charging methods



Desktop Computer



Laptop USB port




Phone charger USB port



Fixed socket USB port

Remote and Car Operation




Operations Tips:

- Ensure the power switch is in the "ON" position when operating. If switched OFF, the car will not function.
- If the car veers left while driving straight, adjust the trim to the right until it corrects.
- If the car veers right while driving straight, adjust the trim to the left until it corrects.

Battery Installation:

1. Remove the battery cover from the back of the remote controller.
2. Install two AA batteries following the polarity markings.



How to play?

1. Insert two AA batteries into the remote controller.
2. Switch the remote controller to "ON" – the indicator will flash.
3. Switch the car to "ON" – the blue underbody light will stay on, and the front/rear lights will flash. After pairing, the lights will stop flashing, and the controller light will stay on.
4. This indicates successful pairing. You may now begin playing.
5. Adjust the trim on the car's underside for straight driving.
6. If the remote's indicator dims, replace the AA batteries.
7. If the car slows down, it needs recharging.

Battery Safety

● RC cars

1. Battery is non-removable. Do not disassemble or alter.
2. Recharge only via USB.
3. Charge and use under adult supervision.
4. Do not store in high or low temperatures.
5. Charge in a separate area away from flammable objects.
6. Do not charge when the car is hot. Let it cool first.
7. Do not drop or expose to moisture.
8. Do not drop or expose to moisture.

● Remote Controller:

1. Install batteries with correct polarity to avoid short circuits.
2. Do not attempt to charge non-rechargeable batteries.
3. Remove depleted batteries from the controller.
4. Dispose of used batteries properly. Do not incinerate, as leaking may cause explosions.

To Consumers:

1. When playing indoors, avoid damaging furniture or glass.
2. Do not play on roads or among crowds – play in safe, open areas outdoors.
3. Stop use immediately if you hear thunder outdoors.
4. Do not play in puddles or close to prevent electrical failure.
5. Keep hands, hair, and clothes away from rotating wheels to avoid injury.
6. Do not drive the car towards people.
7. Do not throw or crash the RC car.
8. Store away from fire and heat sources.
9. The car contains complex circuitry – do not disassemble or modify.

Maintenance:

1. Remove batteries from the controller and switch the car to "OFF" when not in use for extended periods.
2. Clean gently with a dry cloth.
3. Avoid high temperature, humidity, and direct sunlight.
4. Do not immerse in water – may damage electronics.

© GUANGDONG XINYU TECHNOLOGY INDUSTRIAL CO., LTD.
Quan Yu Industrial Park, Laimei Industrial Zone, Chenghai District, Shantou City, Guangdong Province
China More info: www.xq-toys.com
Made in China



说明书

感谢您使用本公司生产的玩具，为了确保操作愉快，在使用前请您先阅读以下说明，以便您对本产品有足够的了解，并能进行正确使用。

注意:

● 电控产品

不要给8岁及其以下的孩子使用。所有的电子产品在使用的时候都要留意和预防电击。

● 请在成人监督下使用

警告：请遵守不要改变和修改这个产品，修改产品就无权使用这个产品。


产品内容：四驱漂移遥控车X1 遥控器X1 内置可充电锂电池包X1 TYPE-C USB 充电线X1

● 特色

1. 充电时间：20分钟左右
2. 玩耍时间：30分钟左右
3. 功能：前进、后退、左转、右转
4. 2.4GHz

如何充电?

1. 将充电线TYPE-C充电头插到车子充电口上；
2. 另一头插到手机USB充电座或者电脑主机USB插口等等带有USB插口上都能给小车充电；
3. 充电时充电指示灯红色常亮，充满电后指示灯灯灭。



充电方式



台式电脑主机USB插口充电



笔记本电脑USB插口充电




手机USB充电座充电



固定插座USB插口充电

遥控器和遥控车的操作



操作提示:


- 请确保电源开关是处于“ON”的位置上，当您在操作时，如电源开关是处于“OFF”时，遥控车是无功能的。
- 当遥控车在直线行驶时向左偏移，请将此装置向右微调，直到遥控车恢复正确的行驶路线。
- 当遥控车在直线行驶时向右偏移，请将此装置向左微调，直到遥控车恢复正确的行驶路线。

電池安裝

1. 将遥控器背面的电池盖取下；
2. 依照电池盒里的正负电极指示来装两节五号“AA”电池；

如何玩遥控车?

1. 首先将两节五号“AA”电池装到遥控器电池仓；
2. 然后将遥控器上的开关拨到“ON”，指示灯亮并闪烁；
3. 再将车子上的开关拨到“ON”，此时车底盘蓝灯常亮，前后车灯闪烁，对上码后前后车灯灭掉，遥控器指示灯常亮；
4. 此时表示遥控器与车子对码成功，可以尽情玩耍；
5. 调整车底的微调杆，使遥控车能够直线行驶；
6. 当遥控器的指示灯变暗时，请更换遥控器五号“AA”电池；
7. 当遥控车速度变慢，车子电量不足，此时须对遥控车进行充电。



電池的安全使用

一、遥控车

1. 电池不可拆卸，切勿拆开更改
2. 遥控车为内置锂电池包，仅可使用USB接口充电
3. 成年人监护充电与使用
4. 切勿在高温或低温储存
5. 单独充电区域，远离易燃物
6. 避免太阳直射，遥控车发热切勿充电，应先冷却
7. 不抛落、不受潮
8. 定期检查USB接头是否受损

二、遥控器

1. 遥控器电池正负极不可装反，避免短路
2. 非充电电池不可充电
3. 用完电的电池需从遥控器上取下来
4. 安全处理废电池。不要将废电池投入火里，因为电池泄露会引起爆炸

致消费者

1. 在室内玩遥控车时，请注意不要造成家具或玻璃损坏。
2. 请不要在道路和人群中玩遥控车，以免发生危险，请在户外安全地方玩耍。
3. 在室外玩遥控车听到打雷时，应立即停止玩耍。
4. 勿在积水或沙地上面玩耍，以免电池电路出现故障。
5. 车轮旋转时，不要将手伸近，以免受伤，更不可卷入头发，衣服等。
6. 不可将遥控车对着人行驶。
7. 不可将遥控车乱扔，乱碰撞。
8. 放置遥控车时，请远离火源及高温的地方。
9. 本车采用了复杂电子电路及大量元配件，请不要随意对电路板进行拆装或改装。

保养与维修

1. 长时间不玩时，请取出遥控器电池并将遥控车开关拨到“OFF”状态。
2. 清洁时请用干布轻轻擦拭。
3. 不要将玩具放在高温、潮湿及阳光直射的地方。
4. 不要把玩具放在水里，这样会损坏电子元件。

广东信宇科技实业有限公司
广东汕头市澄海区莱美工业区全宇工业园
更多信息请登陆网站:www.xq-toys.com
由中国制造

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.