



NTNV-n41-PC2-30-50-H-DFT-BPSK-Inner_1RB_Left-0.009-0.15-PAS
S



NTNV-n41-PC2-30-50-H-DFT-BPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n41-PC2-30-50-H-DFT-BPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n41-PC2-30-50-H-DFT-BPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n41-PC2-30-50-H-DFT-BPSK-Inner_1RB_Left-3000-18000-PA
SS




NTNV-n41-PC2-30-50-H-DFT-BPSK-Inner_1RB_Left-18000-30000-PA
SS



NTNV-n41-PC2-30-50-H-DFT-BPSK-Inner_1RB_Right-0.009-0.15-PA
SS



NTNV-n41-PC2-30-50-H-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n41-PC2-30-50-H-DFT-BPSK-Inner_1RB_Right-30-1000-PAS

S



NTNV-n41-PC2-30-50-H-DFT-BPSK-Inner_1RB_Right-1000-3000-PAS

S



NTNV-n41-PC2-30-50-H-DFT-BPSK-Inner_1RB_Right-3000-18000-P

ASS



NTNV-n41-PC2-30-50-H-DFT-BPSK-Inner_1RB_Right-18000-30000-P

ASS



NTNV-n41-PC2-30-50-H-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PAS

S



NTNV-n41-PC2-30-50-H-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS




NTNV-n41-PC2-30-50-H-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n41-PC2-30-50-H-DFT-QPSK-Inner_1RB_Left-1000-3000-PAS

S



NTNV-n41-PC2-30-50-H-DFT-QPSK-Inner_1RB_Left-3000-18000-PA

SS



NTNV-n41-PC2-30-50-H-DFT-QPSK-Inner_1RB_Left-18000-30000-PA

SS



NTNV-n41-PC2-30-50-H-DFT-QPSK-Inner_1RB_Right-0.009-0.15-PA

SS



NTNV-n41-PC2-30-50-H-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n41-PC2-30-50-H-DFT-QPSK-Inner_1RB_Right-30-1000-PAS

S



NTNV-n41-PC2-30-50-H-DFT-QPSK-Inner_1RB_Right-1000-3000-PA

SS



NTNV-n41-PC2-30-50-H-DFT-QPSK-Inner_1RB_Right-3000-18000-P

ASS



NTNV-n41-PC2-30-50-H-DFT-QPSK-Inner_1RB_Right-18000-30000-P

ASS


NTNV-n41-PC2-30-60-L-DFT-BPSK-Inner_1RB_Left-0.009-0.15-PAS
S


NTNV-n41-PC2-30-60-L-DFT-BPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n41-PC2-30-60-L-DFT-BPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n41-PC2-30-60-L-DFT-BPSK-Inner_1RB_Left-1000-3000-PASS


NTNV-n41-PC2-30-60-L-DFT-BPSK-Inner_1RB_Left-3000-18000-PA
SS

NTNV-n41-PC2-30-60-L-DFT-BPSK-Inner_1RB_Left-18000-30000-PA
SS

NTNV-n41-PC2-30-60-L-DFT-BPSK-Inner_1RB_Right-0.009-0.15-PA
SS


NTNV-n41-PC2-30-60-L-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n41-PC2-30-60-L-DFT-BPSK-Inner_1RB_Right-30-1000-PASS


NTNV-n41-PC2-30-60-L-DFT-BPSK-Inner_1RB_Right-1000-3000-PASS
S

NTNV-n41-PC2-30-60-L-DFT-BPSK-Inner_1RB_Right-3000-18000-PASS
ASS

NTNV-n41-PC2-30-60-L-DFT-BPSK-Inner_1RB_Right-18000-30000-PASS
ASS

NTNV-n41-PC2-30-60-L-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PASS
S


NTNV-n41-PC2-30-60-L-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n41-PC2-30-60-L-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n41-PC2-30-60-L-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n41-PC2-30-60-L-DFT-QPSK-Inner_1RB_Left-3000-18000-PA

SS



NTNV-n41-PC2-30-60-L-DFT-QPSK-Inner_1RB_Left-18000-30000-PA

SS



NTNV-n41-PC2-30-60-L-DFT-QPSK-Inner_1RB_Right-0.009-0.15-PA

SS



NTNV-n41-PC2-30-60-L-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n41-PC2-30-60-L-DFT-QPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n41-PC2-30-60-L-DFT-QPSK-Inner_1RB_Right-1000-3000-PAS

S




NTNV-n41-PC2-30-60-L-DFT-QPSK-Inner_1RB_Right-3000-18000-P

ASS



NTNV-n41-PC2-30-60-L-DFT-QPSK-Inner_1RB_Right-18000-30000-P

ASS


NTNV-n41-PC2-30-60-M-DFT-BPSK-Inner_1RB_Left-0.009-0.15-PAS
S


NTNV-n41-PC2-30-60-M-DFT-BPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n41-PC2-30-60-M-DFT-BPSK-Inner_1RB_Left-30-1000-PASS


NTNV-n41-PC2-30-60-M-DFT-BPSK-Inner_1RB_Left-1000-3000-PAS
S

NTNV-n41-PC2-30-60-M-DFT-BPSK-Inner_1RB_Left-3000-18000-PA
SS

NTNV-n41-PC2-30-60-M-DFT-BPSK-Inner_1RB_Left-18000-30000-PA
SS

NTNV-n41-PC2-30-60-M-DFT-BPSK-Inner_1RB_Right-0.009-0.15-PA
SS


NTNV-n41-PC2-30-60-M-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n41-PC2-30-60-M-DFT-BPSK-Inner_1RB_Right-30-1000-PAS

S



NTNV-n41-PC2-30-60-M-DFT-BPSK-Inner_1RB_Right-1000-3000-PA

SS



NTNV-n41-PC2-30-60-M-DFT-BPSK-Inner_1RB_Right-3000-18000-P

ASS



NTNV-n41-PC2-30-60-M-DFT-BPSK-Inner_1RB_Right-18000-30000-P

ASS



NTNV-n41-PC2-30-60-M-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PA

SS



NTNV-n41-PC2-30-60-M-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n41-PC2-30-60-M-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n41-PC2-30-60-M-DFT-QPSK-Inner_1RB_Left-1000-3000-PAS

S


NTNV-n41-PC2-30-60-M-DFT-QPSK-Inner_1RB_Left-3000-18000-PA
SS

NTNV-n41-PC2-30-60-M-DFT-QPSK-Inner_1RB_Left-18000-30000-PA
SS

NTNV-n41-PC2-30-60-M-DFT-QPSK-Inner_1RB_Right-0.009-0.15-P
ASS



NTNV-n41-PC2-30-60-M-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS


NTNV-n41-PC2-30-60-M-DFT-QPSK-Inner_1RB_Right-30-1000-PAS
S


NTNV-n41-PC2-30-60-M-DFT-QPSK-Inner_1RB_Right-1000-3000-PA
SS

NTNV-n41-PC2-30-60-M-DFT-QPSK-Inner_1RB_Right-3000-18000-P
ASS

NTNV-n41-PC2-30-60-M-DFT-QPSK-Inner_1RB_Right-18000-30000-P
ASS


NTNV-n41-PC2-30-60-H-DFT-BPSK-Inner_1RB_Left-0.009-0.15-PAS
S


NTNV-n41-PC2-30-60-H-DFT-BPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n41-PC2-30-60-H-DFT-BPSK-Inner_1RB_Left-30-1000-PASS




NTNV-n41-PC2-30-60-H-DFT-BPSK-Inner_1RB_Left-1000-3000-PASS


NTNV-n41-PC2-30-60-H-DFT-BPSK-Inner_1RB_Left-3000-18000-PA
SS

NTNV-n41-PC2-30-60-H-DFT-BPSK-Inner_1RB_Left-18000-30000-PA
SS

NTNV-n41-PC2-30-60-H-DFT-BPSK-Inner_1RB_Right-0.009-0.15-PA
SS


NTNV-n41-PC2-30-60-H-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n41-PC2-30-60-H-DFT-BPSK-Inner_1RB_Right-30-1000-PAS

S



NTNV-n41-PC2-30-60-H-DFT-BPSK-Inner_1RB_Right-1000-3000-PAS

S



NTNV-n41-PC2-30-60-H-DFT-BPSK-Inner_1RB_Right-3000-18000-P

ASS



NTNV-n41-PC2-30-60-H-DFT-BPSK-Inner_1RB_Right-18000-30000-P

ASS



NTNV-n41-PC2-30-60-H-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PAS

S



NTNV-n41-PC2-30-60-H-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n41-PC2-30-60-H-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n41-PC2-30-60-H-DFT-QPSK-Inner_1RB_Left-1000-3000-PAS

S



NTNV-n41-PC2-30-60-H-DFT-QPSK-Inner_1RB_Left-3000-18000-PA

SS



NTNV-n41-PC2-30-60-H-DFT-QPSK-Inner_1RB_Left-18000-30000-PA

SS



NTNV-n41-PC2-30-60-H-DFT-QPSK-Inner_1RB_Right-0.009-0.15-PA

SS



NTNV-n41-PC2-30-60-H-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n41-PC2-30-60-H-DFT-QPSK-Inner_1RB_Right-30-1000-PAS

S



NTNV-n41-PC2-30-60-H-DFT-QPSK-Inner_1RB_Right-1000-3000-PA

SS



NTNV-n41-PC2-30-60-H-DFT-QPSK-Inner_1RB_Right-3000-18000-P

ASS



NTNV-n41-PC2-30-60-H-DFT-QPSK-Inner_1RB_Right-18000-30000-P

ASS



NTNV-n41-PC2-30-70-L-DFT-BPSK-Inner_1RB_Left-0.009-0.15-PAS
S



NTNV-n41-PC2-30-70-L-DFT-BPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n41-PC2-30-70-L-DFT-BPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n41-PC2-30-70-L-DFT-BPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n41-PC2-30-70-L-DFT-BPSK-Inner_1RB_Left-3000-18000-PA
SS




NTNV-n41-PC2-30-70-L-DFT-BPSK-Inner_1RB_Left-18000-30000-PA
SS



NTNV-n41-PC2-30-70-L-DFT-BPSK-Inner_1RB_Right-0.009-0.15-PA
SS



NTNV-n41-PC2-30-70-L-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n41-PC2-30-70-L-DFT-BPSK-Inner_1RB_Right-30-1000-PASS

NTNV-n41-PC2-30-70-L-DFT-BPSK-Inner_1RB_Right-1000-3000-PASS



NTNV-n41-PC2-30-70-L-DFT-BPSK-Inner_1RB_Right-3000-18000-PASS

NTNV-n41-PC2-30-70-L-DFT-BPSK-Inner_1RB_Right-18000-30000-PASS




NTNV-n41-PC2-30-70-L-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PASS

NTNV-n41-PC2-30-70-L-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n41-PC2-30-70-L-DFT-QPSK-Inner_1RB_Left-30-1000-PASS

NTNV-n41-PC2-30-70-L-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n41-PC2-30-70-L-DFT-QPSK-Inner_1RB_Left-3000-18000-PA

SS



NTNV-n41-PC2-30-70-L-DFT-QPSK-Inner_1RB_Left-18000-30000-PA

SS



NTNV-n41-PC2-30-70-L-DFT-QPSK-Inner_1RB_Right-0.009-0.15-PA

SS



NTNV-n41-PC2-30-70-L-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n41-PC2-30-70-L-DFT-QPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n41-PC2-30-70-L-DFT-QPSK-Inner_1RB_Right-1000-3000-PASS

S



NTNV-n41-PC2-30-70-L-DFT-QPSK-Inner_1RB_Right-3000-18000-P

ASS



NTNV-n41-PC2-30-70-L-DFT-QPSK-Inner_1RB_Right-18000-30000-P

ASS



NTNV-n41-PC2-30-70-M-DFT-BPSK-Inner_1RB_Left-0.009-0.15-PAS
S



NTNV-n41-PC2-30-70-M-DFT-BPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n41-PC2-30-70-M-DFT-BPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n41-PC2-30-70-M-DFT-BPSK-Inner_1RB_Left-1000-3000-PAS
S



NTNV-n41-PC2-30-70-M-DFT-BPSK-Inner_1RB_Left-3000-18000-PA
SS




NTNV-n41-PC2-30-70-M-DFT-BPSK-Inner_1RB_Left-18000-30000-PA
SS



NTNV-n41-PC2-30-70-M-DFT-BPSK-Inner_1RB_Right-0.009-0.15-PA
SS



NTNV-n41-PC2-30-70-M-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n41-PC2-30-70-M-DFT-BPSK-Inner_1RB_Right-30-1000-PAS

S



NTNV-n41-PC2-30-70-M-DFT-BPSK-Inner_1RB_Right-1000-3000-PA

SS



NTNV-n41-PC2-30-70-M-DFT-BPSK-Inner_1RB_Right-3000-18000-P

ASS



NTNV-n41-PC2-30-70-M-DFT-BPSK-Inner_1RB_Right-18000-30000-P

ASS



NTNV-n41-PC2-30-70-M-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PA

SS



NTNV-n41-PC2-30-70-M-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n41-PC2-30-70-M-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n41-PC2-30-70-M-DFT-QPSK-Inner_1RB_Left-1000-3000-PAS

S



NTNV-n41-PC2-30-70-M-DFT-QPSK-Inner_1RB_Left-3000-18000-PA

SS



NTNV-n41-PC2-30-70-M-DFT-QPSK-Inner_1RB_Left-18000-30000-PA

SS



NTNV-n41-PC2-30-70-M-DFT-QPSK-Inner_1RB_Right-0.009-0.15-P

ASS



NTNV-n41-PC2-30-70-M-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n41-PC2-30-70-M-DFT-QPSK-Inner_1RB_Right-30-1000-PAS

S



NTNV-n41-PC2-30-70-M-DFT-QPSK-Inner_1RB_Right-1000-3000-PA

SS




NTNV-n41-PC2-30-70-M-DFT-QPSK-Inner_1RB_Right-3000-18000-P

ASS




NTNV-n41-PC2-30-70-M-DFT-QPSK-Inner_1RB_Right-18000-30000-P

ASS


NTNV-n41-PC2-30-70-H-DFT-BPSK-Inner_1RB_Left-0.009-0.15-PAS
S


NTNV-n41-PC2-30-70-H-DFT-BPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n41-PC2-30-70-H-DFT-BPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n41-PC2-30-70-H-DFT-BPSK-Inner_1RB_Left-1000-3000-PASS


NTNV-n41-PC2-30-70-H-DFT-BPSK-Inner_1RB_Left-3000-18000-PA
SS

NTNV-n41-PC2-30-70-H-DFT-BPSK-Inner_1RB_Left-18000-30000-PA
SS

NTNV-n41-PC2-30-70-H-DFT-BPSK-Inner_1RB_Right-0.009-0.15-PA
SS


NTNV-n41-PC2-30-70-H-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS




NTNV-n41-PC2-30-70-H-DFT-BPSK-Inner_1RB_Right-30-1000-PAS

S



NTNV-n41-PC2-30-70-H-DFT-BPSK-Inner_1RB_Right-1000-3000-PAS

S



NTNV-n41-PC2-30-70-H-DFT-BPSK-Inner_1RB_Right-3000-18000-P

ASS



NTNV-n41-PC2-30-70-H-DFT-BPSK-Inner_1RB_Right-18000-30000-P

ASS



NTNV-n41-PC2-30-70-H-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PAS

S



NTNV-n41-PC2-30-70-H-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS




NTNV-n41-PC2-30-70-H-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n41-PC2-30-70-H-DFT-QPSK-Inner_1RB_Left-1000-3000-PAS

S



NTNV-n41-PC2-30-70-H-DFT-QPSK-Inner_1RB_Left-3000-18000-PA

SS



NTNV-n41-PC2-30-70-H-DFT-QPSK-Inner_1RB_Left-18000-30000-PA

SS



NTNV-n41-PC2-30-70-H-DFT-QPSK-Inner_1RB_Right-0.009-0.15-PA

SS



NTNV-n41-PC2-30-70-H-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n41-PC2-30-70-H-DFT-QPSK-Inner_1RB_Right-30-1000-PAS

S



NTNV-n41-PC2-30-70-H-DFT-QPSK-Inner_1RB_Right-1000-3000-PA

SS



NTNV-n41-PC2-30-70-H-DFT-QPSK-Inner_1RB_Right-3000-18000-P

ASS




NTNV-n41-PC2-30-70-H-DFT-QPSK-Inner_1RB_Right-18000-30000-P

ASS



NTNV-n41-PC2-30-80-L-DFT-BPSK-Inner_1RB_Left-0.009-0.15-PAS
S



NTNV-n41-PC2-30-80-L-DFT-BPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n41-PC2-30-80-L-DFT-BPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n41-PC2-30-80-L-DFT-BPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n41-PC2-30-80-L-DFT-BPSK-Inner_1RB_Left-3000-18000-PA
SS



NTNV-n41-PC2-30-80-L-DFT-BPSK-Inner_1RB_Left-18000-30000-PA
SS



NTNV-n41-PC2-30-80-L-DFT-BPSK-Inner_1RB_Right-0.009-0.15-PA
SS



NTNV-n41-PC2-30-80-L-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n41-PC2-30-80-L-DFT-BPSK-Inner_1RB_Right-30-1000-PASS


NTNV-n41-PC2-30-80-L-DFT-BPSK-Inner_1RB_Right-1000-3000-PASS
S

NTNV-n41-PC2-30-80-L-DFT-BPSK-Inner_1RB_Right-3000-18000-P
ASS

NTNV-n41-PC2-30-80-L-DFT-BPSK-Inner_1RB_Right-18000-30000-P
ASS

NTNV-n41-PC2-30-80-L-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PAS
S


NTNV-n41-PC2-30-80-L-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n41-PC2-30-80-L-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n41-PC2-30-80-L-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n41-PC2-30-80-L-DFT-QPSK-Inner_1RB_Left-3000-18000-PA

SS



NTNV-n41-PC2-30-80-L-DFT-QPSK-Inner_1RB_Left-18000-30000-PA

SS



NTNV-n41-PC2-30-80-L-DFT-QPSK-Inner_1RB_Right-0.009-0.15-PA

SS



NTNV-n41-PC2-30-80-L-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n41-PC2-30-80-L-DFT-QPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n41-PC2-30-80-L-DFT-QPSK-Inner_1RB_Right-1000-3000-PAS

S




NTNV-n41-PC2-30-80-L-DFT-QPSK-Inner_1RB_Right-3000-18000-P

ASS



NTNV-n41-PC2-30-80-L-DFT-QPSK-Inner_1RB_Right-18000-30000-P

ASS


NTNV-n41-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-0.009-0.15-PAS
S


NTNV-n41-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n41-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n41-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-1000-3000-PAS
S

NTNV-n41-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-3000-18000-PA
SS

NTNV-n41-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-18000-30000-PA
SS

NTNV-n41-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-0.009-0.15-PA
SS


NTNV-n41-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n41-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-30-1000-PAS

S



NTNV-n41-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-1000-3000-PA

SS



NTNV-n41-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-3000-18000-P

ASS



NTNV-n41-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-18000-30000-P

ASS



NTNV-n41-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PA

SS



NTNV-n41-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n41-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n41-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-1000-3000-PAS

S



NTNV-n41-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-3000-18000-PA
SS



NTNV-n41-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-18000-30000-PA
SS



NTNV-n41-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-0.009-0.15-P
ASS



NTNV-n41-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n41-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-30-1000-PAS
S



NTNV-n41-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-1000-3000-PA
SS




NTNV-n41-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-3000-18000-P
ASS




NTNV-n41-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-18000-30000-P
ASS



NTNV-n41-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-0.009-0.15-PAS
S



NTNV-n41-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n41-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n41-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n41-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-3000-18000-PA
SS



NTNV-n41-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-18000-30000-PA
SS



NTNV-n41-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-0.009-0.15-PA
SS



NTNV-n41-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS