




NTNV-n78(3450-3550)-PC2-30-60-H-CP-QPSK-Inner_1RB_Right
-1000-3000-PASS

NTNV-n78(3450-3550)-PC2-30-60-H-CP-QPSK-Inner_1RB_Right-
3000-6000-PASS

NTNV-n78(3450-3550)-PC2-30-60-H-CP-QPSK-Inner_1RB_Right
-6000-20000-PASS


NTNV-n78(3450-3550)-PC2-30-60-H-CP-QPSK-Inner_1RB_Right-
20000-40000-PASS

NTNV-n78(3450-3550)-PC2-30-70-L-CP-QPSK-Inner_1RB_Left-0
.009-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-70-L-CP-QPSK-Inner_1RB_Left-0.
15-30-PASS


NTNV-n78(3450-3550)-PC2-30-70-L-CP-QPSK-Inner_1RB_Left-3
0-1000-PASS

NTNV-n78(3450-3550)-PC2-30-70-L-CP-QPSK-Inner_1RB_Left-10
00-3000-PASS


NTNV-n78(3450-3550)-PC2-30-70-L-CP-QPSK-Inner_1RB_Left-3
000-6000-PASS


NTNV-n78(3450-3550)-PC2-30-70-L-CP-QPSK-Inner_1RB_Left-60
00-20000-PASS

NTNV-n78(3450-3550)-PC2-30-70-L-CP-QPSK-Inner_1RB_Left-2
0000-40000-PASS

NTNV-n78(3450-3550)-PC2-30-70-L-CP-QPSK-Inner_1RB_Right-0
.009-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-70-L-CP-QPSK-Inner_1RB_Right-
0.15-30-PASS

NTNV-n78(3450-3550)-PC2-30-70-L-CP-QPSK-Inner_1RB_Right-3
0-1000-PASS

NTNV-n78(3450-3550)-PC2-30-70-L-CP-QPSK-Inner_1RB_Right-
1000-3000-PASS


NTNV-n78(3450-3550)-PC2-30-70-L-CP-QPSK-Inner_1RB_Right-3
000-6000-PASS




NTNV-n78(3450-3550)-PC2-30-70-L-CP-QPSK-Inner_1RB_Right-6000-20000-PASS




NTNV-n78(3450-3550)-PC2-30-70-L-CP-QPSK-Inner_1RB_Right-20000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-70-M-CP-QPSK-Inner_1RB_Left-0.009-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-70-M-CP-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-70-M-CP-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-70-M-CP-QPSK-Inner_1RB_Left-1000-3000-PASS




NTNV-n78(3450-3550)-PC2-30-70-M-CP-QPSK-Inner_1RB_Left-3000-6000-PASS



NTNV-n78(3450-3550)-PC2-30-70-M-CP-QPSK-Inner_1RB_Left-6000-20000-PASS




NTNV-n78(3450-3550)-PC2-30-70-M-CP-QPSK-Inner_1RB_Left-20000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-70-M-CP-QPSK-Inner_1RB_Right-0.009-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-70-M-CP-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-70-M-CP-QPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-70-M-CP-QPSK-Inner_1RB_Right-1000-3000-PASS




NTNV-n78(3450-3550)-PC2-30-70-M-CP-QPSK-Inner_1RB_Right-3000-6000-PASS



NTNV-n78(3450-3550)-PC2-30-70-M-CP-QPSK-Inner_1RB_Right-6000-20000-PASS




NTNV-n78(3450-3550)-PC2-30-70-M-CP-QPSK-Inner_1RB_Right-20000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-70-H-CP-QPSK-Inner_1RB_Left-0
 .009-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-70-H-CP-QPSK-Inner_1RB_Left-0.
 15-30-PASS




NTNV-n78(3450-3550)-PC2-30-70-H-CP-QPSK-Inner_1RB_Left-3
 0-1000-PASS



NTNV-n78(3450-3550)-PC2-30-70-H-CP-QPSK-Inner_1RB_Left-1
 000-3000-PASS



NTNV-n78(3450-3550)-PC2-30-70-H-CP-QPSK-Inner_1RB_Left-3
 000-6000-PASS




NTNV-n78(3450-3550)-PC2-30-70-H-CP-QPSK-Inner_1RB_Left-6
 000-20000-PASS



NTNV-n78(3450-3550)-PC2-30-70-H-CP-QPSK-Inner_1RB_Left-2
 0000-40000-PASS




NTNV-n78(3450-3550)-PC2-30-70-H-CP-QPSK-Inner_1RB_Right-
 0.009-0.15-PASS


NTNV-n78(3450-3550)-PC2-30-70-H-CP-QPSK-Inner_1RB_Right
-0.15-30-PASS

NTNV-n78(3450-3550)-PC2-30-70-H-CP-QPSK-Inner_1RB_Right-
30-1000-PASS

NTNV-n78(3450-3550)-PC2-30-70-H-CP-QPSK-Inner_1RB_Right
-1000-3000-PASS

NTNV-n78(3450-3550)-PC2-30-70-H-CP-QPSK-Inner_1RB_Right-
3000-6000-PASS

NTNV-n78(3450-3550)-PC2-30-70-H-CP-QPSK-Inner_1RB_Right
-6000-20000-PASS

NTNV-n78(3450-3550)-PC2-30-70-H-CP-QPSK-Inner_1RB_Right-
20000-40000-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-CP-QPSK-Inner_1RB_Left-0
.009-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-CP-QPSK-Inner_1RB_Left-0.
15-30-PASS



NTNV-n78(3450-3550)-PC2-30-80-L-CP-QPSK-Inner_1RB_Left-3
0-1000-PASS



NTNV-n78(3450-3550)-PC2-30-80-L-CP-QPSK-Inner_1RB_Left-10
00-3000-PASS




NTNV-n78(3450-3550)-PC2-30-80-L-CP-QPSK-Inner_1RB_Left-3
000-6000-PASS



NTNV-n78(3450-3550)-PC2-30-80-L-CP-QPSK-Inner_1RB_Left-60
00-20000-PASS



NTNV-n78(3450-3550)-PC2-30-80-L-CP-QPSK-Inner_1RB_Left-2
0000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-80-L-CP-QPSK-Inner_1RB_Right-0
.009-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-80-L-CP-QPSK-Inner_1RB_Right-
0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-80-L-CP-QPSK-Inner_1RB_Right-3
0-1000-PASS



NTNV-n78(3450-3550)-PC2-30-80-L-CP-QPSK-Inner_1RB_Right-1000-3000-PASS




NTNV-n78(3450-3550)-PC2-30-80-L-CP-QPSK-Inner_1RB_Right-3000-6000-PASS




NTNV-n78(3450-3550)-PC2-30-80-L-CP-QPSK-Inner_1RB_Right-6000-20000-PASS



NTNV-n78(3450-3550)-PC2-30-80-L-CP-QPSK-Inner_1RB_Right-20000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-CP-QPSK-Inner_1RB_Left-0.009-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-CP-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-CP-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-CP-QPSK-Inner_1RB_Left-1000-3000-PASS




NTNV-n78(3450-3550)-PC2-30-80-M-CP-QPSK-Inner_1RB_Left-3000-6000-PASS




NTNV-n78(3450-3550)-PC2-30-80-M-CP-QPSK-Inner_1RB_Left-6000-20000-PASS




NTNV-n78(3450-3550)-PC2-30-80-M-CP-QPSK-Inner_1RB_Left-20000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-CP-QPSK-Inner_1RB_Right-0.009-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-CP-QPSK-Inner_1RB_Right-0.15-30-PASS




NTNV-n78(3450-3550)-PC2-30-80-M-CP-QPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-CP-QPSK-Inner_1RB_Right-1000-3000-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-CP-QPSK-Inner_1RB_Right-3000-6000-PASS


NTNV-n78(3450-3550)-PC2-30-80-M-CP-QPSK-Inner_1RB_Right
-6000-20000-PASS

NTNV-n78(3450-3550)-PC2-30-80-M-CP-QPSK-Inner_1RB_Right-
20000-40000-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-CP-QPSK-Inner_1RB_Left-0
.009-0.15-PASS


NTNV-n78(3450-3550)-PC2-30-80-H-CP-QPSK-Inner_1RB_Left-0.
15-30-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-CP-QPSK-Inner_1RB_Left-3
0-1000-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-CP-QPSK-Inner_1RB_Left-1
000-3000-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-CP-QPSK-Inner_1RB_Left-3
000-6000-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-CP-QPSK-Inner_1RB_Left-6
000-20000-PASS


NTNV-n78(3450-3550)-PC2-30-80-H-CP-QPSK-Inner_1RB_Left-2
0000-40000-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-CP-QPSK-Inner_1RB_Right-
0.009-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-CP-QPSK-Inner_1RB_Right
-0.15-30-PASS


NTNV-n78(3450-3550)-PC2-30-80-H-CP-QPSK-Inner_1RB_Right-
30-1000-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-CP-QPSK-Inner_1RB_Right
-1000-3000-PASS


NTNV-n78(3450-3550)-PC2-30-80-H-CP-QPSK-Inner_1RB_Right-
3000-6000-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-CP-QPSK-Inner_1RB_Right
-6000-20000-PASS


NTNV-n78(3450-3550)-PC2-30-80-H-CP-QPSK-Inner_1RB_Right-
20000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-90-L-CP-QPSK-Inner_1RB_Left-0.009-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-90-L-CP-QPSK-Inner_1RB_Left-0.15-30-PASS




NTNV-n78(3450-3550)-PC2-30-90-L-CP-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-90-L-CP-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n78(3450-3550)-PC2-30-90-L-CP-QPSK-Inner_1RB_Left-3000-6000-PASS




NTNV-n78(3450-3550)-PC2-30-90-L-CP-QPSK-Inner_1RB_Left-6000-20000-PASS



NTNV-n78(3450-3550)-PC2-30-90-L-CP-QPSK-Inner_1RB_Left-20000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-90-L-CP-QPSK-Inner_1RB_Right-0.009-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-90-L-CP-QPSK-Inner_1RB_Right-0.15-30-PASS




NTNV-n78(3450-3550)-PC2-30-90-L-CP-QPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-90-L-CP-QPSK-Inner_1RB_Right-1000-3000-PASS



NTNV-n78(3450-3550)-PC2-30-90-L-CP-QPSK-Inner_1RB_Right-3000-6000-PASS



NTNV-n78(3450-3550)-PC2-30-90-L-CP-QPSK-Inner_1RB_Right-6000-20000-PASS



NTNV-n78(3450-3550)-PC2-30-90-L-CP-QPSK-Inner_1RB_Right-20000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-90-M-CP-QPSK-Inner_1RB_Left-0.009-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-90-M-CP-QPSK-Inner_1RB_Left-0.15-30-PASS




NTNV-n78(3450-3550)-PC2-30-90-M-CP-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-90-M-CP-QPSK-Inner_1RB_Left-1000-3000-PASS




NTNV-n78(3450-3550)-PC2-30-90-M-CP-QPSK-Inner_1RB_Left-3000-6000-PASS



NTNV-n78(3450-3550)-PC2-30-90-M-CP-QPSK-Inner_1RB_Left-6000-20000-PASS



NTNV-n78(3450-3550)-PC2-30-90-M-CP-QPSK-Inner_1RB_Left-20000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-90-M-CP-QPSK-Inner_1RB_Right-0.009-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-90-M-CP-QPSK-Inner_1RB_Right-0.15-30-PASS





NTNV-n78(3450-3550)-PC2-30-90-M-CP-QPSK-Inner_1RB_Right-30-1000-PASS


NTNV-n78(3450-3550)-PC2-30-90-M-CP-QPSK-Inner_1RB_Right
-1000-3000-PASS

NTNV-n78(3450-3550)-PC2-30-90-M-CP-QPSK-Inner_1RB_Right-
3000-6000-PASS

NTNV-n78(3450-3550)-PC2-30-90-M-CP-QPSK-Inner_1RB_Right
-6000-20000-PASS




NTNV-n78(3450-3550)-PC2-30-90-M-CP-QPSK-Inner_1RB_Right-
20000-40000-PASS

NTNV-n78(3450-3550)-PC2-30-90-H-CP-QPSK-Inner_1RB_Left-0
.009-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-90-H-CP-QPSK-Inner_1RB_Left-0.
15-30-PASS

NTNV-n78(3450-3550)-PC2-30-90-H-CP-QPSK-Inner_1RB_Left-3
0-1000-PASS

NTNV-n78(3450-3550)-PC2-30-90-H-CP-QPSK-Inner_1RB_Left-1
000-3000-PASS


NTNV-n78(3450-3550)-PC2-30-90-H-CP-QPSK-Inner_1RB_Left-3
000-6000-PASS

NTNV-n78(3450-3550)-PC2-30-90-H-CP-QPSK-Inner_1RB_Left-6
000-20000-PASS



NTNV-n78(3450-3550)-PC2-30-90-H-CP-QPSK-Inner_1RB_Left-2
0000-40000-PASS

NTNV-n78(3450-3550)-PC2-30-90-H-CP-QPSK-Inner_1RB_Right-
0.009-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-90-H-CP-QPSK-Inner_1RB_Right
-0.15-30-PASS

NTNV-n78(3450-3550)-PC2-30-90-H-CP-QPSK-Inner_1RB_Right-
30-1000-PASS

NTNV-n78(3450-3550)-PC2-30-90-H-CP-QPSK-Inner_1RB_Right
-1000-3000-PASS

NTNV-n78(3450-3550)-PC2-30-90-H-CP-QPSK-Inner_1RB_Right-
3000-6000-PASS


NTNV-n78(3450-3550)-PC2-30-90-H-CP-QPSK-Inner_1RB_Right
-6000-20000-PASS

NTNV-n78(3450-3550)-PC2-30-90-H-CP-QPSK-Inner_1RB_Right-
20000-40000-PASS

NTNV-n78(3450-3550)-PC2-30-100-L-CP-QPSK-Inner_1RB_Left-
0.009-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-100-L-CP-QPSK-Inner_1RB_Left-0
.15-30-PASS

NTNV-n78(3450-3550)-PC2-30-100-L-CP-QPSK-Inner_1RB_Left-
30-1000-PASS


NTNV-n78(3450-3550)-PC2-30-100-L-CP-QPSK-Inner_1RB_Left-1
000-3000-PASS

NTNV-n78(3450-3550)-PC2-30-100-L-CP-QPSK-Inner_1RB_Left-
3000-6000-PASS

NTNV-n78(3450-3550)-PC2-30-100-L-CP-QPSK-Inner_1RB_Left-6
000-20000-PASS




NTNV-n78(3450-3550)-PC2-30-100-L-CP-QPSK-Inner_1RB_Left-20000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-100-L-CP-QPSK-Inner_1RB_Right-0.009-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-100-L-CP-QPSK-Inner_1RB_Right-t0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-100-L-CP-QPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-100-L-CP-QPSK-Inner_1RB_Right-t1000-3000-PASS



NTNV-n78(3450-3550)-PC2-30-100-L-CP-QPSK-Inner_1RB_Right-3000-6000-PASS



NTNV-n78(3450-3550)-PC2-30-100-L-CP-QPSK-Inner_1RB_Right-t6000-20000-PASS



NTNV-n78(3450-3550)-PC2-30-100-L-CP-QPSK-Inner_1RB_Right-20000-40000-PASS