






NTNV-n78(3700-3800)-PC2-30-30-H-CP-QPSK-Inner_1RB_Left-0.009-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-30-H-CP-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n78(3700-3800)-PC2-30-30-H-CP-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3700-3800)-PC2-30-30-H-CP-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n78(3700-3800)-PC2-30-30-H-CP-QPSK-Inner_1RB_Left-3000-6000-PASS




NTNV-n78(3700-3800)-PC2-30-30-H-CP-QPSK-Inner_1RB_Left-6000-26000-PASS



NTNV-n78(3700-3800)-PC2-30-30-H-CP-QPSK-Inner_1RB_Left-26000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-30-H-CP-QPSK-Inner_1RB_Right-0.009-0.15-PASS


NTNV-n78(3700-3800)-PC2-30-30-H-CP-QPSK-Inner_1RB_Right
-0.15-30-PASS

NTNV-n78(3700-3800)-PC2-30-30-H-CP-QPSK-Inner_1RB_Right-
30-1000-PASS

NTNV-n78(3700-3800)-PC2-30-30-H-CP-QPSK-Inner_1RB_Right
-1000-3000-PASS

NTNV-n78(3700-3800)-PC2-30-30-H-CP-QPSK-Inner_1RB_Right-
3000-6000-PASS

NTNV-n78(3700-3800)-PC2-30-30-H-CP-QPSK-Inner_1RB_Right
-6000-26000-PASS

NTNV-n78(3700-3800)-PC2-30-30-H-CP-QPSK-Inner_1RB_Right-
26000-40000-PASS

NTNV-n78(3700-3800)-PC2-30-40-L-CP-QPSK-Inner_1RB_Left-0
.009-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-40-L-CP-QPSK-Inner_1RB_Left-0.
15-30-PASS



NTNV-n78(3700-3800)-PC2-30-40-L-CP-QPSK-Inner_1RB_Left-3
0-1000-PASS



NTNV-n78(3700-3800)-PC2-30-40-L-CP-QPSK-Inner_1RB_Left-10
00-3000-PASS




NTNV-n78(3700-3800)-PC2-30-40-L-CP-QPSK-Inner_1RB_Left-3
000-6000-PASS



NTNV-n78(3700-3800)-PC2-30-40-L-CP-QPSK-Inner_1RB_Left-60
00-26000-PASS




NTNV-n78(3700-3800)-PC2-30-40-L-CP-QPSK-Inner_1RB_Left-2
6000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-40-L-CP-QPSK-Inner_1RB_Right-0
.009-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-40-L-CP-QPSK-Inner_1RB_Right-
0.15-30-PASS



NTNV-n78(3700-3800)-PC2-30-40-L-CP-QPSK-Inner_1RB_Right-3
0-1000-PASS



NTNV-n78(3700-3800)-PC2-30-40-L-CP-QPSK-Inner_1RB_Right-1000-3000-PASS




NTNV-n78(3700-3800)-PC2-30-40-L-CP-QPSK-Inner_1RB_Right-3000-6000-PASS



NTNV-n78(3700-3800)-PC2-30-40-L-CP-QPSK-Inner_1RB_Right-6000-26000-PASS



NTNV-n78(3700-3800)-PC2-30-40-L-CP-QPSK-Inner_1RB_Right-26000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-40-M-CP-QPSK-Inner_1RB_Left-0.009-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-40-M-CP-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n78(3700-3800)-PC2-30-40-M-CP-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3700-3800)-PC2-30-40-M-CP-QPSK-Inner_1RB_Left-1000-3000-PASS




NTNV-n78(3700-3800)-PC2-30-40-M-CP-QPSK-Inner_1RB_Left-3000-6000-PASS




NTNV-n78(3700-3800)-PC2-30-40-M-CP-QPSK-Inner_1RB_Left-6000-26000-PASS




NTNV-n78(3700-3800)-PC2-30-40-M-CP-QPSK-Inner_1RB_Left-26000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-40-M-CP-QPSK-Inner_1RB_Right-0.009-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-40-M-CP-QPSK-Inner_1RB_Right-0.15-30-PASS




NTNV-n78(3700-3800)-PC2-30-40-M-CP-QPSK-Inner_1RB_Right-30-1000-PASS






NTNV-n78(3700-3800)-PC2-30-40-M-CP-QPSK-Inner_1RB_Right-1000-3000-PASS



NTNV-n78(3700-3800)-PC2-30-40-M-CP-QPSK-Inner_1RB_Right-3000-6000-PASS



NTNV-n78(3700-3800)-PC2-30-40-M-CP-QPSK-Inner_1RB_Right
-6000-26000-PASS

NTNV-n78(3700-3800)-PC2-30-40-M-CP-QPSK-Inner_1RB_Right-
26000-40000-PASS

NTNV-n78(3700-3800)-PC2-30-40-H-CP-QPSK-Inner_1RB_Left-0
.009-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-40-H-CP-QPSK-Inner_1RB_Left-0.
15-30-PASS

NTNV-n78(3700-3800)-PC2-30-40-H-CP-QPSK-Inner_1RB_Left-3
0-1000-PASS

NTNV-n78(3700-3800)-PC2-30-40-H-CP-QPSK-Inner_1RB_Left-1
000-3000-PASS

NTNV-n78(3700-3800)-PC2-30-40-H-CP-QPSK-Inner_1RB_Left-3
000-6000-PASS

NTNV-n78(3700-3800)-PC2-30-40-H-CP-QPSK-Inner_1RB_Left-6
000-26000-PASS


NTNV-n78(3700-3800)-PC2-30-40-H-CP-QPSK-Inner_1RB_Left-2
6000-40000-PASS

NTNV-n78(3700-3800)-PC2-30-40-H-CP-QPSK-Inner_1RB_Right-
0.009-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-40-H-CP-QPSK-Inner_1RB_Right
-0.15-30-PASS


NTNV-n78(3700-3800)-PC2-30-40-H-CP-QPSK-Inner_1RB_Right-
30-1000-PASS

NTNV-n78(3700-3800)-PC2-30-40-H-CP-QPSK-Inner_1RB_Right
-1000-3000-PASS


NTNV-n78(3700-3800)-PC2-30-40-H-CP-QPSK-Inner_1RB_Right-
3000-6000-PASS

NTNV-n78(3700-3800)-PC2-30-40-H-CP-QPSK-Inner_1RB_Right
-6000-26000-PASS

NTNV-n78(3700-3800)-PC2-30-40-H-CP-QPSK-Inner_1RB_Right-
26000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-50-L-CP-QPSK-Inner_1RB_Left-0.009-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-50-L-CP-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n78(3700-3800)-PC2-30-50-L-CP-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3700-3800)-PC2-30-50-L-CP-QPSK-Inner_1RB_Left-1000-3000-PASS




NTNV-n78(3700-3800)-PC2-30-50-L-CP-QPSK-Inner_1RB_Left-3000-6000-PASS




NTNV-n78(3700-3800)-PC2-30-50-L-CP-QPSK-Inner_1RB_Left-6000-26000-PASS



NTNV-n78(3700-3800)-PC2-30-50-L-CP-QPSK-Inner_1RB_Left-26000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-50-L-CP-QPSK-Inner_1RB_Right-0.009-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-50-L-CP-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n78(3700-3800)-PC2-30-50-L-CP-QPSK-Inner_1RB_Right-3 0-1000-PASS



NTNV-n78(3700-3800)-PC2-30-50-L-CP-QPSK-Inner_1RB_Right-1000-3000-PASS



NTNV-n78(3700-3800)-PC2-30-50-L-CP-QPSK-Inner_1RB_Right-3 000-6000-PASS



NTNV-n78(3700-3800)-PC2-30-50-L-CP-QPSK-Inner_1RB_Right-6000-26000-PASS



NTNV-n78(3700-3800)-PC2-30-50-L-CP-QPSK-Inner_1RB_Right-2 6000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-50-M-CP-QPSK-Inner_1RB_Left-0.009-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-50-M-CP-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n78(3700-3800)-PC2-30-50-M-CP-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3700-3800)-PC2-30-50-M-CP-QPSK-Inner_1RB_Left-1000-3000-PASS




NTNV-n78(3700-3800)-PC2-30-50-M-CP-QPSK-Inner_1RB_Left-3000-6000-PASS



NTNV-n78(3700-3800)-PC2-30-50-M-CP-QPSK-Inner_1RB_Left-6000-26000-PASS



NTNV-n78(3700-3800)-PC2-30-50-M-CP-QPSK-Inner_1RB_Left-26000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-50-M-CP-QPSK-Inner_1RB_Right-0.009-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-50-M-CP-QPSK-Inner_1RB_Right-0.15-30-PASS





NTNV-n78(3700-3800)-PC2-30-50-M-CP-QPSK-Inner_1RB_Right-30-1000-PASS


NTNV-n78(3700-3800)-PC2-30-50-M-CP-QPSK-Inner_1RB_Right
-1000-3000-PASS

NTNV-n78(3700-3800)-PC2-30-50-M-CP-QPSK-Inner_1RB_Right-
3000-6000-PASS

NTNV-n78(3700-3800)-PC2-30-50-M-CP-QPSK-Inner_1RB_Right
-6000-26000-PASS


NTNV-n78(3700-3800)-PC2-30-50-M-CP-QPSK-Inner_1RB_Right-
26000-40000-PASS

NTNV-n78(3700-3800)-PC2-30-50-H-CP-QPSK-Inner_1RB_Left-0
.009-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-50-H-CP-QPSK-Inner_1RB_Left-0.
15-30-PASS

NTNV-n78(3700-3800)-PC2-30-50-H-CP-QPSK-Inner_1RB_Left-3
0-1000-PASS

NTNV-n78(3700-3800)-PC2-30-50-H-CP-QPSK-Inner_1RB_Left-1
000-3000-PASS


NTNV-n78(3700-3800)-PC2-30-50-H-CP-QPSK-Inner_1RB_Left-3
000-6000-PASS

NTNV-n78(3700-3800)-PC2-30-50-H-CP-QPSK-Inner_1RB_Left-6
000-26000-PASS


NTNV-n78(3700-3800)-PC2-30-50-H-CP-QPSK-Inner_1RB_Left-2
6000-40000-PASS

NTNV-n78(3700-3800)-PC2-30-50-H-CP-QPSK-Inner_1RB_Right-
0.009-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-50-H-CP-QPSK-Inner_1RB_Right
-0.15-30-PASS

NTNV-n78(3700-3800)-PC2-30-50-H-CP-QPSK-Inner_1RB_Right-
30-1000-PASS


NTNV-n78(3700-3800)-PC2-30-50-H-CP-QPSK-Inner_1RB_Right
-1000-3000-PASS

NTNV-n78(3700-3800)-PC2-30-50-H-CP-QPSK-Inner_1RB_Right-
3000-6000-PASS


NTNV-n78(3700-3800)-PC2-30-50-H-CP-QPSK-Inner_1RB_Right
-6000-26000-PASS

NTNV-n78(3700-3800)-PC2-30-50-H-CP-QPSK-Inner_1RB_Right-
26000-40000-PASS


NTNV-n78(3700-3800)-PC2-30-60-L-CP-QPSK-Inner_1RB_Left-0
.009-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-60-L-CP-QPSK-Inner_1RB_Left-0.
15-30-PASS

NTNV-n78(3700-3800)-PC2-30-60-L-CP-QPSK-Inner_1RB_Left-3
0-1000-PASS


NTNV-n78(3700-3800)-PC2-30-60-L-CP-QPSK-Inner_1RB_Left-10
00-3000-PASS

NTNV-n78(3700-3800)-PC2-30-60-L-CP-QPSK-Inner_1RB_Left-3
000-6000-PASS

NTNV-n78(3700-3800)-PC2-30-60-L-CP-QPSK-Inner_1RB_Left-60
00-26000-PASS


NTNV-n78(3700-3800)-PC2-30-60-L-CP-QPSK-Inner_1RB_Left-2
6000-40000-PASS

NTNV-n78(3700-3800)-PC2-30-60-L-CP-QPSK-Inner_1RB_Right-0
.009-0.15-PASS


NTNV-n78(3700-3800)-PC2-30-60-L-CP-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n78(3700-3800)-PC2-30-60-L-CP-QPSK-Inner_1RB_Right-3
0-1000-PASS


NTNV-n78(3700-3800)-PC2-30-60-L-CP-QPSK-Inner_1RB_Right-1000-3000-PASS



NTNV-n78(3700-3800)-PC2-30-60-L-CP-QPSK-Inner_1RB_Right-3
000-6000-PASS


NTNV-n78(3700-3800)-PC2-30-60-L-CP-QPSK-Inner_1RB_Right-6000-26000-PASS


NTNV-n78(3700-3800)-PC2-30-60-L-CP-QPSK-Inner_1RB_Right-2
6000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-60-M-CP-QPSK-Inner_1RB_Left-0.009-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-60-M-CP-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n78(3700-3800)-PC2-30-60-M-CP-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3700-3800)-PC2-30-60-M-CP-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n78(3700-3800)-PC2-30-60-M-CP-QPSK-Inner_1RB_Left-3000-6000-PASS




NTNV-n78(3700-3800)-PC2-30-60-M-CP-QPSK-Inner_1RB_Left-6000-26000-PASS



NTNV-n78(3700-3800)-PC2-30-60-M-CP-QPSK-Inner_1RB_Left-26000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-60-M-CP-QPSK-Inner_1RB_Right-0.009-0.15-PASS


NTNV-n78(3700-3800)-PC2-30-60-M-CP-QPSK-Inner_1RB_Right
-0.15-30-PASS

NTNV-n78(3700-3800)-PC2-30-60-M-CP-QPSK-Inner_1RB_Right-
30-1000-PASS

NTNV-n78(3700-3800)-PC2-30-60-M-CP-QPSK-Inner_1RB_Right
-1000-3000-PASS

NTNV-n78(3700-3800)-PC2-30-60-M-CP-QPSK-Inner_1RB_Right-
3000-6000-PASS

NTNV-n78(3700-3800)-PC2-30-60-M-CP-QPSK-Inner_1RB_Right
-6000-26000-PASS

NTNV-n78(3700-3800)-PC2-30-60-M-CP-QPSK-Inner_1RB_Right-
26000-40000-PASS

NTNV-n78(3700-3800)-PC2-30-60-H-CP-QPSK-Inner_1RB_Left-0
.009-0.15-PASS


NTNV-n78(3700-3800)-PC2-30-60-H-CP-QPSK-Inner_1RB_Left-0.
15-30-PASS


NTNV-n78(3700-3800)-PC2-30-60-H-CP-QPSK-Inner_1RB_Left-3
0-1000-PASS

NTNV-n78(3700-3800)-PC2-30-60-H-CP-QPSK-Inner_1RB_Left-1
000-3000-PASS

NTNV-n78(3700-3800)-PC2-30-60-H-CP-QPSK-Inner_1RB_Left-3
000-6000-PASS

NTNV-n78(3700-3800)-PC2-30-60-H-CP-QPSK-Inner_1RB_Left-6
000-26000-PASS

NTNV-n78(3700-3800)-PC2-30-60-H-CP-QPSK-Inner_1RB_Left-2
6000-40000-PASS

NTNV-n78(3700-3800)-PC2-30-60-H-CP-QPSK-Inner_1RB_Right-
0.009-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-60-H-CP-QPSK-Inner_1RB_Right
-0.15-30-PASS

NTNV-n78(3700-3800)-PC2-30-60-H-CP-QPSK-Inner_1RB_Right-
30-1000-PASS


NTNV-n78(3700-3800)-PC2-30-60-H-CP-QPSK-Inner_1RB_Right
-1000-3000-PASS

NTNV-n78(3700-3800)-PC2-30-60-H-CP-QPSK-Inner_1RB_Right-
3000-6000-PASS

NTNV-n78(3700-3800)-PC2-30-60-H-CP-QPSK-Inner_1RB_Right
-6000-26000-PASS


NTNV-n78(3700-3800)-PC2-30-60-H-CP-QPSK-Inner_1RB_Right-
26000-40000-PASS

NTNV-n78(3700-3800)-PC2-30-70-L-CP-QPSK-Inner_1RB_Left-0
.009-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-70-L-CP-QPSK-Inner_1RB_Left-0.
15-30-PASS


NTNV-n78(3700-3800)-PC2-30-70-L-CP-QPSK-Inner_1RB_Left-3
0-1000-PASS

NTNV-n78(3700-3800)-PC2-30-70-L-CP-QPSK-Inner_1RB_Left-10
00-3000-PASS


NTNV-n78(3700-3800)-PC2-30-70-L-CP-QPSK-Inner_1RB_Left-3
000-6000-PASS


NTNV-n78(3700-3800)-PC2-30-70-L-CP-QPSK-Inner_1RB_Left-60
00-26000-PASS

NTNV-n78(3700-3800)-PC2-30-70-L-CP-QPSK-Inner_1RB_Left-2
6000-40000-PASS

NTNV-n78(3700-3800)-PC2-30-70-L-CP-QPSK-Inner_1RB_Right-0
.009-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-70-L-CP-QPSK-Inner_1RB_Right-
0.15-30-PASS

NTNV-n78(3700-3800)-PC2-30-70-L-CP-QPSK-Inner_1RB_Right-3
0-1000-PASS

NTNV-n78(3700-3800)-PC2-30-70-L-CP-QPSK-Inner_1RB_Right-
1000-3000-PASS


NTNV-n78(3700-3800)-PC2-30-70-L-CP-QPSK-Inner_1RB_Right-3
000-6000-PASS




NTNV-n78(3700-3800)-PC2-30-70-L-CP-QPSK-Inner_1RB_Right-6000-26000-PASS




NTNV-n78(3700-3800)-PC2-30-70-L-CP-QPSK-Inner_1RB_Right-2-6000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-70-M-CP-QPSK-Inner_1RB_Left-0.009-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-70-M-CP-QPSK-Inner_1RB_Left-0-15-30-PASS



NTNV-n78(3700-3800)-PC2-30-70-M-CP-QPSK-Inner_1RB_Left-30-1000-PASS




NTNV-n78(3700-3800)-PC2-30-70-M-CP-QPSK-Inner_1RB_Left-1000-3000-PASS




NTNV-n78(3700-3800)-PC2-30-70-M-CP-QPSK-Inner_1RB_Left-3000-6000-PASS



NTNV-n78(3700-3800)-PC2-30-70-M-CP-QPSK-Inner_1RB_Left-6000-26000-PASS


NTNV-n78(3700-3800)-PC2-30-70-M-CP-QPSK-Inner_1RB_Left-
26000-40000-PASS

NTNV-n78(3700-3800)-PC2-30-70-M-CP-QPSK-Inner_1RB_Right-
0.009-0.15-PASS


NTNV-n78(3700-3800)-PC2-30-70-M-CP-QPSK-Inner_1RB_Right
-0.15-30-PASS

NTNV-n78(3700-3800)-PC2-30-70-M-CP-QPSK-Inner_1RB_Right-
30-1000-PASS

NTNV-n78(3700-3800)-PC2-30-70-M-CP-QPSK-Inner_1RB_Right
-1000-3000-PASS


NTNV-n78(3700-3800)-PC2-30-70-M-CP-QPSK-Inner_1RB_Right-
3000-6000-PASS

NTNV-n78(3700-3800)-PC2-30-70-M-CP-QPSK-Inner_1RB_Right
-6000-26000-PASS


NTNV-n78(3700-3800)-PC2-30-70-M-CP-QPSK-Inner_1RB_Right-
26000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-70-H-CP-QPSK-Inner_1RB_Left-0.009-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-70-H-CP-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n78(3700-3800)-PC2-30-70-H-CP-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3700-3800)-PC2-30-70-H-CP-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n78(3700-3800)-PC2-30-70-H-CP-QPSK-Inner_1RB_Left-3000-6000-PASS




NTNV-n78(3700-3800)-PC2-30-70-H-CP-QPSK-Inner_1RB_Left-6000-26000-PASS



NTNV-n78(3700-3800)-PC2-30-70-H-CP-QPSK-Inner_1RB_Left-26000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-70-H-CP-QPSK-Inner_1RB_Right-0.009-0.15-PASS


NTNV-n78(3700-3800)-PC2-30-70-H-CP-QPSK-Inner_1RB_Right
-0.15-30-PASS

NTNV-n78(3700-3800)-PC2-30-70-H-CP-QPSK-Inner_1RB_Right-
30-1000-PASS

NTNV-n78(3700-3800)-PC2-30-70-H-CP-QPSK-Inner_1RB_Right
-1000-3000-PASS

NTNV-n78(3700-3800)-PC2-30-70-H-CP-QPSK-Inner_1RB_Right-
3000-6000-PASS

NTNV-n78(3700-3800)-PC2-30-70-H-CP-QPSK-Inner_1RB_Right
-6000-26000-PASS


NTNV-n78(3700-3800)-PC2-30-70-H-CP-QPSK-Inner_1RB_Right-
26000-40000-PASS




NTNV-n78(3700-3800)-PC2-30-80-L-CP-QPSK-Inner_1RB_Left-0
.009-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-80-L-CP-QPSK-Inner_1RB_Left-0.
15-30-PASS


NTNV-n78(3700-3800)-PC2-30-80-L-CP-QPSK-Inner_1RB_Left-3
0-1000-PASS

NTNV-n78(3700-3800)-PC2-30-80-L-CP-QPSK-Inner_1RB_Left-10
00-3000-PASS

NTNV-n78(3700-3800)-PC2-30-80-L-CP-QPSK-Inner_1RB_Left-3
000-6000-PASS

NTNV-n78(3700-3800)-PC2-30-80-L-CP-QPSK-Inner_1RB_Left-60
00-26000-PASS

NTNV-n78(3700-3800)-PC2-30-80-L-CP-QPSK-Inner_1RB_Left-2
6000-40000-PASS

NTNV-n78(3700-3800)-PC2-30-80-L-CP-QPSK-Inner_1RB_Right-0
.009-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-80-L-CP-QPSK-Inner_1RB_Right-
0.15-30-PASS

NTNV-n78(3700-3800)-PC2-30-80-L-CP-QPSK-Inner_1RB_Right-3
0-1000-PASS



NTNV-n78(3700-3800)-PC2-30-80-L-CP-QPSK-Inner_1RB_Right-1000-3000-PASS




NTNV-n78(3700-3800)-PC2-30-80-L-CP-QPSK-Inner_1RB_Right-3000-6000-PASS




NTNV-n78(3700-3800)-PC2-30-80-L-CP-QPSK-Inner_1RB_Right-6000-26000-PASS



NTNV-n78(3700-3800)-PC2-30-80-L-CP-QPSK-Inner_1RB_Right-26000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-80-M-CP-QPSK-Inner_1RB_Left-0.009-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-80-M-CP-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n78(3700-3800)-PC2-30-80-M-CP-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3700-3800)-PC2-30-80-M-CP-QPSK-Inner_1RB_Left-1000-3000-PASS