



扫码关注

fingertime凡纪

深圳市盛创数码科技有限公司
Shenzhen Century Digital Technology Co., Ltd.
广东省深圳市龙华区龙华街道梅龙大道194号卫东龙商务大厦A座1205-1207
Add: Unit 1205-1207, 12th Floor, Block A, WDL Business Building, NO. 194 Meilong Avenue,
Longhua Committee, Longhua District, Shenzhen, Guangdong (518109)

www.fingertime.net 400 990 0236
商标说明: fingertime® 为深圳市盛创数码科技有限公司持有注册商标, 仿冒必究。

保修卡 WARRANTY CARD

产品型号
Model number

购买日期
Purchase date

购买账号
Purchase account

用户姓名
User name

产品颜色
Color

购买店铺
Purchase shop

保修原因
Warranty reason

联系电话
Contact number

用户地址
Buyer address

产品合格证

经检验该产品符合技术标准, 准予出厂。

产品名称: 头戴式蓝牙耳机

型 号: Roam

检 验 号: 08

制造地址: 汕头市潮阳区谷饶镇沟南工业区

深圳市盛创数码科技有限公司
电话: 400 990 0236
执行标准: GB/T14471-2013



注意事项 Note

蓝牙耳机进入配对模式后若无配对连接操作, 请关闭设备避免电量损耗。
搜索蓝牙时不要进行其他操作, 防止程序出错。
在使用中请选择适当的音量, 以防对耳朵造成伤害。
请注意蓝牙耳机的良好使用环境, 避免对耳机造成损伤。
长时间未使用的耳机, 请先将耳机进行一次充电过程后再使用。
If no pairing connection after the Bluetooth headset enters the pairing mode,
please turn off the headset to save power.
Do not perform other operations when searching Bluetooth to prevent the program error.
Please select a proper volume while using to prevent damage to your ears.
Please note that a good environment for using the Bluetooth headsets can avoid
damage to the headsets.
Please charge the headset after a long time none-use.

产品参数(Product Parameters):


蓝牙标准(Bluetooth Version):	Bluetooth V5.4
低延迟模式(Low latency mode):	0.04S
支持协议(Support Profile):	a2dp\avctp\avdtp\avrcp\hfp\spp\smp\att\gap\gatt\rfcomm\sdp\l2cap profile
工作频率(Frequency Range):	2.402—2.480GHz
有效范围(Working Distance Range):	10m
发声单元(Speaker Unit):	40mm
电池规格(Battery Specifications):	3.7V/500mAh
充电电压(Charging Voltage):	5V/1A
充电时间(Charging Time):	约2.5小时(about 2.5 hours)



Roam
Retro Design
Bluetooth Headset

fingertime®

按键说明(Button Description):



短按切换至降噪模式，语音提示“ANC Mode”
Short press to switch the ANC Mode.


开机/关机耳机； 暂停/播放音乐； 接听/挂断电话；
模式切换； 唤醒语音助手
ON/ OFF, Play/ Pause, Answer Calls/ Hang off Calls ,Modes Switch, activate the voice assistance

在连接蓝牙状态下，五连击进入游戏模式。开启0.04S无感延迟。
In Bluetooth mode,five press to enter the Game mode,no inductive delay at 0.04s.

短按加音量/长按下一曲
short press for increasing volume
long press for next song


短按减音量/长按上一曲
short press for reducing volume
long press for previous song


ANC降噪模式(ANC mode):


短按“”键，切换至降噪模式，语音提示“ANC Mode”。


ANC Mode: short press “” to switch the ANC Mode, voice prompts “ANC Mode”.

低延迟游戏模式(Low latency mode):


连续五击“”键，进入低延迟模式，语音提示“Game Mode”。

再次五击“”键，切换至音乐模式，语音提示“Music Mode”。

Press“” for five times to enter the low latency game mode, voice prompts “Game Mode”.

Press“” for five times again to switch the music mode, voice prompts “Music Mode”.


蓝牙模式(Bluetooth Mode):

蓝牙配对: 长按 “”3秒，语音提示 “power on”，耳机开机。

自动进入配对状态，语音提示“Bluetooth mode”，白色和橙色指示灯交替闪烁，
打开智能设备蓝牙功能，开启搜索并选择设备“Roam”，无需密码，配对成功后语音提示“Connected”，
白色指示灯慢闪。


清除配对: 同时长按“+”键和“-”键3秒，清除原配对连接的设备。


按键功能说明:


1) 暂停/播放音乐: 短按“”暂停或播放音乐


2) 上/下曲: 长按“+”2秒切换下一曲，长按“-”2秒切换上一曲


3) 加/减音量: 短按“+”增加音量，短按“-”降低音量


4) 语音助手: 连续三击“”键，唤醒语音助手功能

5) 接通电话: 来电时，短按“”

6) 挂断电话: 通话结束，短按“”

7) 拒绝来电: 来电时，长按“”2秒


8) 关机: 长按“”3秒，耳机关机

Bluetooth pairing: long press“” for three seconds, voice prompts “power on” to start up the Bluetooth headphone, it will enter pairing mode automatically, voice prompts “Bluetooth Mode”, indicator light flashes with white and orange.

Turn on the smart device's Bluetooth searching function and select the device “Roam”, no password is required, after successfully pairing, a tone “Connected” will be heard, the LED indicator light flashes white slowly.


Clean pairing: long press the “+” and “-” for 3s at the same time to clean the original pair of connected devices.


Button Description:


1)Play/pause the music: short press “”to play or pause the music


2)Last/next song: long press “+”for 2 seconds to the next song; long press “ - ”for 2 seconds to the previous song


3)Volume control: short press “+” for increasing volume, short press “ - ” for reducing volume

4)Voice assistance: triple press“”to activate the voice assistance

5)Answer the call: short press “”when calls coming

6)End of the call: short press “”when calls ending

7)Reject the call: long press “”for 2 seconds when calls coming

8)Power off: long press “”for 3 seconds to turn off the headphone

LED指示灯状态(LED indicator light Status):

充电状态	充电时：橙色指示灯长亮 满电时：指示灯熄灭
配对状态	橙色和白色指示灯交替闪烁
播放状态	指示灯熄灭

Charge Status	LED indicator light stays orange when charging. When fully charged, LED indicator light turns off.
Pairing Status	LED indicator light alternating flashes white and orange.
Playing Status	LED indicator turns off.

APP下载(Download the APP):



扫一扫【凡纪-APP】
解锁更多个性化功能

FCC STATEMENT :
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.