



无线蓝牙耳机EW305使用说明
中国制造



关注联想智生活

制造商：来酷科技有限公司
地址：天津自贸试验区（空港经济区）空港国际物流区第二大街1号
服务热线：400-0100-800


产品介绍

耳机参数


蓝牙版本：5.3
佩戴方式：入耳式
最大工作距离：10m（无障碍）
电池容量：30mAh
耳机播放时间：3h
配对名：EW305

充电盒参数

电池容量：230mAh
充电电流：5V/1A
充电接口：TYPE-C
充电盒充电灯闪烁，充满红灯常亮



功能	当前状态	操作	提示音
开机	关机	拿出充电仓自动关机/手动开机长按3S	Power on
关机	开机	放入充电仓自动关机/手动关机长按5S	Power off
播放	已连接	单击	
暂停	音乐播放	单击	
接听	第一个来电打进	单击	
拒接	第一个来电打进	长按1.5S	
挂断	双方通话中	单击	
音量加	音乐中/通话中	双击右耳	最大音量-嘀
音量减	音乐中/通话中	双击左耳	
上一曲	音乐中	三击副耳L	
下一曲	音乐中	三击主耳R	
SIRI	音乐中/耳机中	长按2S	“Beep”
连接成功			Connected
断开连接			Disconnected
低电量			Battery low



注意事项

1. 请勿将无线耳机摔落，撞击，刮擦，扭曲，敲打，碾压，投入水中等。
2. 使用无线耳机时，请将其远离磁体，电器和扬声器附件；
3. 尽量避免将无线耳机放置于极端温度中（使用环境工作温度范围-10°C~45°C）；
4. 避免将无线耳机暴露在潮湿的环境中；
5. 若长时间不使用无线耳机，请充满电并隔一星期充一次电，延长无线耳机使用寿命；
6. 请勿让无线耳机靠近火源；
7. 请勿将无线耳机与充电仓放在易燃易爆物品旁边；
8. 禁止快充

安全指导：

给充电仓充电请使用标准直流充电器（DC 5V/500MA-1A）；
请勿拆卸充电仓与无线耳机。或者将其他物品插入产品内，以避免产品损坏给您带来伤害。

严重警告：

请勿在充电时使用本产品，请使用厂家指定的适配器给产品充电。
内置锂电池切勿拆开放置火中，不可让金属物品接触或短路电极，不可撞击和挤压电池，避免放置于潮湿腐蚀或过热（> 60°C）环境中。
该设备

FCC警告

本设备符合FCC规则第15部分：
操作需满足以下两个条件：
1. 本设备不得造成有害干扰；
2. 本设备必须接受收到的任何干扰，包括可能导致不希望的操作干扰。
未经合规负责方明确批准的任何更改或修改可能会使用户失去操作设备的权限。
注：根据FCC规则第15部分，该设备已经通过测试，符合B类数字设备的限制。这些限制旨在为住宅安装中的有害干扰提供合理的保护。本设备产生、使用并能辐射射频能量，如果未按照说明安装和使用，可能会对无线电通信造成有害干扰。
但是，不能保证在特定的安装中不会发生干扰。如果该设备确实对无线电或电视接收造成有害干扰，可以通过关闭和打开设备来确定，鼓励用户尝试通过以下一种或多种措施来纠正干扰：
--调整接收天线的方向或位置。
--增加设备与接收器之间的距离。
--将设备连接到与接收器不同的电路插座上。
--请咨询经销商或有经验的无线电/电视技术人员以获得帮助。

包装内容

1. 无线耳机2PCS
2. 充电收纳盒1PCS
3. 说明书
4. 充电线一条

售后服务

来酷售后服务承诺：
本产品售后有效期：自购买之日起，在正常使用的情况下提供整机一年保修服务，其他附件（如包装等）不属售后服务范围之内。
以下情况不属售后服务范围：
1、不能提供有效的凭证及有效发票的（能证明此产品在产品售后有效期内外）或擅自涂改有效凭证的；
2、有效凭证上的产品型号及序列号与产品实物不相符合的；
3、未按产品使用说明的要求使用、维护和保管而造成损坏的；
4、因意外灾害、自行拆卸、人为损坏或经非本公司授权之外服务站维修所引起的故障；
5、因不可抗力因素所造成的损坏。



TWS Wireless Earbuds
EW305 User Guide
Made in China



Follow Lenovo Smart Life

Manufacturer: Lecoo Technology Co., Ltd
Address: No. 1, 2nd Street, Airport International Logistics Zone, Tianjin Pilot Free Trade Zone (Airport Economic Zone)
Hotline: 400-0100-800


product description

Earbuds parameter


Bluetooth version: 5.3
Wearing method: in-ear
Maximum working distance: 10m
Battery capacity: 30mAh
Headphone play time: 3h
Pairing name: EW305

Charging Case Spec

Battery capacity: 230mAh
Charging current: 5V/1A
Charging interface: TYPE-C
The red light of the charging box is flashing, and the red light is always on when fully charged



status		operating	
Power on	Power off	Take out the charging compartment and automatically turn off the machine/ Manually turn on and long press for 3S	Power on
Power off	Power on	Put the earbuds into the charging compartment and automatically shut down/Manual shutdown long press 5S	Power off
Play	Connected	Click the touch area	
Pause	Play music	Click the touch area	
Answer	The first call comes in	Click the touch area	
Reject	The first call comes in	Long press the touch area for 1.5S	
Hang up	Calling	Click the touch area	
Volume +	In music/calling	Double tap the right ear touch area	Maximum volume “beep-beep”
Volume -	In music/calling	Double tap the left ear touch area	
Previous piece	In music	Triple tap the right ear touch area	
Next track	In music	Triple tap the left ear touch area	
Siri	Music/Online	Long press 2S	“Beep”
Connection succeeded			Connected
Disconnect			Disconnected
Low power			Battery low



Precautions

1. Do not drop, impact, scratch, twist, beat, crush, drop into the water, etc, the Wireless Earbuds.
2. When using a Wireless Earbuds, please keep it away from magnets, electrical appliances and speaker accessories;
3. Try to avoid placing the Wireless Earbuds in extreme temperatures (working environment operating temperature range +10°C~45°C);
4. Avoid exposing the Wireless Earbuds to a humid environment;
5. If you don't use the Wireless Earbuds for a long time, please fully charge it and charge it every other week to extend the service life of the Wireless Earbuds;
6. Do not put the Wireless Earbuds near the fire source;
7. Do not place the Wireless Earbuds and charging compartment next to flammable and explosive items;
8. No fast charging

Safety guidance:

Please use the standard DC charger (DC 5V/500MA-1A) to charge the charging compartment; do not disassemble the charging compartment and Wireless Earbuds. Or insert other items into the product to avoid damage to you caused by product damage.

Serious warning:

Do not use this product while charging, please use the adapter specified by the manufacturer to charge the product.
Do not disassemble the built-in lithium electronic battery and place it in a fire. Do not allow metal objects to contact or short-circuit the electrode. Do not hit or squeeze the battery. Avoid placing it in a wet, corrosive or overheated (>60°C) environment.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

FCC warning

This device complies with Part 15 of the FCC Rules:
The following two conditions must be met:
1. The equipment shall not cause harmful interference;
2. the equipment must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications that are not explicitly approved by the responsible party for compliance may deprive the user of permission to operate the equipment.
Note: According to Part 15 of the FCC Rules, this device has been tested to meet the restrictions for Class B digital devices. These restrictions are intended to provide reasonable protection against harmful disturbances in residential installations. This device generates, uses and radiates radio frequency energy, which, if not installed and used in accordance with the instructions, may cause harmful interference with radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If the device does cause harmful interference with radio or television reception, this can be determined by turning the device off and on, and users are encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

After-sales service

Lecoo After-sales Service Commitment:
After-sale period of validity of the product: from the date of purchase, the product is provided with one-year warranty service under normal use. Other accessories (such as packaging, etc.) are not within the scope of after-sales service.
The following situations are not covered by after-sales service:
1. Unable to provide valid warranty card and valid invoice (not including those that can prove the product is within the valid warranty period) or after the warranty without authorization;
2. The product model and serial number on the warranty card are not consistent with the real product;
3. Damage is caused by failure to use, maintain and keep the product according to the instructions;
4. Damage caused by accident, personal dismantle, man-made damage or repair of service stations not authorized by the Company;
5. Damages caused by force majeure,

Package Contents

1.Wireless Earbuds 2pcs
2. charging box 1pc
3.manual 1pc
4.1 charging cable

说明书
折后尺寸：70*80mm
材质： 80g书写纸 黑白印刷
风琴折

