

# 196x140mm

## NOTE

1. It can only be used 30 minutes after meals.
2. Not suitable for use during pregnancy or menstruation.
3. Electronic products cannot be washed with water, they can be wiped with a cloth.
4. Charge the machine battery promptly after it runs out of battery to prevent battery depletion.
5. If the body feels uncomfortable during use, stop using immediately.
6. It is recommended to wear boxing gloves when using.
7. Unauthorized disassembly of products is prohibited.

## Warranty policy

Warranty within 1 year from purchase. (Self disassembling products is not covered by the warranty)

Product name	
Purchasing date	
Purchase address	
Telephone	
Fault Description	

**Certificate of conformity**

Product name: Musical boxing pro

Inspector: WS 05

DATE:

\* Please read the instruction manual carefully before use

## Musical boxing pro

### Operation instructions

## Product Introduction

Boxing is a fighting sport in which two opponents of equal physique and ability cover their fists with gloves Head to head combat, it is both an amateur and a professional sports activity . During boxing training, boxing targets are usually used to train the athlete's speed and strength, Due to the fleeting gap between opponents in boxing matches, it is more important than strength training , It is the player's ability to respond to attacks and defenses, and the product is guided by electronically controlled lighting To train people's reaction ability, using sound effects to indicate whether they are accurately hitting the target point,So as to efficiently exercise a person's overall coordination and sensing abilities.

## Parameter

Product Name: Musical boxing pro  
Power: 5W  
Working voltage: 3.7V  
Product size: 40 \* 40 \* 6.2cm  
Product net/gross weight: 2kg/2.5kg  
Rated input: 5V

## Charging instructions

Using power supply equipment (self provided): Input 100-240V, output 5V--- Charge by connecting it to the power cord. When installing boxing targets, consideration should be given to the location close to the wall socket. The distance between the socket and the machine interface should not exceed 1.8 meters.



## Operating instructions



1. Press and hold for 3 seconds to turn on or off the device
2. After turning on, short press the adjustment mode from P1P7 to adjust a total of 7 modes
- 3.+keys to adjust music volume
4. Bluetooth can be connected immediately upon startup, and disconnected upon shutdown

## Installation instructions



1. The first installation method is to peel off the adhesive attached to the back of the machine and directly attach it to the device to be installed Position: Divide the back of the adhesive into several sections, and choose the adhesive model according to the desired position Surrounding, metaphorically referring to a ceramic tile surface, the outermost layer - a circle - is sufficient. (As shown in Figure 1)
2. The second installation method is to tear off the Velcro needle surface of the accessory and directly stick the sticker onto the machine On the back. Pay attention to the parallel direction of the machine when pasting. (As shown in Figure 2)
3. Glue the Velcro needle surface and the rough surface together, find the corresponding position on the wall, determine the position, and tear it off Stick the sticker behind the rough surface to the wall. (As shown in Figure 3)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement , the device can be used in portable exposure condition without restriction