

# Quick Start Guide

## Included In-Box:

- Device
- HDMI Cable
- Power cord
- Remote
- 2 AAA batteries

## CONNECT YOUR DEVICE TO YOUR TV WITH HDMI

1. Plug in the power cord  
Plug the included power cord into your device's power port and then a power outlet.
2. Plug the HDMI cable into your TV's HDMI ARC/eARC port
  - a) Find your TV's ARC/eARC port. Plug the included HDMI cable into it.
  - b) Plug the other end into your device's HDMI port.
  - c) Check that your TV's HDMI CEC setting is enabled.
3. Select device's HDMI input  
Press the input button on the device or the remote until the HDMI option is selected.

## SET UP YOUR ACCESSORIES

1. Make sure your device is powered on.
2. Plug the included power cords into your accessories and then into a power outlet.
3. The accessories will automatically connect to your device. The LED light on the connect button will turn white.