

Quick Start Guide

Included In-Box:

- Device
- HDMI Cable
- Power cord
- Remote
- 2 AAA batteries

Set Up Your Device:

1. Plug in the power cord

Plug the included power cord into your device's power port and then a power outlet.

2. Plug the HDMI cable into your TV's HDMI ARC/eARC port

Find your TV's ARC/eARC port. Plug the included HDMI cable into it. Plug the other end into your device's HDMI port.

Check that your TV's HDMI CEC setting is enabled.

3. Select HDMI input on the device

Press the input button  on the device or the device remote until the HDMI option is selected.