


User manual




Welcome


Thank you for choosing to purchase this karaoke microphone, which uses industry advanced technology. With strong compatibility, you can easily enjoy mobile song practice and KTV anytime and anywhere just by linking the audio playback device. Wish you a pleasant use!

Function

This karaoke microphone speaker set adopts advanced 1-wire communication technology, mobile phone karaoke Bluetooth connection, wireless accompaniment, and is fully compatible with current mainstream mobile phones. Whether you are a karaoke fan or an K fan, you can enjoy the pleasure of karaoke with energy conservation and ease.




Instructions for microphone functions



Function

Support Bluetooth connection to play music/support TF card to play music/karaoke sound reinforcement function/built-in reverberation sound effect function/headphone output function.

Accessories



Loudspeaker box

Microphone



Type-c cable

Accessories

Loudspeaker box
Type-c cable



Instructions

Microphone
Instructions

Precautions for using speaker microphone

Switch on / off-

When the machine is turned off, the product starts automatically with the Chang An On/Off key. When the TF is not inserted when the card is used, it will enter the Bluetooth mode by default, and the voice prompt will be "Bluetooth mode"; Long press the ON/OFF key turns off the machine.

Bluetooth connectivity-

Open your phone's Bluetooth settings, search for the device name, and then make a pairing connection. After the connection is successful, there will be a prompt tone and the blue light will always be on.

Mobile Playback-

After the Bluetooth connection is successful, open the mobile music player and download your favorite songs or the accompaniment can be played, and the volume can also be adjusted to the appropriate level on the mobile phone.

Tf card play-

Insert the TF card into the device, and the device will automatically play the music in the TF card.

Sound adjustment-

The volume of microphone and accompaniment can be adjusted through the buttons on the device control panel.

Charge-

Connect the standard charging line to the charger for charging. The red light is always on when charging, and it is full off.

Attention

1. Please disconnect the charger and turn it off before cleaning the machine.
2. Non-professionals are not allowed to disassemble the equipment by themselves to avoid machine failure and loss of warranty rights.
3. Please do not place the equipment in the direct sunlight to avoid premature aging of electronic parts.
4. Avoid using in places with flying dust or dirty environment (dust is easy to cause equipment failure).
5. Do not place the equipment in an excessively cold or overheated environment, which may cause the equipment to fail to operate normally.
6. It is recommended that the ambient temperature of the equipment used should not exceed 10°C-40°C, which is relatively moderate (10%-95%).
7. Please do not put any objects into the equipment to avoid short circuit or circuit damage. Please do not spill any liquid on the product.
8. Avoid friction and collision between the machine and hard objects to avoid scratching, falling off, or other hardware damage.
9. The product shall not be exposed to the sun, fire, or similar overheating environment.
10. It is forbidden to disassemble, impact, squeeze, or put the product into fire. If the battery has serious failure, do not continue to use.
11. This manual contains important information, please reserve it.

Bluetooth

1. Press and hold the speaker power on key to start the machine, and the voice prompt "Bluetooth mode" will flash at the same time. Connect the success blue light is always on.
 2. Turn on the mobile phone Bluetooth and scan, search for the device, and then pair and connect, and you can hear it after connecting. The device sends a successful connection tone.
 3. After the microphone is turned on, it will automatically pair the speakers. When the microphone is not paired, the blue light will flash, and the Bluetooth light will flash always bright.
 4. Bluetooth connection name: C30 Pro.
- Note: After the device is connected to the mobile phone once, Bluetooth has a memory function, and it will automatically connect when the phone is turned on. To disconnect, disconnect Bluetooth through the phone settings. If you listen to music only, you can turn the microphone volume adjustment to the minimum.

Sing K audio & microphone features

Intelligent anti squealing-

Sing loudly without howling within 10cm.

High radio sensitivity-

It is easy to sing with a 5-10cm microphone. The microphone is loud and has good sound quality.

Low latency-

The delay is less than 40ms.

AI functions-

5 kinds of sound effects; One click to cancel the original sound; Flexible adjustment of accompaniment reverberation and microphone volume.

Note: The company's products are constantly innovative and subject to change without notice.

Speaker

Bluetooth version: 5.3
Horn diameter: 57mm
Horn power: 5W
Working voltage: 3.7V
Frequency range: 20Hz-20kHz
Reverberation; echo sound effect
reverberation Power adapter: DC5V ≤ 1A
(common with mobile phone charger)
Charging duration: 2-3 hours

Microphone

Pickup: back pole condenser microphone
Working voltage: 3.7V
Frequency range: 20Hz-20kHz
Power adapter: DC5V 1A
(common with mobile phone charger)
Charging duration: about 2.5 hours

Information

Product name: Hand-held karaoke speaker
Product model: C30 Pro
Note: The company's products are constantly innovative and subject to change without notice.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.