

| 1 | 2 | 3 | 4 | 5 | 6 |
|------|------------------------------|---|---|---------|--------|
| 修改区域 | 描述 | | | 日期 | 担当 |
| 1 | XXXXXXXXXXXXXXXXXXXXXXXXXXXX | | | XXXXXXX | XXXXXX |

A

封面



1

2

3

Important Safety Instructions

WARNING: To reduce the risk of electric shock, do not dismantle the product and do not expose the product to rain or moisture. No user-serviceable parts inside. Refer servicing to qualified personnel only.

1. Read all instructions for future reference

2. Always operate the product from a power source of the same voltage, frequency and rating as indicated on the rating label.

3. This product is intended for indoor/household use only.

4. To protect against electric shock: do not immerse unit/plug or cord in water or spray water on the unit. Do not use the unit near water, such as near a tub, sink, or a swimming pool, or in a wet basement.

5. Do not use this product in the immediate vicinity of water such as bathtubs, washbasins, swimming pools etc, where the likelihood of immersion or splashing occur.

6. Keep the unit away from heat sources like radiators, heat registers, stoves or other products that produce heat. No open flame sources like candles should be placed on the unit.

7. Use only with attachments/accessories specified by the manufacturer. Use of other attachments/accessories may be hazardous.

8. This appliance is not intended for use by persons (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

9. This product is not a toy. Children should be supervised to ensure that they do not play with the appliance.

10. Do not cover the unit during use. Do not impede ventilation by covering ventilation openings with cloths, curtains or similar items.

11. Do not operate the product with a damaged cord or plug or if the product malfunctions, or is dropped or damaged in any manner.

12. If repair is required, have it made by a service center approved by the manufacturer, its service agent or similarly qualified persons in order to avoid hazard.


13. For safety reasons, do not remove any covers or attempt to access the inside of the unit.

14. Do not clean the unit with any harsh chemicals as this might damage the finish. Wipe clean with a dry cloth.

15. When removing the power plug from the wall outlet, always pull directly on the plug, not on the cord.

16. Do not expose the batteries to excessive heat, direct sunlight, fire or similar.

17. Do not throw used batteries in your household rubbish. Dispose of it responsibly according to local regulations.







4

5

6

封底



骑马钉册子 成品尺寸: 140*210MM 105g铜版纸 单黑印刷



订单编号:

料号:

设计: 吴梓鹏 2024/11/25 文件编号:

业务: 名称: LASB-3300BLK 说明书 RJ 美国

电子: 审核:

结构: 核准:

页次: 1/1

版次: 1.0

1

2

3

4

5

6

A

D

C

B

D