

JYD-C63 Wireless helmet headphones




User Manual

Wireless pairing search device:



Figure 4:



Installation of rear clip base onto helmet



6



7

Power On/Off:

Press and hold the power button " " for two to three seconds to turn on; the indicator light will flash red and blue alternately, indicating the headset is powered on. To turn off, also press and hold the power symbol button. Press and hold for two to three seconds to turn off. A tone prompt will sound, and the indicator light will go out after shutdown.

How to Switch Between Chinese and English Voice Prompts:

After powering on and when the indicator light flashes red and blue alternately, do not connect to your phone. Press the " " button twice consecutively to switch between Chinese and English voice prompts.

How to Connect Two Phones Simultaneously:

After turning on the wireless earphones, first connect them to phone A, then turn off phone A's wireless connection, and finally connect them successfully to phone B. Then turn on phone A's wireless connection to connect both phones at the same time.

How to Connect to Your Phone:

After powering on and with the indicator flashing red and blue alternately, enable on your phone. Search for devices on your phone and select "JYD-C63." The connection will be established within a few seconds. Once the devices have been paired, future connections will happen automatically when both the headset and your phone's are turned on.

1

Volume Adjustment/Track Selection:

Press the "+" button once to increase the volume one level; press the "-" button once to decrease the volume one level. Press the " " button once for the previous track; press the " " button once for the next track.

Automatic/Manual Call Answering Toggle

While music is paused, press the " " button twice. A voice prompt will confirm the change.

Nighttime Ambient Light Effect

After powering on, the four control buttons are illuminated with a steady blue light.

Answering Calls:

Incoming calls are answered automatically, or you can manually answer by pressing the call symbol " ".

Charging the Product:

A low battery will trigger a voice prompt to recharge. Charge for 5 to 6 hours to reach full capacity. The red light remains on while charging and turns off when fully charged.

2

Package Contents:

1. One wireless headset for the helmet.
2. One charging cable.
3. One user manual.
4. Two spare Velcro pads.
5. One spare mic cover.


Product Specifications:

1. Chip version: V5.4+EDR
2. Frequency Range: 2.402GHz - 2.480GHz
3. Transmission Distance: Over 10 meters
4. Microphone Range: ≤1 meter
5. Lithium Battery: 3.7V / 1000mA
6. Charging Time: 5-7 hours
7. Standby Time: Approximately 280 hours
8. Continuous Operating Time: Approximately 30 hours
9. Connection name: JYD-C63


3

Device Appearance and Function Overview:

Single press for next track
Double press to switch between automatic and manual call answering
Single press for previous track
Double press to activate Siri voice assistant
Power on/off / Answer call
Play/Pause / Redial
Switch between Chinese and English



Single press to decrease volume
Single press to increase volume



Speaker wire assembly
USB charging

5



Left speaker installation:
Peel off the white release paper from the spare round fuzzy Velcro pad,




Peel off the white release paper from the spare round fuzzy Velcro pad and attach it to the ear opening inside the helmet.




Refer to the left illustration:
position the speaker at the ear location and install the microphone boom in a suitable position.



Right speaker installation:
Peel off the white release liner from the spare round fuzzy Velcro pad.



Peel off the white release liner from the spare round fuzzy Velcro pad, then position the speaker and attach it securely.



Route the left and right speaker wires inside the helmet lining.

4

5

Compatible with the following products:



Suitable for the following helmet types



Precautions for using helmet wireless earphones

1. To protect your eardrums and hearing, do not set the volume to maximum.
2. Do not listen to music continuously for extended periods.
3. Avoid impact or collision with the product whenever possible.
4. Keep away from dust, fire, and moisture.
5. Before outdoor use, ensure the device is fully charged.



11