

AGES 3+

Thank you for using our company's toy products. In order to have a better understanding of this product, please read the following instructions before use, which will bring you a different operating experience.

This product is suitable for children 3 years old and above. After assembled / charged by adults, play with children again.
Please Use This Product Under The Supervision Of An Adult.
Warning: please do not disassemble or modify the product without authorization, any changes may cause the product to not work properly.

The output voltage used by the charging plug should be 5V. Please do not use the quick-charging plug and quick-charging cable, so as to avoid the condition that the too quick current output during charging causes overheated battery charging and results in dangerous matters such as product burnout.

R/C Car

Handle Remote Control


Rechargeable battery pack
3.7V

USB Charging Cable

3V CR2032 button battery Figure

Built in 3.7V lithium battery

USB Charging Cable



Battery chargers that use this toy must be regularly checked to prevent damage to the wires and other components and, if damaged, must be repaired for damage.

Vehicle out of control within distant remote control	1. There is not enough power in the remote control battery or rechargeable battery pack. 2. There may be sources of interference near the site.	When the function of the remote control car is hindered by the external force and can not finish the full function of the function or the circuit battery is short-circuited.	Abnormal Protect
1. Replace the battery inside the remote control with a new battery or charge the rechargeable battery pack. 2. Change the venue.	1. Re-open the power switch remote car power protection.		

Battery installation
Open the body battery cover,
Connect the rechargeable battery
pack to the power socket,
Close the battery cover.

3.7V

OFF ON

Power switch

1. Connect the Rechargeable battery pack to the USB charging cable

2. Plug the other end of the USB charging cable into the USB port for charging

Attention: Before the battery of this car is almost depleted during use, it will sound two beeps and automatically shut down. If you need to continue using it, you should replace the battery.

General Trouble Shooting

- * Before playing please charge the new battery pack.
- * The output voltage used by the charging plug should be 5V.
- * The higher the actual milliamperes of the rechargeable battery, the longer the charging time;
- * Rechargeable batteries can only be charged under adult supervision.
- * During charging, the light of the USB charging cable head is on red. When the light goes out, it indicates that the lithium battery is fully charged. The charging time is 3-4 hours.
- * First plug the battery pack into the charger, then plug the charger plugged in the socket.
- * Take out and put in the battery according to the mark on the toy battery room.
- * Non-rechargeable batteries cannot be charged.
- * Use only the same or identical battery as recommended;
- * Do not mix-use old and new batteries or different types of batteries;
- * Batteries should be placed in the correct polarity;
- * Remove the exhausted battery from the toy;
- * Power terminals should not be short-circuited;
- * The charger must be checked regularly for damage to its wires, plugs, housings and other components. If damage is found, stop using the charger until it is repaired.

1. Please add an appropriate amount of clean water to the water tank before use. (As shown in the figure).

2. When the water tank is dry, the atomization function cannot continue to operate. Long pause operation can cause circuit board short circuits, leading to or disordered or missing vehicle functions.

Important notice: Due to the small size of the main body of this product and the small capacity of the water tank, only 6 grams of clean water can be added. Spray for 4 times or more. If you need to use the spray function again, add water again. Please insert the water bottle into the mouth of the water tank and slowly squeeze it, filling it all at once.

Water inlet

Spray tablet

 Raise the gesture, the R/C car body twists and parallels.


Diagram illustrating the front panel controls and indicators of the Atomizing Machine:

- Indicator Light
- Atomization lamp
- Light switching light
- Deformation Programming
- Right 45°
- Turn Left
- Turn Right
- Music
- Right Transverse
- Demo
- Atomizing
- Left Transverse
- ON/OFF/Lights
- Forward Backward
- Left 45°
- Rotate 360° to the right


Indicator Light	When the frequency is not correct, the light flashes, and when the frequency is up, the light goes out.
Atomization lamp	Turn on the atomization function and the light will be on; Turn off the atomization function and turn off the light.
Rotate 360 ° to the right	Press the "Rotate 360 ° Right" button while the remote control car is in a stopped state, and the remote control car will rotate 360 ° to the right.
Deformation	When the remote control vehicle is in a stopped state, press the "deformation" button, and the vehicle body will twist and arch up; Press the button again to lower the vehicle body in parallel.
Programming	After pressing the programming keys, press the buttons that need to be demonstrated one by one, and then press the programming keys. The remote control car will start demonstrating in the order of input.
Left 45°	When the R/C car is in the stop state, press down the "Left 45° Travel" key, the R/C car travels left 45°.
ON/OFF/Lights	Long press to turn the power on or off; Briefly press to turn on or off the roof lights and light switch
Music	Press the first time to turn on music, press the second and third times to switch music, and press the fourth time to turn off sound.
Right 45°	When the R/C car is in the stop state, press down the "Right 45° Travel" key, the R/C car travels Right 45°.
Left Transverse	When the R/C car is in the stop state, press down the "Left Horizontal Travel" key, the R/C car travels left horizontal.
Demo	Press the "Demo" button when the remote control vehicle is stopped, and the remote control vehicle enters the automatic demonstration mode; Press any key to exit the automatic presentation mode.
Atomizing	Turn on the atomization function, the atomization light will flash, turn off the atomization function, and the atomization light will be off.



Note: The effective control distance between the remote control and the vehicle is approximately 40 meters. If the remote control is out of frequency or does not operate during frequency synchronization, it will hibernate after 2minute. If operation is necessary, restart the remote control and the vehicle's power switch.



The gravity watch remote control effectively controls a distance of about 30 meters.



1. First, turn on the power switch of the vehicle body, and the lights of the entire vehicle will flash. Then, turn on the power switch of the remote control to start frequency matching. If the frequency matching is successful, the power on light will flash red and blue.
2. The frequency conversion is unsuccessful, and the remote control power light and body light keep flashing. If the connection is unsuccessful, please repeat the above operation.
3. After frequency synchronization, there is no operation. After 2 minutes, the remote control car and remote control enter sleep mode, and the frequency synchronization connection needs to be reconnected.

1. Connect the gravily remote control to the USB charging cable.
2. Insert the other end of the USB charging cable into the USB charging port.

Open the battery cover of the gravily remote control and tighten the 3V CR2022 button insert the battery compartment with the negative electrode facing downwards and cover it with the battery cover.

There are two options for the gravity watch remote control (operate according to the corresponding

Gravity Watch Remote Control Battery Description

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.