

**Product parameters**

product name	APP Tiadian
Product color	red, purple
Product material	Silica gel
Standard	95*80*20mm
Maximum volume	60 dB
noise value	9-frequency vibration
The main function	wireless remotecontrol, APP remotecontrol
packing list	Product*, remotecontrol*, manual*, charging cable*

**USB power supply description**

1. The product is charged by USB power supply. Please keep the product dry during charging.  
2. The charging time is about 2 hours and can be used for 1 hour after charging.  
3. When the product is not in use, the power can be turned off. After charging, pull out the charge. After the line, the product automatically releases the safety mode and can be used normally.  
4. In order to protect the battery, there is a unique charging effect, we recommend you to press the power button to ensure the vibration of the equipment is significantly reduced.

**Wireless remote control operation instructions**

- Long press "①" for 1.5s to start / shut down the host, and click "②" for frequency conversion.
- In the standby mode of the host, press "③" on the remote control to convert the frequency. There are 9 vibration modes in total.

**APP operating instructions**

1. For iOS System  
1.1 Go to the App Store, download and install "Love Spouse" APP.  
1.2 Scan the QR code with your mobile phone and follow the instructions to download and install "Love Spouse" APP.  
2. For Android System  
2.1 Go to the Google Play, download and install "Love Spouse" APP.  
2.2 Scan the QR code with your mobile phone and follow the instructions to download and install "Love Spouse" APP.



**Device Connection and Control**

- Make sure bluetooth is turned on.
- Open the "Love Spouse" APP.
- There are "Visitor login" and "New user" two modes to log in. If you want to experience more operation modes, select "New user", follow the instructions to complete the registration.

**New user**

- Click "④", the device binding scan box will appear.
- Scan the QR code below or enter the binding code 1095.
- The device must be turned on when binding the device.
- APP binding code: 1095



**Notes needing attention**

- Please charge the product for the first time.
- This product is forbidden to be used by minors under the age of 18.
- Please keep the product clean after use. Do not use corrosive detergent for cleaning.
- This product has a built-in polymer lithium battery, which cannot be disassembled by itself. To avoid damage to the product.

**产品参数**

产品名称	APP跳蛋
产品颜色	红色、紫色
主体材质	硅胶
规格尺寸	95*80*20mm
最大噪音值	60分贝
主要功能	9频震动、无线遥控、APP远程控制
包装清单	产品*1、遥控器*1、说明书*1、充电线*1

**USB供电说明**

1. 产品采用USB供电方式充电，充电时请保持产品干燥。  
2. 充电时间约为1.5小时，充电后可使用1小时。  
3. 充电时产品处于安全模式无法开机，充电结束后拔出充电线后，产品自动解除安全模式，可正常使用。  
4. 为了延长电池寿命并确保充电效果，我们建议在设备振动明显减弱时对设备进行充电。

**无线遥控操作说明**

- 长按主机 "①" 1.5s开机/关机，点按 "②" 变频。
- 主机关机模式下，点按遥控器 "③" 变频，共9个震动模式

**APP操作说明**



请微信扫一扫二维码  
将说明书下载安装APP



APP绑定码: 1422  
请用下载的APP扫描绑定  
注: APP绑定需要打开手机  
蓝牙功能并将其开机

**注意事项**

- 第一次使用请先为产品充电。
- 本产品禁止18岁以下未成年人使用。
- 使用后请保持产品清洁，请勿使用带腐蚀性清洁剂清洗。
- 本产品内置聚合物锂电池，电池不可自行拆卸，以免对产品造成损坏。

**使用说明**



# FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Any Changes or modifications to this equipment not expressly approved by the manufacturer may void the user's authority to operate the equipment.**

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.