

prowand

USER MANUALS



Choose your language

English

Deutsch

Español

Română

Click on one



Software notice

ProWand by Kiiroo is to be used with the authorized FeelConnect app and FeelPerformer only.

Downloading any third-party applications to control or interact with the ProWand that are not mentioned above is done entirely at your own risk.

If a third-party application is downloaded, and it damages either the device software or hardware or leads to personal injury, neither Kiiroo, FeelRobotics nor any of their partners will be held liable.

Hardware notice

ProWand by Kiiroo was designed to be used alone. The usage of any third-party hardware product in combination with ProWand violates the terms of usage and warranty, and Kiiroo will not be liable for any damage sustained.

National deviation 7.12.Z1

This appliance contains batteries that are non-replaceable.

For a part of class III construction supplied from a detachable power supply unit, the instructions state that the appliance is only to be used with the unit provided.

The appliance is not to be used by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge unless they have been given supervision or instruction.

Kiiroo and FeelRobotics are constantly working to ensure their hardware and software are as secure as possible.



We recommend updating your app and device every time there is an update. Keeping your device and app versions up-to-date ensures you have the newest features and guarantees your safety.

Logo usage

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc., registered in the U.S. and other countries.

Google Play and the Google Play logo are trade marks of Google Inc.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Kiiroo is under license.

Other trademarks and trade names are those of their respective owners.

Table of contents

Setting up your device	6
Using your device	7
Modes	9
Bluetooth mode	
Manual mode	
FeelConnect & Services	12
Charging and LED indicator	17
Handling	18
Lubrication	
Disclaimer and warnings	19
Disposal specifications	20
Aftercare and help	21
Specifications & FAQ	
FCC statement, ISED statement	22



SETTING UP YOUR DEVICE

Setting up your device

Using the magnetic USB charger provided, charge ProWand until the LED lights at the bottom turn to solid green. Charging takes approximately 4 hours.

**We recommend charging ProWand fully prior to the first use.*

While your device is charging

1. Scan the QR code on the tray found inside the box or go to www.kiiroo.com to create your user account.
<https://www.kiiroo.com/my-account/>
2. Once you have created an account, please go to: <https://www.kiiroo.com/pages/register-your-device> to register your device and activate your one (1) year warranty.
3. Download the FeelConnect App from app store so you are ready to pair your ProWand with your mobile phone once it is charged.


Magnetic USB Charger



Quick start

1. To turn ProWand on, press and hold the **Power Button** for approximately 2 seconds until the device turns on.
**The first LED color that flashes indicates battery level, after 1 second ProWand will flash blue.*
2. The **flashing blue light** indicates that ProWand is in **Interactive/Bluetooth Mode** and searching to connect to the FeelConnect app or the FeelPerformer app via Bluetooth.
**Go to page 12 for a detailed explanation on how to use Interactive Mode.*
3. Press and hold the **Power Button** again for 1 second to enter **Manual Mode**.
**Go to page 10 for an overview of the Manual Modes.*

 **Power Button**





USING YOUR DEVICE

4. To pause ProWand, press the **Power Button** 2 times quickly. Press any button again to resume operation.
5. To go back to **Interactive/Bluetooth Mode**, you need to swing through the patterns until you reach the one after 6, which is Bluetooth mode and ProWand will flash blue.
6. To reset your ProWand, press the power button approximately 10 seconds then you will see the LED blinking blue light; then, press again until you see the charging status.
**When you reset ProWand, your settings will be removed, and ProWand will be restored back to its original settings.*
7. To turn ProWand off, press and hold the **Power Button** (approximately 3 seconds) until the light blinks white for 2 seconds and then ProWand turns off.



***Please note:** ProWand is waterproof! Enjoy using your new ProWand in the bath or shower and live up to some of your wettest and wildest fantasies.




MODES

Bluetooth Mode - indicated by a **blue light**

When ProWand is turned on, the LED light will blink blue, indicating that ProWand is in pairing mode.

Follow the onboarding instructions in the FeelConnect app to connect and set up your ProWand. Once you are paired with the app, the LED light will turn solid blue.

Now, you can enjoy music, interactive content, connect to your partner(s) and control your ProWand using the FeelConnect app.





MODES

To pause vibrations - indicated by a **blinking purple light**

To pause the vibrations, press the **Power Button** 2 times quickly. Press any button again to resume operation.



****To reset ProWand, press **Power Button** approximately 10 seconds then you will see the LED blinking light blue. Then, press the button for 2 seconds to turn ProWand on again.***



CHARGING AND LED INDICATOR

Insert the USB port into a wall charger/charging port. The other end of the charging cable is magnetic and attaches to the magnets located on the underside of your ProWand.

****Please note, a wall adapter is NOT included in the box.***

We recommend using a wall adapter instead of computer USB as using a computer to charge ProWand will exceed the 1 hour charging time.

The LED ring on ProWand indicates the battery level and charging progress.

-  When the LED indicator blinks red, the battery is approximately 20% charged.
-  When the battery is over 20% but lower than 50% charged, the LED indicator will blink orange.
-  When the battery is over 50% but lower than 80% charged, the LED indicator will blink yellow.
-  When the battery is 80% charged, the LED indicator will blink green.
-  The LED light will turn solid green when ProWand is fully charged. Please disconnect the charger before use.



AFTERCARE AND HELP

Specifications

Materials:	ABS plastic, body-friendly silicone
Size:	241 mm H x 50 mm W x 50 mm H
Weight:	177 g (ProWand only)
Charging:	4 hours
User time:	10+ hours
Stimulation:	Clitoris
Waterproof:	Yes

Help

If you have any further problems with setup and installation or issues with using your device, please do not hesitate to contact our Customer Support team. Our team is there for your support and to help, whatever it is you may need. We aim to answer all questions within 48 hours of your query.

For frequently asked questions visit

www.kiiroo.com/faq
www.kiiroo.com

Contact

info@kiiroo.com



FCC STATEMENT

The equipment is used in portable condition.

“The antenna(s) used for this transmitter must not be colocated or operating in conjunction with any other antenna or transmitter”.

This device complies with Part 15 of the FCC Rules.

The operation is subject to the following two conditions: This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation.

prowand

BENUTZERHANDBUCH



Jedes Mal, wenn ein Update verfügbar ist, empfehlen wir Ihnen, Ihre App und Ihr Gerät zu aktualisieren. Durch aktuelle Geräte- und App-Versionen stehen Ihnen immer die neuesten Funktionen zur Verfügung und Ihre Sicherheit ist gewährleistet.

Nutzung des Logos

Apple und das Apple-Logo sind Marken von Apple Inc. und sind in den Vereinigten Staaten von Amerika und in anderen Ländern eingetragen. App Store ist eine Dienstleistungsmarke von Apple Inc. und in den USA und anderen Ländern eingetragen.

Google Play und das Google Play Logo sind Marken von Google Inc.

Die Bluetooth® Wortmarke und Logos sind eingetragene Marken von Bluetooth SIG, Inc. und jede Verwendung dieser Marken durch Kiiroo erfolgt unter Lizenz.

Andere Marken und Handelsnamen sind Eigentum ihrer jeweiligen Inhaber.

Inhaltsübersicht

Dein Gerät einrichten	5
Dein Gerät benutzen	6
Modi	8
Bluetooth-Modus	
Manueller Modus	
FeelConnect & Dienstleistungen	11
Aufladen und LED-Anzeige	16
Handling	17
Schmierung	
Haftungsausschluss und Warnhinweise	18
Spezifikationen für die Entsorgung	20
Nachsorge und Hilfe	21
Spezifikationen & FAQ	
FCC-Erklärung, ISED-Erklärung	22

