


KQZ

AIR PURIFIER

USER MANUAL



Product Model: KQZ-300

Thank you for purchasing our product. In order to bring you the best experience, please read the instruction manual carefully before using and keep it for future reference.

Contents

Notices & Warnings	2
Machine Spare Parts &Components of Product --	3
Guidance for Usage	4
Filter replacement steps	5
Water tank filling operation steps	7
Solution of Common Troubles	8
Technical Specifications	9
After-sales service	11
Warranty Card	12

Notices & Warnings

Power Notice

- Only use two-pin sockets that meet the standard voltage of the nameplate. If the power cord, power cord plug, and power socket are damaged, do not use the product; when unplugging the power plug, you must hold the plug tightly instead of pulling the power cord. Otherwise, it may cause electric shock or fire due to short circuit. If the power cord is damaged, it must be replaced by a professional from the manufacturer, its maintenance department or similar department in order to avoid danger.
 - Do not use the machine without a filter installed.
-

Prohibited Notice

- Forbidden to use alcohol or organic solvents to wipe the machine, otherwise it will damage the machine, and it is also easy to cause electric shock, injury, fire, etc.; it is forbidden to add water with pollution, irritating odor or chemical additives;
 - Prohibit the use of insecticide sprays while the machine is running;
 - Contact with flammable substances or sources of ignition is prohibited.
-

Notice When Using The Machine

- Do not insert foreign objects into the air inlet or outlet;
 - Do not block the air inlet/outlet;
 - Do not approach or place it on heat source objects (such as stoves and other places that may come into contact with flammable gases);
 - In case of malfunctions such as smoke and odor, unplug the power plug immediately. Do not use it when there are oil residues in the room, smoke from incense burning, flames from cigarette lighting, or chemical odors in the air;
-

Usage Restrictions

- Do not use this machine in an environment full of hydrogen, natural gas, and other flammable gases to avoid electric shock, fire and other damages;
 - When using spray pesticides, do not use this machine; do not use it in unstable places such as easy dumping, bathrooms and other places with high temperature, humidity, and water, so as to avoid electric shock, fire or other damage.
-

Cleaning Notice


- Do not wash and reuse the composite filter; only use a soft cloth to clean the surface of the machine, otherwise the machine may be damaged or broken, and may also cause sensor failure; when cleaning the machine or not using the machine, please clean Unplug the power plug from the power outlet, otherwise it may cause electric shock or fire due to short circuit.
-

Warm Tips


- This machine is not suitable for disabled, perceptually handicapped, intellectually handicapped or children to operate by themselves.
- Children are not allowed to climb, so as to avoid the instability of the machine and cause injury.
- When moving, be sure to stop the operation first and unplug the power plug.

Machine Spare Parts & Components of Product

1. Product components




Air Purifier Device




Air Filter

The filter is placed inside the device, please remove the packaging bag before use



User Manual


2. Product structure introduction



Guidance for Usage

1. Instruction of Control Panel

Once the device is powered on, it enters standby mode



· Schematic Diagram ·



Power On/Off

- a. Press power button to turn on/off



"Wind speed" button, display the wind speed gear.

- a. When you click this button repeatedly, you can switch between manual/automatic/sleep wind speed modes, which are gear 1, gear 2, gear 3, and gear 4, automatic mode, sleep mode.



"Timer" button, display the set time

- a. When the digital tube displays PM2.5, touching this key will first display the current timing time (without time switching) and then each time you press it will switch the time once, a key beep, timing 1h, the digital tube lights up, press multiple times The timing key can cycle to select the timing time, (the digital tube displays the timing, and the PM2.5 value will be restored after 5S) 1h...2h 3h... 12h --h 1h...Cyclic switching ("--h" means no Timing, if it is in the state of setting timing power on, "--h" will not be displayed), after displaying 2S, it will enter the countdown state.

After the timer is complete:

- a. Scheduled shutdown: If it is on, it will shutdown at scheduled time.
b. Timing power-on: If it is in the standby state, it will power on regularly



"Child lock" button, turn on/off the child lock function

- a. Long press this button for 3s to enter child lock mode, and long press this button for 3s again to exit child lock mode.



"Humidifier" button, turn on/off humidifier function

- a. Press this button to turn on/off humidifier function
b. This function works continuously for 2 hours and automatically turns off




"TIMER"+ "FAN SPEED "button, reset filter

- a. When the filter life expires, long press "timer"+ "fan speed " for 3s, the filter life reset is completed.




Long press " HUMIDIFIER "+ " FAN SPEED " button for 3s , enter the WIFI network pairing mode

Filter replacement steps




1. Turn off and cut off the power of the host.

Note: Turn off the purifier, the purifier is in standby mode, you need to unplug the power plug, to cut off the power of the host.



2. Open the filter cover.

Open the door cover. After the purifier is powered off, grab the handle of the filter cover and pull it out




3. Take out the filter and grab the waste filter material in a garbage bag to prevent the pollutants on the filter material from falling into the room.

Points for attention:

- a. Please dispose of used filters as non-combustible garbage;
- b. The replacement cycle of the filter is about half a year (due to the different use environments, the replacement cycle of the filter varies greatly);
- c. When the filter indicator is red, it prompts to replace the filter.


Filter replacement steps



4. Adjust the direction of the new filter to corresponding to the filter groove on the upper purifier, and install the filter; then grab the filter cover, and align the bottom of the filter cover with the groove at the bottom of the main unit before closing. Put on the door cover, plug in the power and it can run.

Points for attention:

- a. Please read the filter replacement operation in detail to ensure the purification effect of the purifier.
- b. Before cleaning the purifier system, remove the power plug and cut off the power to the purifier system.
- c. Keep the inside of the purifier dry to prevent damage to the circuit.
- d. In case of dust on the surface area, use a vacuum cleaner to clean the dust on the surface, which can prolong the service life of the filter.




5. Please reset the filter after the replacement, long press the timer + speed button for 3 seconds

Points for attention:


- a. The side of the filter with handle is facing outward.

Water tank filling operation steps




1. Shut down and cut off the power of the host.


Note: Turn off the purifier, the purifier is in standby mode, you need to unplug the power plug to cut off the power of the host.



2. Take the humidification module out of the machine.



3. Unscrew the water tank cover counterclockwise. After adding clean tap water (you can add a small amount of aromatherapy liquid as needed), tighten the water tank cover clockwise.



6. Dry the water tank and the water tank cover, put the humidification module back into the machine, and let the magnet absorb the water tank.

5. After the power is turned on, press the "humidify" button to turn on/off the humidification function.

Solution of Common Troubles

If your purifier is not functioning properly, check the following before servicing:

Phenomenon	Possible reason	Solution
Machine does not start	a. The power plug is not installed. b. The host panel is not in place.	a. Reconnect the power plug. b. Reinstall the host panel and seat it in place.
Air outlet, smelly	a. There are many pollution sources in the room, such as many people smoking, barbecue, etc. b. The filter is heavily contaminated.	a. It is recommended to ventilate the room. b. Replace the filter with a new one.
The effect of dust removal and purification is not significant. Air quality has not improved significantly	a. There is no filter installed on the machine. b. The machine is placed in or near a small place There are obstacles that affect the purification effect. c. The filter is too dirty.	a. Install the filter. b. Clear the blockage. c. Clean or replace the filter.
Running noise is too high	a. Whether the installation is not firm enough. b. There are debris in the machine.	a. Contact the after-sales service center. b. Remove debris.
Host key failure	a. Child lock may be turned on	a. Press and hold the child lock button for 3 seconds to release the child lock
Humidification function suddenly turned off	a. The humidification function works continuously for more than 2 hours, and the machine program sets the humidification function to work continuously for 2 hours, and it will automatically turn off.	a. Refill the water tank and press the humidification button again to turn it on.
Humidify without fog	a. The water level of the water tank is too low. b. The water tank is not installed in place	a. Refill the water tank. b. The water tank is installed in place.
There is water in the fog outlet	a. The fan airflow interferes with the mist causing condensation to form on the mist outlet.	a. It is normal, just dry it with a paper towel.

Fault code	Fault description	Solutions
EE	Filter life expired	a. Please replace the filter and reset it; reset operation: in the standby state, press the "timing + wind speed" button at the same time for 3 seconds, the machine will make three sounds of ding, ding, and ding, and the reset is successful.


Note: If the fault cannot be eliminated after the above inspection, please contact the maintenance online shop or technical service center provided by our service center. Do not disassemble and repair by yourself to avoid danger and damage to the machine.

Technical Specifications

1. Technical parameters

Product Name	Air Purifier	Model No.	KQZ-300
Rated Voltage	110-120V~	Rated frequency	60Hz
Noise	≤65dB(A)	Input power	70W
Particulate Matter Clean Air Volume (CADR Particulate Matter)		300m³/h	
Applicable Area		21m²~36m²	
Product Size		380×170×465mm	
Net Weight/Gross Weight		5.5kg/6.5kg	

2. Electrical Schematic



After-Sales Service

1. Terms of Warranty


1. The product is warranted according to the Chinese national "three guarantees" regulations.
2. A lifetime maintenance service is available at the company's after-sales service center.
3. The following circumstances are not in the scope of the "three guarantees":
 - 1) the machine damage caused by human factors.
 - 2) Damage caused by unauthorized disassembly and repair by personnel not authorized by the Company.
 - 3) Normal loss and wear during use.
 - 4) Filter screen (except for the shortcomings of the filter material and the product itself).
 - 5) Damage caused by failure to install and use the operation manual correctly.

2. Important Notice

In order to protect your rights and interests, please pay attention to the following information:

1. When buying the machine, fill in your after-sales service card completely, correctly and truthfully, and stamp it with the seller's seal.
2. Please properly keep the after-sales service card user union that has been filled in and stamped with the seller's seal.
3. Effective after-sales service card is the basic guarantee to realize your after-sales service rights of products. (Effective after-sales service. The card filling content is comprehensive, true, correct, with no alteration trace).
4. The product shall not be used by personnel (including children) with insufficient physical strength, sensory or mental ability or inexperienced knowledge, unless they are under the supervision of other safety personnel or with instructions for the use of the product.

3. Product Quality Warranty Card



Warranty Card

Air Purifier Warranty Card (User Saved)

Model							
Warranty Period		Year	Month	Date to	Year	Month	Date
Name	Name				Telephone		
	Address						
Sales Agent	Name				Telephone		
	Address						
After-sales service description		<p>1. Warranty terms</p> <p>a) From the date of purchase, the warranty period is 1 year, and the warranty period is free of charge (except for force majeure and man-made factors).</p> <p>b) Gifts that come with shopping are not covered by warranty.</p> <p>c) Voucher: Purchase records, purchase vouchers issued by the company, and invoices are all acceptable.</p> <p>2. Spare parts</p> <p>a) During the warranty period, the accessories are free of charge, and the market price will be charged outside the warranty period.</p>					

The design parameters, specifications and other information of this product are subject to change without prior notice, please refer to the actual machine.

The packaging and printed matter of this product are specially designed for the Chinese mainland market, and the company reserves the right of final interpretation of its information.

Air purifier warranty card (Distributor Saved)

Model							
Warranty Period		Year	Month	Date to	Year	Month	Date
Name	Name				Telephone		
	Address						
Sales Agent	Name				Telephone		
	Address						
After-sales service description		<p>1. Warranty terms</p> <p>a) From the date of purchase, the warranty period is 1 year, and the warranty period is free of charge (except for force majeure and man-made factors).</p> <p>b) Gifts that come with shopping are not covered by warranty.</p> <p>c) Voucher: Purchase records, purchase vouchers issued by the company, and invoices are all acceptable.</p> <p>2. Spare parts</p> <p>a) During the warranty period, the accessories are free of charge, and the market price will be charged outside the warranty period.</p>					

After-Sales Service

Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.